

VEICHI



Manual

AC310 Series Frequency Inverter

Catalog

| | |
|--|----|
| Chapter 1 General..... | 1 |
| 1.1 Safety Precaution..... | 1 |
| 1.2 Pre-use..... | 1 |
| 1.3 Technical Specifications..... | 3 |
| Chapter 2 Installation..... | 5 |
| Chapter 3 Panel Layout and Operation Instructions..... | 13 |
| Chapter 4 Parameter List..... | 15 |
| 4.1 Terms and Marks..... | 15 |
| 4.2 Parameter List..... | 15 |
| 4.3 F00: Environmental Parameters..... | 16 |
| F00.0x: Environment Settings..... | 16 |
| F00.1x~F00.3x: Common Parameters..... | 17 |
| 4.4 F01: Basic Settings..... | 17 |
| F01.0x: Basic Commands..... | 17 |
| F01.1x: Frequency Commands..... | 18 |
| F01.2x~F01.3x: Acceleration/Deceleration Time..... | 19 |
| F01.4x: PWM..... | 20 |
| 4.5 F02: Motor 1 Parameters..... | 20 |
| F02.0x: Basic Motor Parameters and Auto-Tuning..... | 20 |
| F02.1x: AM Advanced Parameters..... | 21 |
| F02.2x: PM Advanced Parameters..... | 21 |
| F02.3x~F02.4x: Encoder Parameters..... | 22 |
| F02.5x~F02.6x: Motor Application Parameters..... | 23 |
| 4.6 F03: Vector Control..... | 23 |
| F03.0x: ASR (Automatic Speed Regulator)..... | 23 |
| F03.1x: ACR and Torque Limit..... | 24 |
| F03.2x: Torque Optimization..... | 25 |
| F03.3x: Magnetic Flux Optimization..... | 25 |
| F03.4x~F03.5x: Torque Control..... | 26 |
| F03.6x: PM High-Frequency Injection..... | 27 |
| F03.7x: Position Compensation..... | 28 |

- F03.8x: Expansion Control..... 28
- 4.7 F04: V/F Control..... 28
 - F04.0x: V/F Control..... 28
 - F04.1x: Customized V/F Curve.....29
 - F04.2x: V/F Conversion.....30
 - F04.3x: V/F ECO Control.....30
- 4.8 F05: Input Terminal..... 31
 - F05.0x: Digital Input Terminal..... 31
 - F05.1x:DI Terminal Detection Delay.....32
 - F05.2x: DI Terminal Characteristics..... 32
 - F05.3x: PUL Terminal..... 33
 - F05.4x: AI Type..... 33
 - F05.5x: AI Linear Parameters.....34
 - F05.6x: AI Curve 1..... 34
 - F05.7x: AI Curve 2..... 35
 - F05.8x: AI as DI Terminal.....35
- 4.9 F06: Output Terminal.....36
 - F06.0x: AO(Analog Output)..... 36
 - F06.1x: AO Expansion..... 37
 - F06.2x~F06.3x: DO and RO..... 37
 - F06.4x: Frequency Detection..... 38
 - F06.5x: Monitor Comparator Output 1..... 38
 - F06.6x~F06.7x: Virtual I/O Terminal.....39
 - F06.7x: Monitor Comparator 2 Output..... 40
- 4.10 F07: Operation Control..... 41
 - F07.0x: Connection..... 41
 - F07.1x: Stop Control..... 41
 - F07.2x: DC Brake and Speed Tracking.....42
 - F07.3x: Jogging.....42
 - F07.4x: Holding and Jump Frequency during Start/Stop.....43
- 4.11 F08: Auxiliary Control..... 43
 - F08.0x: Counting and Timing..... 43
 - F08.3x : Swing Frequency..... 44
- 4.12 F09: Auxiliary Control 2..... 45

| | |
|---|----|
| F09.0x: Maintenance | 45 |
| 4.13 F10: Protection Parameters | 45 |
| F10.0x: Current Protection | 45 |
| F10.1x: Voltage Protection | 46 |
| F10.2x: Auxiliary Protection | 47 |
| F10.3x: Load Protection | 48 |
| F10.4x: Stall Protection | 49 |
| F10.5x: Fault Recovery Protection and Motor Overload | 50 |
| 4.14 F11: Panel Parameters | 51 |
| F11.0x: Key Operation | 51 |
| F11.1x: Cyclic Monitoring of Status Interface | 52 |
| F11.2x: Monitoring Parameters | 53 |
| F11.3x: Special Functions of Panel | 53 |
| 4.15 F12: Communication Parameters | 54 |
| F12.0x: Modbus slave parameters | 55 |
| F12.1x: Modbus Master Parameters | 56 |
| F12.2x: Modbus Special Functions | 56 |
| F12.3x: PROFIBUS-DP | 57 |
| F12.4x: CANopen | 57 |
| F12.5x~F12.6x: Expansion Communication of EX_A and EX_B | 58 |
| 4.16 F13: PID Control | 59 |
| F13.00~F13.06: PID Setting and Feedback | 59 |
| F13.07~F13.24: PID Regulation | 59 |
| F13.25~F13.28: PID Feedback Disconnection | 60 |
| F13.29~F13.33: PID Sleep | 61 |
| 4.17 F14: Multi-seg Speed and Simple PLC | 61 |
| F14.00~F14.14: Multi-seg Speed Frequency | 61 |
| F14.15: PLC Operation Mode | 62 |
| F14.16~F14.30 : PLC Runtime | 62 |
| F14.31~F14.45 : PLC Operation Direction and Time | 64 |
| 4.18 F15: Reserved | 64 |
| 4.19 F16: Tension Control | 64 |
| F16.01~F16.02: Tension Mode | 64 |
| F16.03~F16.09: Tension Setting | 65 |

| | |
|---|----|
| F16.12~F16.16: Friction Compensation..... | 65 |
| F16.30~F16.32: Material Fracture Detection..... | 66 |
| F16.36~F16.38: Pre-drive..... | 66 |
| F16.42~F16.43: Stop Braking..... | 66 |
| F16.44~F16.55: Roll Diameter..... | 66 |
| F16.56~F16.63: Roll Diameter Calculation by Linear Speed..... | 67 |
| F16.68~F16.70: Thickness-based Roll Diameter Calculation..... | 68 |
| F16.75~F16.82: Tension PID..... | 68 |
| 4.20 F25: AI and AO Correction..... | 69 |
| 4.21 C0x: Monitoring Parameters..... | 69 |
| C00: Basic Monitoring..... | 69 |
| C01: Fault Monitoring..... | 69 |
| C02: App Monitoring..... | 70 |
| C03 group: maintenance and tension monitoring..... | 70 |
| 4.22 Terminal I/O Function Selection..... | 71 |
| 4.23 Fault and Warning Code List..... | 72 |
| Chapter Five Regular Inspection and Maintenance..... | 74 |
| 5.1. Inspection..... | 74 |
| 5.2 Maintenance..... | 75 |
| 5.3 Product Warranty..... | 75 |
| Appendix I: Modbus Communication Protocol..... | 76 |
| Appendix II: Terminal Wiring Methods..... | 79 |
| Appendix III: External Panel Dimensions and Models..... | 80 |
| Version Change Log..... | 81 |

Chapter 1 General

1.1 Safety Precaution

To ensure safe and proper use of this product, please fully understand the safety precautions outlined in this manual before using.

Signs and Meanings

The following signs are used in this manual to highlight the key safety points. Failure to observe these points may result in damages to this product and the associated system, or even personal injuries.

| | |
|---|--|
|  | <p>DANGER: Incorrect operation may result in death or major safety incidents.</p> |
|  | <p>CAUTION: Incorrect operation may result in minor injuries.</p> |

Operator

This product must be installed, operated and maintained by trained professionals. "Trained professionals" means that the personnel working on this product must be trained with specialized skills and knowledge about installation, wiring, operation and maintenance of the equipment, so they can respond correctly to various emergencies that may arise during use.

Safety Guide

The safety rules and warning signs presented for safety are taken to prevent personal injuries and damages to the products and the associated systems. Please read this manual carefully before use and strictly follow the safety guidelines and warning signs in this manual.



- Correct transportation, storage, installation, as well as careful operation and maintenance, for the safe operation of the AC drive is essential. During transportation and storage, it is crucial to protect the AC drive from shocks and vibrations. Additionally, it should be stored in a dry environment free of corrosive gases and conductive dust below 60°C.
- This product is equipped with hazardous voltage to control potentially dangerous motion mechanisms. Failure to observe the regulations or this manual may lead to damages to the products and associated systems, or even personal injuries and death.
- Do not perform wiring work while the power is on, as there is a risk of death by electric shock. Before performing wiring, inspection, maintenance, etc., disconnect the power supply to all associated equipment and make sure that the DC voltage in the main circuit has dropped to a safe level for 5 minutes.
- The power cables, motor cables, and control cables must all be tightly connected, and the grounding terminal must be grounded with resistance lower than 10Ω.
- The static electricity of human body may cause significant harm to internal sensitive devices. So it is crucial for professionals to adhere to the measures and methods outlined in the Electrostatic Discharge Prevention (ESD) guidelines before commencing work on the AC drives.
- Due to the pulse waveform output voltage of the AC drive, it is essential to remove the installed power factor improvement capacitors, lightning protection varistors or other devices on the output side of the AC drive, or move the devices to the input side.
- Do not add switching devices such as circuit breakers and contactors to the output side of the AC drive. (If it is necessary to connect switching devices to the output side, please ensure that the output current of the AC drive is zero when the switch is on or off.)
- Failure of the control device could lead to production halt and significant accidents. Therefore, please apply the necessary external protection measures or backup devices.
- This product is intended for the manufacturer's specified purposes. Unauthorized applications in such as emergency, rescue, marine, medical, aviation, or facility-related settings are seriously prohibited.
- Maintenance of this product can only be carried out by VEICHI or by professionals authorized and licensed by VEICHI. Unauthorized modification or accessories may result in product failure. Any defective devices during maintenance must be replaced timely.

1.2 Pre-use

Please check the outer packaging for any damage upon receiving the ordered products. And then check the product inside for any damage, scratches, or dirt (Please **Note** that damage during transportation is not covered by the Three Guarantees warranty policy.) If the product is damaged

during shipping, please contact us or the shipping company immediately. If everything is fine, please double-check that the model number of the received drive is the same as the order sheet.

Drive Model and Description



Drive rated output current

| Power(kW) | Input Voltage(V) | | | |
|-----------|-------------------|-----|-----|--|
| | Output Current(A) | | | |
| | 220 | 380 | 660 | |
| 0.75 | 4 | 3 | - | |
| 1.5 | 7 | 4 | - | |
| 2.2 | 10 | 6 | - | |
| 4 | 16 | 10 | - | |
| 5.5 | 20 | 13 | - | |
| 7.5 | 30 | 17 | - | |
| 11 | 42 | 25 | - | |
| 15 | 55 | 32 | - | |
| 18.5 | 70 | 38 | - | |
| 22 | 80 | 45 | 28 | |
| 30 | 110 | 60 | 35 | |
| 37 | 130 | 75 | 45 | |
| 45 | 160 | 90 | 52 | |
| 55 | 200 | 110 | 63 | |
| 75 | 260 | 150 | 86 | |
| 90 | 320 | 180 | 98 | |
| 110 | 380 | 210 | 121 | |
| 132 | 420 | 250 | 150 | |
| 160 | 550 | 310 | 175 | |
| 185 | 600 | 340 | 198 | |
| 200 | 660 | 380 | 218 | |
| 220 | 720 | 415 | 235 | |
| 250 | - | 470 | 270 | |
| 280 | - | 510 | 330 | |

| | | | |
|------|---|------|------|
| 315 | - | 600 | 345 |
| 355 | - | 670 | 380 |
| 400 | - | 750 | 430 |
| 450 | - | 810 | 466 |
| 500 | - | 860 | 540 |
| 560 | - | 990 | 600 |
| 630 | - | 1200 | 690 |
| 710 | - | 1340 | 760 |
| 800 | - | 1500 | 860 |
| 900 | - | 1620 | 932 |
| 1000 | - | 1720 | 1080 |
| 1120 | - | 1980 | 1200 |

1.3 Technical Specifications


| Item | | Specification |
|--------------------------|----------------------------|---|
| Power Input | Voltage and frequency | S2: Single-phase 200V~240V 50Hz/60Hz; T2: Three-phase 200V~240V 50Hz/60Hz; T3: Three-phase 380V~480V 50Hz/60Hz; T6: Three-phase 660V~690V 50Hz/60Hz. |
| | Allowable fluctuation | T/S2: -10%~10%; T3: -15%~10%; T6: -10%~10% Voltage imbalance rate: <3%; Frequency: ±5%; Distortion rate with reference to IEC61800-2 |
| | Switching impulse current | <rated current |
| Output | Output voltage | Output under rated conditions: Three-phase, 0V~input voltage, tolerance<5% |
| | Output frequency range | 0Hz~599Hz |
| | Output frequency accuracy | ±0.5% of the max. frequency |
| | Overload capacity | G: 150% of rated current for 89s, 180% of rated current for 10s, and 200% of rated current for 3s P: 120% of rated current for 35s, 140% of rated current for 7s, and 150% of rated current for 3s |
| Main Control Performance | Motor type | Three-phase asynchronous motors, permanent magnet synchronous motors (sine wave), and synchronous reluctance motors |
| | Control mode | V/F control, SVC, FVC, and voltage-frequency conversion control |
| | Modulation | PWM |
| | Carrier frequency | 1.0kHz~16.0kHz |
| | Speed control range | SVC: Rated load 1:200 FVC: Rated load 1:200 |
| | Speed stabilizing accuracy | SVC: ± 0.5% (Three-phase AM), ±0.1% (PM) FVC: ±0.02% |
| | Starting torque | SVC: 150% of the motor rated torque at 0.25Hz FVC: 200% of the motor rated torque at 0Hz |
| | Torque response | SVC: <10ms; FVC: <5ms |
| | Torque accuracy | SVC: ±5%; FVC: ±2.5% |
| | Frequency accuracy | Digit setting: Max. frequency × (±0.01%); analog setting: Max. frequency × (±0.2%) |
| | Frequency resolution | Digit setting: 0.01Hz; analog setting: Max. frequency × ±0.05% |
| Basic Function | Torque control | Torque calculation and speed limit in torque mode |
| | DC brake | Starting frequency: 0.00Hz~50.00Hz; Braking time: 0.0s~60.0s; Braking current: 0.0%~150.0% of rated current |
| | Torque boost | Auto torque boost: 0.0%~100.0%; manual torque boost: 0.0%~30.0% |
| | V/F curve | 4 patterns: Linear torque curve, self-defined V/F curve, torque drop curves (1.1~2.0 power), and square V/F curve |
| | ACC/DEC curve | 2 patterns: Linear and S-curve acceleration/deceleration 4 sets of acceleration/deceleration time, unit: 0.01s, 650.00s max |

| | | | |
|----------------|------------------------------|--|--|
| | Rated output voltage | With the power voltage compensation function, it can be set within 50%~100% with the rated voltage of the motor as 100% (the output cannot exceed the input voltage) | |
| | Auto voltage regulation | The output voltage can be automatically kept constant during the grid voltage fluctuation | |
| | Auto ECO mode | Output voltage is automatically optimized according to the load under V/F control mode to save energy. | |
| | Auto current limit | Auto current limit works during operation to prevent frequent tripping due to over-current fault. | |
| | Instantaneous power-cut mode | Uninterrupted operation is realized through bus voltage control in case of instantaneous power loss | |
| | Standard function | PID control, speed tracking and restart after power down, jump frequency, upper/lower frequency limit control, programmed operation, multi-segment speed, RS485, analog output, frequency pulse output, parameter access level setting, common parameter setting, monitoring comparator output, counting and timing, and swing frequency | |
| | Frequency source | Digital setting via the panel, panel potentiometer, analog voltage/current terminal AI1 and AI2, communication, terminal combination, and frequency source combination | |
| | Feedback input source | Set via AI1 and AI2, communication, and PUL terminal | |
| | Command source | Set via operation panel, external terminals and communication | |
| | Input command signal | Start, stop, forward and reverse, jog, multi-segment speed, free stop, reset, acceleration/deceleration time, frequency setting method selection, and external fault alarms. | |
| | Output signal | 1 × relay output, 1 × open collector output, and 1 × analog output can be selected to 0V~10V, 0mA~20mA or 4mA~20mA, or frequency pulse output | |
| Protection | | Over-voltage, under-voltage, current limit, over-current, overload, electronic thermal relay, over-heat, over-voltage stall, data protection, overspeed protection and input/output phase loss protection | |
| Panel Display | LED display | Built-in panel: Single-line 5-bit digital tube | To monitor the status of 1 AC drive |
| | | External panel: Single/dual line 5-bit digital tube | Dual-line to monitor the status of 2 AC drives |
| | Parameter copy | The function code information of the AC drive can be uploaded and downloaded to realize fast parameter copying | |
| | Status monitoring | All parameters of the monitoring parameter group include output frequency, given frequency, output current, input voltage, output voltage, motor speed, PID feedback, PID setting, module temperature, given torque, output torque, etc. | |
| | Fault warning | OV, UV, OC, SC, phase loss, OL, OT, OV stall, current limit, data damaged, operating conditions of current faults, and fault history | |
| Environment | Installation | <1000 meters, derate 1% for every 100 meters rise when above 1000m. No condensation, icing, rain, snow, hail, etc., solar radiation below 700W/m ² , air pressure 70kPa~106kPa | |
| | Temperature, humidity | -10°C~+50°C, derate above 40°C, 60°C max. (no-load) 5%RH~95%RH (non-condensing) | |
| | Vibration | 5.9m/s ² (0.6G) at 9Hz~200Hz | |
| | Storage temperature | -30°C~+60°C | |
| | Installation method | Wall-mounting | |
| | Protection | IP20 | |
| | Pollution class | Level 2 | |
| Cooling method | Forced air-cooling | | |


Chapter 2 Installation

To ensure personal safety, maximized product performance and reliable operation of the drive, please use the products in strict accordance with the environmental, wiring and ventilation requirements described in this chapter.

External dimensions of the AC drive(plastic)




| Drive Model | Outer Dimension(mm) | | | | | Installation Dimension(mm) | | | | | Aperture |
|-----------------------|---------------------|-----|-------|-----|-----|----------------------------|------|-------|-----|-----|----------|
| | W | H | H1 | D | D1 | W1 | W2 | H2 | A | B | |
| AC310-T/ S2-R75G-B | 76 | 200 | 192 | 155 | 149 | 65 | 65 | 193 | 5.5 | 4 | 3-M4 |
| AC310-T/ S2-1R5G-B | | | | | | | | | | | |
| AC310-T/ S2-2R2G-B | 100 | 242 | 231 | 155 | 149 | 84 | 86.5 | 231.5 | 8 | 5.5 | 3-M4 |
| AC310-T/ S2-004G-B | | | | | | | | | | | |
| AC310-T3-R75G/ 1R5P-B | 76 | 200 | 192 | 155 | 149 | 65 | 65 | 193 | 5.5 | 4 | 3-M4 |
| AC310-T3-1R5G/ 2R2P-B | | | | | | | | | | | |
| AC310-T3-2R2G-B | 100 | 242 | 231 | 155 | 149 | 84 | 86.5 | 231.5 | 8 | 5.5 | 3-M4 |
| AC310-T3-004G/ 5R5P-B | | | | | | | | | | | |
| AC310-T3-5R5G/ 7R5P-B | 116 | 320 | 307.5 | 175 | 169 | 98 | 100 | 307.5 | 9 | 6 | 3-M5 |
| AC310-T3-011G/ 015P-B | | | | | | | | | | | |
| AC310-T/ 2-5R5G-B | | | | | | | | | | | |



| Drive Model | Outer Dimension(mm) | | | | | Installation Dimension(mm) | | | | Aperture |
|-----------------------|---------------------|-----|-----|-----|-----|----------------------------|-----|-------|-----|----------|
| | W | H | H1 | D | D1 | W1 | W2 | H2 | B | |
| AC310-T/ S2-7R5G-B | 142 | 383 | 372 | 225 | 219 | 125 | 100 | 372 | 6 | 4-M5 |
| AC310-T/ S2-011G-B | | | | | | | | | | |
| AC310-T/ S2-015G | 172 | 430 | - | 225 | 219 | 150 | 150 | 416.5 | 7.5 | 4-M5 |
| AC310-T2-018G | | | | | | | | | | |
| AC310-T2-022G | | | | | | | | | | |
| AC310-T3-015G/ 018P-B | 142 | 383 | 372 | 225 | 219 | 125 | 100 | 372 | 6 | 4-M5 |
| AC310-T3-018G/ 022P-B | | | | | | | | | | |
| AC310-T3-022G/ 030P-B | | | | | | | | | | |
| AC310-T3-030G/ 037P | 172 | 430 | - | 225 | 219 | 150 | 150 | 416.5 | 7.5 | 4-M5 |
| AC310-T3-037G/ 045P | | | | | | | | | | |


External dimensions of the AC drive(steel)



| Drive Model | Outer Dimension | | | | Hole Position | | Aperture |
|-----------------------|-----------------|-----|-----|-----|---------------|-----|----------|
| | W | H | H1 | D | W1 | H2 | |
| AC310-T2-030G | 240 | 560 | 520 | 310 | 176 | 544 | 4-M6 |
| AC310-T2-037G | | | | | | | |
| AC310-T2-045G | | | | | | | |
| AC310-T2-055G | 270 | 638 | 580 | 350 | 195 | 615 | 4-M8 |
| AC310-T3-045G/ 055P | 240 | 560 | 520 | 310 | 176 | 544 | 4-M6 |
| AC310-T3-055G/ 075P | | | | | | | |
| AC310-T3-075G/ 090P | | | | | | | |
| AC310-T6-022G/ 030P | | | | | | | |
| AC310-T6-030G/ 037P | | | | | | | |
| AC310-T6-037G/ 045P | | | | | | | |
| AC310-T6-045G/ 055P | 270 | 638 | 580 | 350 | 195 | 615 | 4-M8 |
| AC310-T6-055G/ 075P | | | | | | | |
| AC310-T6-075G/ 090P | | | | | | | |
| AC310-T3-090G/ 110P | | | | | | | |
| AC310-T3-110G/ 132P | 350 | 738 | 680 | 405 | 220 | 715 | 4-M8 |
| AC310-T6-090G/ 110P | | | | | | | |
| AC310-T6-110G/ 132P | | | | | | | |
| AC310-T3-132G/ 160P-L | | | | | | | |
| AC310-T3-160G/ 185P-L | 350 | 738 | 680 | 405 | 220 | 715 | 4-M8 |
| AC310-T6-132G/ 160P-L | | | | | | | |
| AC310-T6-160G/ 185P-L | | | | | | | |


| | | | | | | | |
|----------------------|-----|------|------|-----|-----|------|-------|
| AC310-T3-185G/200P-L | 360 | 940 | 850 | 480 | 200 | 910 | 4-M16 |
| AC310-T3-200G/220P-L | | | | | | | |
| AC310-T3-220G/250P-L | | | | | | | |
| AC310-T6-185G/200P-L | | | | | | | |
| AC310-T6-200G/220P-L | | | | | | | |
| AC310-T6-220G/250P-L | | | | | | | |
| AC310-T3-250G/280P-L | 370 | 1140 | 1050 | 545 | 200 | 1110 | 4-M16 |
| AC310-T3-280G/315P-L | | | | | | | |
| AC310-T6-250G/280P-L | | | | | | | |
| AC310-T6-280G/315P-L | | | | | | | |
| AC310-T3-315G/355P-L | 400 | 1250 | 1140 | 545 | 240 | 1213 | 4-M16 |
| AC310-T3-355G/400P-L | | | | | | | |
| AC310-T3-400G/450P-L | | | | | | | |
| AC310-T6-315G/355P-L | | | | | | | |
| AC310-T6-355G/400P-L | | | | | | | |
| AC310-T6-400G/450P-L | | | | | | | |
| AC310-T3-450G/500P-L | 460 | 1400 | 1293 | 545 | 300 | 1363 | 4-M16 |
| AC310-T3-500G/560P-L | | | | | | | |
| AC310-T3-560G/630P-L | | | | | | | |
| AC310-T6-450G/500P-L | | | | | | | |
| AC310-T6-500G/560P-L | | | | | | | |
| AC310-T6-560G/630P-L | | | | | | | |

External dimensions of the AC drive (cabinet)




| Drive Model | Outer Dimension (mm) | | | | Hole Position (mm) | | | | Aperture |
|-------------------------|----------------------|------|------|-----|--------------------|----|-----|-------|----------|
| | W | H | H1 | D | W1 | W2 | D1 | D2 | |
| AC310-T3-630G/710P-LD | 1200 | 2200 | 2080 | 800 | 520 | 54 | 494 | 108.5 | φ14 |
| AC310-T3-710G/800P-LD | | | | | | | | | |
| AC310-T3-800G/900P-LD | | | | | | | | | |
| AC310-T3-900G/1000P-LD | | | | | | | | | |
| AC310-T3-1000G/1120P-LD | | | | | | | | | |
| AC310-T3-1120G-LD | | | | | | | | | |
| AC310-T6-630G/710P-LD | | | | | | | | | |
| AC310-T6-710G/800P-LD | | | | | | | | | |
| AC310-T6-800G/900P-LD | | | | | | | | | |
| AC310-T6-900G/1000P-LD | | | | | | | | | |
| AC310-T6-1000G/1120P-LD | | | | | | | | | |
| AC310-T6-1120G-LD | | | | | | | | | |


Installation space requirements



a. Unlimited left and right space
(no communication expansion board)




b. Parallel installation space $A \geq 50\text{mm}$ (with communication expansion board).



Top/Bottom space

Standard wiring



Note:

1. Models T3-22kW and below have built-in braking units, which need to be connected with braking resistors as required; For models without built-in brake units, external brake unit can be installed as required.
2. Terminals (X1~X5/PUL) can support NPN or PNP transistor signals as inputs, and the bias voltage can be selected from the internal power supply of AC drive (+24V terminal) or external power supply (PLC terminal).

• **Auxiliary terminal output capacity**

| Terminal | Definition | Max. output |
|----------|--|--|
| +10V | 10V auxiliary power output, forming a circuit with GND | 50mA |
| AO | Analog monitoring output, forming a circuit with GND | Max. output of 2mA for voltage signals |
| +24V | 24V auxiliary power output, forming a circuit with COM | 100mA |
| Y | Open collector output, action object can be set in the software | DC24V/50mA |
| TA/TB/TC | Passive contact output, action object can be set in the software | 3A/240VAC 5A/30VDC |

• **Switch function legend and description**


| Tag | Position | Description |
|---|----------------------------|--|
| RS485 OFF <input type="checkbox"/> Oi AO-F OFF <input type="checkbox"/> Oi AO-I OFF <input type="checkbox"/> Oi AO-U OFF <input type="checkbox"/> Oi AI1 U <input type="checkbox"/> I AI2 U <input type="checkbox"/> I | 485 terminating resistance | RS485 dialed to ON, and then communication circuit is connected to a 120Ω terminating resistor |
| | AO-Frequency | 0.0kHz~100.0kHz frequency output from AO interface AO-F dialed to ON, and voltage needs to be increased by adding external appliances (typically connected to a 5.1kΩ resistor) |
| | AO-Current | AO-I to ON to output current of 0mA~20mA or 4mA~20mA |
| | AO-Voltage | AO-U to ON to output voltage of 0V~10V |
| | AI1-Current/Voltage | AI1 dialed to I: To input current of 0mA~20mA; AI1 dialed to U: To input voltage of 0V~10V |
| | AI2-Current/Voltage | AI2 dialed to I: To input current of 0mA~20mA; AI2 dialed to U: To input voltage of 0V~10V |

Chapter 3 Panel Layout and Operation Instructions

• Panel name

Integrated panel(models 37kW and below)


Dual-line panel(models 37kW and above)



| Mark | Single-line panel | Dual-line panel | Function |
|------|-------------------|-----------------|--|
| A | Unit indicator | | Hz: Frequency; A: Current; V: Voltage; V/A: voltage or current; RPM: Speed; %: Percentage |
| B | Status indicator | | ON: Forward; Flash: Reverse; OFF: Stop |
| C | Program | Program | Enter the function menu under standby or operation status; Press it to exit during parameter modification; Long press it (1 second) under standby or operation to enter the status interface |
| D | Set/Shift | - | Set: Press the key to confirm the modification. Shift: Long press the key (1 second) to shift among the operation bit, and to shift circularly by holding on it. |
| E | UP, DOWN | - | UP key increases the value, and DOWN key decreases the value |
| F | | | When Run/Stop is controlled by the panel, press this key to make the AC drive operate in forward direction. The status indicator is on for forward operation and flashing for reverse operation. |
| | Stop/Reset | Stop, Reset | When the commands are given from the panel, press this key to stop the AC drive; Define other command giving methods to be valid or not by parameter F11.03 [Panel STOP]; Press this key to reset AC drive in fault. |
| G | - | | Potentiometer: Rotate clockwise to increase the value, and counterclockwise to decrease it. |
| | | Left, Right | Confirm: After modification, press it to confirm. Shift the bit to the left and right. |
| H | - | Function keys | The functions of the key are selected via parameter F11.02 [Panel Function Key]. |


• Set the basic parameters

Take F01.22 [Acceleration Time]= 10.00s as an example.



Note: To modify the tens-, hundreds- and thousands-bit of a parameter, press Shift for quick positioning.


• Check the monitoring status



Note: Press Left to cycle through the first row of monitoring parameters and Right to cycle through the second row when it is an external panel.

• Check the monitoring parameters

Take the C02.05 [PLC Operation Stage] as an example.



Chapter 4 Parameter List

This section only provides a brief list of functions. Please refer to the AC310 Technical Manual or consult our company for detailed information.

4.1 Terms and Marks

◆ Marks and terms of control modes

| Mark | Content |
|-------|---|
| V/F | Valid parameters under V/F control for asynchronous motors(AM) |
| SVC | Valid parameters under open-loop vector control for asynchronous motors(AM) |
| FVC | Valid parameters under closed-loop vector control for asynchronous motors(AM) |
| PMVF | Valid parameters under V/F control for permanent magnet synchronous motors(PM) |
| PMSVC | Valid parameters under open-loop vector control for permanent magnet synchronous motors(PM) |
| PMFVC | Valid parameters under closed-loop vector control for permanent magnet synchronous motors(PM) |

Note: The unshaded marks mean that the parameter is invalid under certain control modes.

◆ Marks and terms of control modes

| Mark | Content |
|------|--|
| RUN | Parameters that can be modified during operation |
| STOP | Parameters that cannot be modified during operation |
| READ | The parameter can only be read, not modified (the LED displays five "-" during modification) |

4.2 Parameter List

◆ Code types for this product

| Code | Name | Code | Name |
|----------------|--|---------------|--|
| F00.0x | Environment settings | F07.0x | Start control |
| F00.1x | Common parameters | F07.1x | Stop control |
| F01.0x | Basic commands | F07.2x | DC brake and speed tracking |
| F01.1x | Frequency commands | F07.3x | Jog |
| F01.2x | ACC./DEC. time | F07.4x | Start/Stop frequency holding and jump |
| F01.4x | PWM control | F08.0x | Counting and timing |
| F02.0x | Basic motor parameters and auto-tuning | F08.3x | Swing Frequency |
| F02.1x | Advanced parameters for AM | F09.0x | Maintenance function |
| F02.2x | Advanced parameters for PM | F10.0x | Current protection |
| F02.3x- F02.4x | Encoder parameters | F10.1x | Voltage protection |
| F02.5x | Motor application parameters | F10.2x | Subsidiary protection |
| F03.0x | Velocity loop | F10.3x | Load protection |
| F03.1x | Current loop and torque limit | F10.4x | Stall protection |
| F03.2x | Torque optimization | F10.5x | Fault recovery and motor overload protection |
| F03.3x | Flux optimization | F11.0x | Key operation |
| F03.4x- F03.5x | Torque control | F11.1x | Cyclic monitoring of status interface |
| F03.6x | PM high-frequency injection | F11.2x | Monitoring parameters |
| F03.7x | Position compensation | F11.3x | Special panel functions |
| F03.8x | Expansions | F12.0x | Modbus slave parameters |
| F04.0x | V/F control | F12.1x | Modbus master parameters |
| F04.1x | Customized V/F curves | F12.2x | Special Modbus functions |
| F04.2x | V/F separation | F12.3x | PROFIBUS-DP parameters |
| F04.3x | V/F ECO control | F12.4x | CANopen parameters |
| F05.0x | Digit input terminal | F12.5x~F12.6x | EX_A, EX_B expansion communication |
| F05.1x | X1-X5 detection delay | F13.00~F13.06 | PID setting and feedback |
| F05.2x | Digit input terminal mode | F13.07~F13.24 | PID setting |

| | | | |
|---------------|--------------------------|---------------|------------------------------------|
| F05.3x | PUL terminal | F13.25~F13.28 | PID feedback disconnection |
| F05.4x | AI type processing | F13.29~F13.33 | Sleep |
| F05.5x | AI linear processing | F14.00~F14.14 | Multi-segment speed frequency |
| F05.6x | AI Curve 1 processing | F14.15 | PLC mode |
| F05.7x | AI Curve 2 processing | F14.16~F14.30 | PLC runtime |
| F05.8x | AI as DI terminal | F14.31~F14.45 | PLC direction and ACC/DEC time |
| F06.0x | Analog output | F16.0x | Tension control |
| F06.1x | AO expansion | C00.xx | Basic monitoring |
| F06.2x~F06.3x | Digital and relay output | C01.xx | Fault monitoring |
| F06.4x | Frequency detection | C02.xx | App monitoring |
| F06.5x | Monitoring comparator | C03.xx | Maintenance and tension monitoring |
| F06.6x~F06.7x | Virtual I/O terminals | - | - |

4.3 F00: Environmental Parameters

F00.0x: Environment Settings

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|------------------------|---|-----------------|----------|
| F00.00 (0x0000) | Parameter Access Level | V/F SVC FVC PMVF PMSVC PMFVC Set the parameter access level according to access restriction. 0: Standard parameters (Fxx.yyy, Cxx.yyy); 1: Common parameters (F00.00, Pxx.yyy); 2: Monitoring parameters (F00.00, Cxx.yyy); 3: Modified parameters (F00.00, Hxx.yy) | 0 (0~3) | RUN |
| F00.01 (0x0001) | Purpose | V/F SVC FVC PMVF PMSVC PMFVC AC drives can be set for the specific purpose. 0: General; 1: Fan, pump | 0 (0~1) | STOP |
| F00.03 (0x0003) | Initialization | V/F SVC FVC PMVF PMSVC PMFVC Set the initialization mode for the drive. 0: Initialization OFF; 11: Set parameters according to actual needs (motor parameters excl.); 22: All parameters initialized; 33: Clear fault records | 0 (0~33) | STOP |
| F00.04 (0x0004) | Panel Parameter Copy | V/F SVC FVC PMVF PMSVC PMFVC 0: None; 11: Upload parameters to the panel; 22: Download parameters to the drive | 0 (0~30) | STOP |
| F00.05 (0x0005) | Reserved | - | Reserved | Reserved |
| F00.06 (0x0006) | Reserved | - | Reserved | Reserved |
| F00.07 (0x0007) | Free Parameter 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the machine codes or purpose codes when multiple | 0 (0~65535) | RUN |
| F00.08 (0x0008) | Free Parameter 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the machine codes or purpose codes when multiple | 0 (0~65535) | RUN |

F00.1x~F00.3x: Common Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|----------------------------------|--------------------------|--|-----------------------------|----------|
| F00.10~F00.39 (0x000A~0x0027) | Common Parameter Address | V/F SVC FVC PMVF PMSVC PMFVC Ones-and tens-bit: Set 00 ~ 99 to yy in Fxx.yy. Hundreds- and thousands-bit: Set 00 ~ 31 to xx in Fxx.yy. | Up to F00.01 (0000~2999) | RUN |

4.4 F01: Basic Settings**F01.0x: Basic Commands**

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------|---|-------------------------|----------|
| F01.00 (0x0100) | Motor 1 Control Mode | V/F SVC FVC PMVF PMSVC PMFVC Se the control mode for Motor 1. AM control modes: 0: AM-V/F: V/F control; 1: AM-SVC: Open loop vector control, current closed loop control; 2: AM-FVC: Close-loop vector control PM control modes: 10: PM-V/F: V/F control; 11: PM-SVC: Open-loop vector control; 12: PM-FVC: Close-loop vector control POWER: 20: V/F-SPLIT: Voltage-frequency conversion Note: The V/F separation function only supports for T3 motors(7.5kW and above), and T2 motors(5.5kW and above). | 0 (0~20) | STOP |
| F01.01 (0x0101) | Command Source | V/F SVC FVC PMVF PMSVC PMFVC Select the method to send run/stop commands and the direction of operation to the drive. 0: Panel (external panel first); 1: Terminal; 2: RS485; 3: Optional boards | 0 (0~3) | RUN |
| F01.02 (0x0102) | Frequency Source A | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency giving source A. 0: Via panel keys; 1: Via panel potentiometer; 2: Via analog current/voltage AI1; 3: Via analog current/voltage AI2; 4: Reserved 5: Via PUL terminal; 6: Via RS485; 7: Via UP/DW terminal; 8: Via PID control; 9: Via PLC; 10: Via optional boards; 11: Via multi-segment speed; 12: Via special RS485 setting | 0 (0~12) | RUN |
| F01.03 (0x0103) | Frequency Source A Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the gain of frequency giving source A. | 100.0% (0.0%~500.0%) | STOP |
| F01.04 (0x0104) | Frequency Source B | V/F SVC FVC PMVF PMSVC PMFVC Set frequency giving source B, the same as F01.02. | 2 (0~11) | RUN |
| F01.05 (0x0105) | Frequency Source B Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the gain of frequency giving source B. | 100.0% (0.0%~500.0%) | STOP |
| F01.06 (0x0106) | Source B Reference | V/F SVC FVC PMVF PMSVC PMFVC Set the reference for frequency giving source B by this parameter. 0: Max. output frequency as reference 1: Frequency set by source A as reference | 0 (0~1) | RUN |

| | | | | |
|--------------------|----------------------------------|---|---|-----|
| F01.07 (0x0107) | Frequency Source Combination | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Select the combination method of source A and source B of the drive.</p> <p>0: Source A; 1: Source B; 2: Source A + Source B; 3: Source A - Source B; 4: Max (A, B); 5: Min (A, B)</p> | 0 (0-5) | RUN |
| F01.08 (0x0108) | Frequency/Command Source Binding | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Bind the frequency source to each command source when this parameter is valid.</p> <p>Ones-bit: Bind panel commands; Tens-bit: Bind terminal commands; Hundreds-bit: Bind communication commands; Thousands-bit: Bind optional board commands</p> <p>0: None 1: Via panel keys; 2: Via panel potentiometer; 3: Via analog current/voltage AI1; 4: Via analog current/voltage AI2; 5: Reserved; 6: Via PUL terminal; 7: Via RS485; 8: Via UP/DW terminal; 9: Via PID control; A: Via PLC; B: Via optional boards; C: Via multi-segment speed; D: Reserved</p> | 0000 (0000-DDDD) | RUN |
| F01.09 (0x0109) | Panel Giving Frequency | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set and modify the frequency via the panel.</p> | 50.00Hz (0.00Hz~Upper limit frequency) | RUN |

F01.1x: Frequency Commands

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------------|--|--|----------|
| F01.10 (0x010A) | Max. Frequency | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the maximum frequency for the drive.</p> | 50.00Hz (1.00Hz~500.00Hz) | STOP |
| F01.11 (0x010B) | Upper Limit Frequency Source | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the upper limit frequency source.</p> <p>0: Via panel keys; 1: Via potentiometer; 2: Via analog current/voltage AI1; 3: Via analog current/voltage AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485; 7: Via optional boards;</p> | 0 (0-7) | RUN |
| F01.12 (0x010C) | Panel Giving Upper Limit Frequency | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>The upper limit frequency is given from the panel when F01.11 is set to 0.</p> | 50.00Hz (Lower limit~Max. frequency) | RUN |
| F01.13 (0x010D) | Lower Limit Frequency | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the lower limit frequency.</p> | 0.00Hz (0.00Hz~Upper limit frequency) | RUN |
| F01.14 (0x010E) | Frequency Command Resolution | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the frequency command resolution</p> <p>0: 0.01Hz 1: 0.1Hz 2: 0.1rpm 3: 1rpm 4: 10rpm</p> | 0 (0-4) | STOP |

F01.2x~F01.3x: Acceleration/Deceleration Time

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|--|---|--------------------------------|----------|
| F01.20 (0x0114) | ACC/DEC Time Reference | V/F SVC FVC PMVF PMSVC PMFVC Set the reference frequency to calculate the acceleration/deceleration time. 0: Max. frequency; 1: Fixed frequency at 50Hz; 2: Set frequency | 0 (0~2) | STOP |
| F01.21 (0x0115) | ACC/DEC Time Unit | V/F SVC FVC PMVF PMSVC PMFVC Set the unit for the acceleration and deceleration time. 0: 1s; 1: 0.1s; 2: 0.01s | 2 (0~2) | STOP |
| F01.22 (0x0116) | ACC Time 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to accelerate the output frequency from 0.00Hz to the reference frequency. 1s~65000s(F01.21=0); 0.1s~6500.0s(F01.21=1); 0.01s~650.00s(F01.21=2) | Up to model (0.01s~650.00s) | RUN |
| F01.23 (0x0117) | DEC Time 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to decelerate the output frequency from the reference frequency to 0.00Hz. | Up to model (0.01s~650.00s) | RUN |
| F01.24 (0x0118) | ACC Time 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to accelerate the output frequency from 0.00Hz to the reference frequency. | Up to model (0.01s~650.00s) | RUN |
| F01.25 (0x0119) | DEC Time 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to decelerate the output frequency from the reference frequency to 0.00Hz. | Up to model (0.01s~650.00s) | RUN |
| F01.26 (0x011A) | ACC Time 3 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to accelerate the output frequency from 0.00Hz to the reference frequency. | Up to model (0.01s~650.00s) | RUN |
| F01.27 (0x011B) | DEC Time 3 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to decelerate the output frequency from the reference frequency to 0.00Hz. | Up to model (0.01s~650.00s) | RUN |
| F01.28 (0x011C) | ACC Time 4 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to accelerate the output frequency from 0.00Hz to the reference frequency. | Up to model (0.01s~650.00s) | RUN |
| F01.29 (0x011D) | DEC Time 4 | V/F SVC FVC PMVF PMSVC PMFVC Set the time required to decelerate the output frequency from the reference frequency to 0.00Hz. | Up to model (0.01s~650.00s) | RUN |
| F01.30 (0x011E) | S-Curve ACC/DEC | V/F SVC FVC PMVF PMSVC PMFVC Set S-curve acceleration/deceleration valid or not. 0: Invalid; 1: Valid; 2: Smoother S-curve | 1 (0~2) | STOP |
| F01.31 (0x011F) | ACC S-Curve Start Time | V/F SVC FVC PMVF PMSVC PMFVC Set the S-curve acceleration start time. | 0.20s (0.00s~10.00s) | STOP |
| F01.32 (0x0120) | ACC S-Curve End Time | V/F SVC FVC PMVF PMSVC PMFVC Set the S-curve acceleration stop time. | 0.20s (0.00s~10.00s) | STOP |
| F01.33 (0x0121) | DEC S-Curve Start Time | V/F SVC FVC PMVF PMSVC PMFVC Set the S-curve deceleration start time. | 0.20s (0.00s~10.00s) | STOP |
| F01.34 (0x0122) | DEC S-Curve End Time | V/F SVC FVC PMVF PMSVC PMFVC Set the S-curve deceleration stop time. | 0.20s (0.00s~10.00s) | STOP |
| F01.35 (0x0123) | Switching Frequency of Acceleration Time 1/2 | V/F SVC FVC PMVF PMSVC PMFVC Set the switching frequency of ACC. time 1 and ACC. time 2. | 0.00Hz (0.00Hz~Max. frequency) | RUN |

F01.4x: PWM

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------|---|---------------------------------|----------|
| F01.40 (0x0128) | Carrier Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the switch frequency of IGBT drive | Up to model (1.0kHz~16.0kHz) | RUN |
| F01.41 (0x0129) | PWM Control Mode | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Carrier-temperature relationship 0: Irrelevant; 1: Relevant Tens-bit: Carrier-output frequency relationship 0: Irrelevant; 1: Relevant Hundreds-bit: Random PWM 0: Invalid 1: Valid in V/F control mode 2: Valid in vector control Thousands-bit: PWM mode 0: Three-phase only; 1: Automatic switch between two-phase and three-phase | 1111 (0000~1211) | RUN |
| F01.43 (0x012B) | Deadband Compensation Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the deadband compensation gain. | 306 (0~512) | RUN |
| F01.46 (0x012E) | Random PWM Depth | V/F SVC FVC PMVF PMSVC PMFVC The higher the set point, the greater the carrier fluctuation when random PWM is enabled. | 0 (0~20) | RUN |

4.5 F02: Motor 1 Parameters**F02.0x: Basic Motor Parameters and Auto-Tuning**

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------|--|--|----------|
| F02.00 (0x0200) | Type | V/F SVC FVC PMVF PMSVC PMFVC Set the motor type. 0: Asynchronous motor (AM) 1: Permanent magnet synchronous motor (PM) | 0 (0~1) | READ |
| F02.01 (0x0201) | Pole No. | V/F SVC FVC PMVF PMSVC PMFVC Set the motor pole number. | 4 (2~98) | STOP |
| F02.02 (0x0202) | Rated Power | V/F SVC FVC PMVF PMSVC PMFVC Set the rated power of the motor. | Up to model (0.1kW~1000.0kW) | STOP |
| F02.03 (0x0203) | Rated Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the rated frequency of the motor. | Up to model (0.01Hz~Max. frequency) | STOP |
| F02.04 (0x0204) | Rated Speed | V/F SVC FVC PMVF PMSVC PMFVC Set the rated speed of the motor. | Up to model (0rpm~65000rpm) | STOP |
| F02.05 (0x0205) | Rated Voltage | V/F SVC FVC PMVF PMSVC PMFVC Set the rated voltage of the motor. | Up to model (0V~2000V) | STOP |
| F02.06 (0x0206) | Rated Current | V/F SVC FVC PMVF PMSVC PMFVC Set the rated current of the motor. | Up to model (0.1A~3000.0A) | STOP |
| F02.07 (0x0207) | Auto-Tuning | V/F SVC FVC PMVF PMSVC PMFVC After the auto-tuning is finished, F02.07 will be set to "0" automatically. 0: None 1: Dynamic auto-tuning; 2: Static auto-tuning; 3: Stator resistance auto-tuning; 4~20: Reserved | 0 (0~20) | STOP |

Note: When F02.00 [Type] is set to a synchronous motor, F2.04 [Rated Speed] is calculated from F2.01 [Pole No.] and F2.03 [Rated Frequency], please set the corresponding parameters correctly. The calculation formula is: $F2.04[\text{Rated Speed}] = 60 * F2.03[\text{Rated Frequency}] / (F2.01[\text{Pole No.}] / 2)$

F02.1x: AM Advanced Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|------------------------------------|---|-----------------------------------|----------|
| F02.10 (0x020A) | No-Load Current | V/F SVC FVC PMVF PMSVC PMFVC Set the no-load current of the asynchronous motor. | Up to model (0.1A~3000.0A) | STOP |
| F02.11 (0x020B) | Stator Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the stator resistance of the asynchronous motor. | Up to model (0.01mΩ~60000mΩ) | STOP |
| F02.12 (0x020C) | Rotor Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the rotor resistance of the asynchronous motor. | Up to model (0.01mΩ~60000mΩ) | STOP |
| F02.13 (0x020D) | Stator Leakage Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the stator leakage inductance of the asynchronous motor. | Up to model (0.001mH~6553.5mH) | STOP |
| F02.14 (0x020E) | Stator Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the stator inductance of the asynchronous motor. | Up to model (0.01mH~65535mH) | STOP |
| F02.15 (0x020F) | Per-Unit Stator Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of the stator resistance for the asynchronous motor. | Up to model (0.01%~50.00%) | READ |
| F02.16 (0x0210) | Per-Unit Rotor Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of the rotor resistance for the asynchronous motor. | Up to model (0.01%~50.00%) | READ |
| F02.17 (0x0211) | Per-Unit Stator Leakage Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of the stator leakage inductance for the asynchronous motor. | Up to model (0.01%~50.00%) | READ |
| F02.18 (0x0212) | Per-Unit Stator Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of the stator inductance. | Up to model (0.1%~999.0%) | READ |
| F02.19 (0x0213) | F02.11~F02.14 Decimal Point | V/F SVC FVC PMVF PMSVC PMFVC Set the decimal point of the four parameters from F02.11 to F02.14. | 0x0000 (0x0000~0x2222) | STOP |

F02.2x: PM Advanced Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|----------------------------|---|-----------------------------------|----------|
| F02.20 (0x0214) | Per-unit Stator Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of stator resistance for the permanent magnet synchronous motor. | Up to model (0.01mΩ~60000mΩ) | STOP |
| F02.21 (0x0215) | Per-unit D-Axis Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of d-axis inductance for the permanent magnet synchronous motor. | Up to model (0.001mH~6553.5mH) | STOP |
| F02.22 (0x0216) | Per-unit Q-Axis Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value q-axis inductance for the permanent magnet synchronous motor. | Up to model (0.001mH~6553.5mH) | STOP |
| F02.23 (0x0217) | Back Emf | V/F SVC FVC PMVF PMSVC PMFVC Set the back emf of the permanent magnet synchronous motor. It can only be identified under rotary auto-tuning. | Up to model (0V~1500V) | STOP |
| F02.24 (0x0218) | Encoder Installation Angle | V/F SVC FVC PMVF PMSVC PMFVC Set the encoder installation angle of the permanent magnet synchronous motor. | Up to model (0.0°~360.0°) | RUN |

| | | | | |
|--------------------|--------------------------------|---|-----------------------------------|------|
| F02.25 (0x0219) | Per-unit Stator Resistance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of stator resistance for the permanent magnet synchronous motor. | Up to model (Monitored values) | READ |
| F02.26 (0x021A) | Per-unit D-Axis Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of d-axis inductance for the permanent magnet synchronous motor. | Up to model (Monitored values) | READ |
| F02.27 (0x021B) | Per-unit Q-Axis Inductance | V/F SVC FVC PMVF PMSVC PMFVC Set the per-unit value of q-axis inductance for the permanent magnet synchronous motor. | Up to model (Monitored values) | READ |
| F02.28 (0x021C) | Pulse Width Factor | V/F SVC FVC PMVF PMSVC PMFVC Set the pulse width coefficient of the permanent magnet synchronous motor. | Up to model (00.00~99.99) | STOP |
| F02.29 (0x021D) | F02.20~F02.22 Decimal Point | V/F SVC FVC PMVF PMSVC PMFVC Set the decimal point of the three parameters from F02.20to F02.22. | 0x0000 (0x0000~0x2222) | STOP |

F02.3x~F02.4x: Encoder Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------------|--|----------------------------|----------|
| F02.30 (0x021E) | Encoder Type | V/F SVC FVC PMVF PMSVC PMFVC 0: Common ABZ encoder(to expansion port EX_B) 1: Resolver(to expansion port EX_B) | 0 (0~1) | STOP |
| F02.31 (0x021F) | Encoder Direction | V/F SVC FVC PMVF PMSVC PMFVC 0: Same direction 1: Opposite direction | 0 (0~1) | STOP |
| F02.32 (0x0220) | Z-pulse Detection from ABZ Encoder | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: ON(forward detection); 2: ON(reverse detection) | 1 (0~2) | STOP |
| F02.33 (0x0221) | ABZ Encoder Line No. | V/F SVC FVC PMVF PMSVC PMFVC Set the line number of the ABZ encoder. | 1024 (1~10000) | STOP |
| F02.34 (0x0222) | Resolver Pole No. | V/F SVC FVC PMVF PMSVC PMFVC Set the pole number of the rotary transformer. | 2 (2~128) | STOP |
| F02.35 (0x0223) | Transmission Ratio Numerator | V/F SVC FVC PMVF PMSVC PMFVC Set the transmission ratio numerator of the encoder. | 1 (1~32767) | RUN |
| F02.36 (0x0224) | Transmission Ratio Denominator | V/F SVC FVC PMVF PMSVC PMFVC Set the transmission ratio denominator of the encoder. | 1 (1~32767) | RUN |
| F02.37 (0x0225) | Speed Detection Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the speed detection filter time of the encoder. | 1.0ms (0.0ms~100.0ms) | RUN |
| F02.38 (0x0226) | Disconnection Detection Time | V/F SVC FVC PMVF PMSVC PMFVC Set the disconnection detection time of the encoder. | 0.050s (0.010s~60.000s) | RUN |
| F02.47 (0x022F) | Z-Pulse Tolerance | V/F SVC FVC PMVF PMSVC PMFVC Set the Z pulse allowable tolerance. | 0 (0~65535) | RUN |
| F02.48 (0x0230) | Z-pulse Tuning Current | V/F SVC FVC PMVF PMSVC PMFVC Set the value of Z-pulse tuning current. | 0 (0~65535) | RUN |
| F02.49 (0x0231) | Debug Register | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Monitor PG under SVC 0: Invalid; 1: Valid | 0x0000 (0x0000~0xFFFFF) | RUN |

F02.5x~F02.6x: Motor Application Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|---|--|------------------------|----------|
| F02.50 (0x0232) | Stator Resistance Auto-tuning | V/F SVC FVC PMVF PMSVC PMFVC 0: Invalid; 1: Tune only without update; >1: Tune and update | 0 (0~3) | STOP |
| F02.51 (0x0233) | Stator Resistance Tuning Factor 1 | V/F SVC FVC PMVF PMSVC PMFVC Stator Resistance Tuning Factor 1 | 0 (0~1000) | RUN |
| F02.52 (0x0234) | Stator Resistance Tuning Factor 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the stator resistance tuning factor 2 | 0 (-20.00%~20.00%) | RUN |
| F02.53 (0x0235) | Set the stator resistance tuning factor 3 | V/F SVC FVC PMVF PMSVC PMFVC Set the stator resistance tuning factor 3 | 0 (0~65535) | RUN |
| F02.60 (0x023C) | PM Pole Search | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: SVC 0: OFF; 1: ON; 2: ON, but only at the first startup Tens-bit: FVC 0: OFF; 1: ON; 2: ON, but only at the first startup Hundreds-bit: V/F 0: OFF; 1: ON; 2: ON, but only at the first startup | 0010 (0000~3223) | STOP |
| F02.61 (0x023D) | Pole Search Current | V/F SVC FVC PMVF PMSVC PMFVC Set the value of pole search current. | 0.0% (0.0%~6553.5%) | STOP |

4.6 F03: Vector Control**F03.0x: ASR (Automatic Speed Regulator)**

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|------------------------|--|---------------------------------------|----------|
| F03.00 (0x0300) | Rigidity Class | V/F SVC FVC PMVF PMSVC PMFVC Set the rigidity class of the speed loop. The higher the class, the better the speed rigidity. | 32 (0~128) | RUN |
| F03.01 (0x0301) | Rigidity Mode | V/F SVC FVC PMVF PMSVC PMFVC Set the rigidity mode of the speed loop. | 0x0000 (0x0000~0xFFFF) | RUN |
| F03.02 (0x0302) | HF Proportional Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the proportional gain for high-frequency operation of the speed loop. | 10.00 (0.01~100.00) | RUN |
| F03.03 (0x0303) | HF Integral Time | V/F SVC FVC PMVF PMSVC PMFVC Set the integral time for high-frequency operation of the speed loop. | 0.100s (0.000s~6.000s) | RUN |
| F03.04 (0x0304) | HF Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the filter time for high-speed operation of the speed loop. | 0.0ms (0.0ms~100.0ms) | RUN |
| F03.05 (0x0305) | HF Switching Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the switching frequency for high-frequency operation of the speed loop. | 0.00Hz (0.00Hz~ Max. frequency) | RUN |
| F03.06 (0x0306) | LF Proportional Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the proportional gain for low-frequency operation of the speed loop. | 10.00 (0.01~100.00) | RUN |
| F03.07 (0x0307) | LF Integral Time | V/F SVC FVC PMVF PMSVC PMFVC Set the integral time for low-speed operation of the speed loop. | 0.100s (0.000s~6.000s) | RUN |

| | | | | |
|--------------------|------------------------|--|---------------------------|-----|
| F03.08 (0x0308) | LF Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the filter time for low-frequency operation of the speed loop. | 0.0ms (0.0ms~100.0ms) | RUN |
| F03.09 (0x0309) | LF Switching Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the switching frequency for low-frequency operation of the speed loop. | 0.00Hz (0.00Hz~F03.05) | RUN |

F03.1x: ACR and Torque Limit

| Code (Address) | Name | Content | Default (Range) | Property |
|---------------------------|------------------------------|--|----------------------------|----------|
| F03.10 (0x030A) | D-Axis Proportional Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the d-axis proportional gain for the current loop. | 1.000 (0.001~4.000) | RUN |
| F03.11 (0x030B) RUN | D-Axis Integral Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the d-axis proportional gain of the current loop. | 1.000 (0.001~4.000) | RUN |
| F03.12 (0x030C) | Q-Axis Proportional Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the current loop q-axis proportional gain | 1.000 (0.001~4.000) | RUN |
| F03.13 (0x030D) | Q-Axis Integral Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the q-axis integral gain of the current loop. | 1.000 (0.001~4.000) | RUN |
| F03.15 (0x030F) | Motoring Torque Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the torque limit during normal motor driving. | 250.0% (0.0%~400.0%) | RUN |
| F03.16 (0x0310) | Generating Torque Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the torque limit during power generation. | 250.0% (0.0%~400.0%) | RUN |
| F03.17 (0x0311) | LS Regenerative Torque Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the regenerative torque limit at low speed. | 0.0% (0.0%~400.0%) | RUN |
| F03.18 (0x0312) | LS Frequency Limit by Torque | V/F SVC FVC PMVF PMSVC PMFVC Set the operation frequency limited by torque at low speed. | 6.00Hz (0.00Hz~30.00Hz) | RUN |
| F03.19 (0x0313) | Torque Limit | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Torque limit source during motoring 0: Via panel keys; 1: Via panel potentiometer(on optional external single-row panels); 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485(0x3014); 7: Via optional boards Tens-bit: Torque limit source during generating 0: Via panel keys; 1: Via panel potentiometer(on optional external single-row panels); 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485(0x3015); 7: Via optional boards Hundreds-bit: C00.06 display 0: Display the torque limit under motor mode 1: Display the torque limit under power generation mode Thousands-bit: Reserved | 0x0000 (0x0000~0x0177) | RUN |

F03.2x: Torque Optimization

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------------|--|-------------------------|----------|
| F03.20 (0x0314) | PM LF Injection Current | V/F SVC FVC PMVF PMSVC PMFVC When the SVC mode of the PM is on, the larger the injection current, the larger the torque output. | 20.0% (0.0%~50.0%) | RUN |
| F03.21 (0x0315) | PM HF Injection Current | V/F SVC FVC PMVF PMSVC PMFVC When the SVC mode of the PM is on, the larger the injection current, the larger the torque output. | 10.0% (0.0%~50.0%) | RUN |
| F03.22 (0x0316) | PM Injection Current Frequency | V/F SVC FVC PMVF PMSVC PMFVC The set value 100.0% corresponds to F01.10 [Max. Frequency] | 10.0% (0.0%~100.0%) | RUN |
| F03.23 (0x0317) | Vector Slip Compensation | V/F SVC FVC PMVF PMSVC PMFVC Set the slip compensation under AM vector control. | 100.0% (0.0%~250.0%) | RUN |
| F03.24 (0x0318) | Initial value of starting torque | V/F SVC FVC PMVF PMSVC PMFVC Set the initial value of the starting torque | 0.0% (0.0%~250.0%) | RUN |

F03.3x: Magnetic Flux Optimization

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--|--|---------------------------|----------|
| F03.30 (0x031E) | Field-Weakening Feed-Forward Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Set the feedforward coefficient under field weakening control. | 10.0% (0.0%~500.0%) | RUN |
| F03.31 (0x031F) | Field-Weakening Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the field-weakening control gain. | 10.0% (0.0%~500.0%) | RUN |
| F03.32 (0x0320) | Field-Weakening Current Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the field-weakening current upper limit. | 60.0% (0.0%~250.0%) | RUN |
| F03.33 (0x0321) | Field-Weakening Voltage Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Set the field-weakening voltage coefficient. | 97.0% (0.0%~120.0%) | RUN |
| F03.34 (0x0322) | Axis Output Power Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the axis output power limit. | 250.0% (0.0%~400.0%) | RUN |
| F03.35 (0x0323) | Overexcitation Brake Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the over-excitation brake gain. | 100.0% (0.0%~500.0%) | RUN |
| F03.36 (0x0324) | Overexcitation Brake Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the over-excitation brake limit. | 100.0% (0.0%~250.0%) | RUN |
| F03.37 (0x0325) | ECO Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: ON | 0 (0~1) | RUN |
| F03.38 (0x0326) | Excitation Lower Limit in ECO Mode | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit of excitation during auto energy-saving operation. | 50.0% (0.0%~80.0%) | RUN |
| F03.39 (0x0327) | Filter Coefficient in ECO Mode | V/F SVC FVC PMVF PMSVC PMFVC Set the filter coefficient during auto energy-saving operation. | 0.010s (0.000s~6.000s) | RUN |

F03.4x~F03.5x: Torque Control

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|---|-------------------------------|----------|
| F03.40 (0x0328) | Torque Control | V/F SVC FVC PMVF PMSVC PMFVC 0: Torque limit under speed control; 1: speed limit under torque control | 0 (0~1) | RUN |
| F03.41 (0x0329) | Torque Command | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Source A; Tens-bit: Source B 0: Via panel keys; 1: Via panel potentiometer (on optional external single-row panels); 2: Via analog current/voltage AI1; 3: Via analog current/voltage AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485; 7: Via optional boards; 8: Reserved; 9: Via tension calculation; Hundreds-bit: Command source 0: Source A; 1: Source B; 2: Source A + Source B; 3: Source A - Source B; 4: Min(A, B) 5: Max(A, B); | 0000 (0000~0599) | RUN |
| F03.42 (0x032A) | Panel Giving Torque | V/F SVC FVC PMVF PMSVC PMFVC Set to give the torque command via panel keys. | 0.0% (0.0%~100.0%) | RUN |
| F03.43 (0x032B) | Torque Input Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the torque input lower limit. | 0.00% (0.00%~100.00%) | RUN |
| F03.44 (0x032C) | Torque Lower Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the corresponding percentage to the torque lower limit. | 0.00% (-250.00%~300.00%) | RUN |
| F03.45 (0x032D) | Torque Input Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the torque input upper limit. | 100.00% (0.00%~100.00%) | RUN |
| F03.46 (0x032E) | Torque Upper Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the corresponding percentage to the torque upper limit | 100.00% (-250.00%~300.00%) | RUN |
| F03.47 (0x032F) | Torque Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the operation frequency limited by torque at low speed. | 0.100s (0.000s~6.000s) | RUN |
| F03.49 (0x0331) | Torque ACC Time | V/F SVC FVC PMVF PMSVC PMFVC Set the acceleration time when the given torque increases, with a reference of 100%. This parameter is only valid during torque control, and invalid during stop. | 0.00s (0.00s~650.00s) | RUN |
| F03.50 (0x0332) | Torque DEC Time | V/F SVC FVC PMVF PMSVC PMFVC Set the deceleration time when the given torque decreases, with a reference of 100%. This parameter is only valid during torque control, and invalid during stop. | 0.00s (0.00s~650.00s) | RUN |

| | | | | |
|--------------------|---|--|------------------------------------|-----|
| F03.52 (0x0334) | Torque Upper Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC Set the output torque upper limit in torque control. | 150.0% (0.0%~300.0%) | RUN |
| F03.53 (0x0335) | Torque Lower Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC Set the output torque lower limit in torque control. | 0.0% (0.0%~300.0%) | RUN |
| F03.54 (0x0336) | FWD Speed Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC 0: F03.56; 1: Panel potentiometer (optional with external single-row panels) × F03.56 2: AI1 × F03.56 3: AI2 × F03.56 4: Reserved; 5: PUL × F03.56 6: RS485 × F03.56 7: Optional board × F03.56 8: Reserved; | 0 (0~8) | RUN |
| F03.55 (0x0337) | REV Speed Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC 0: F03.57 1: Panel potentiometer (optional with external single-row panels) × F03.57 2: AI1 × F03.57 3: AI2 × F03.57 4: Reserved; 5: PUL × F03.57 6: RS485 × F03.57 7: Optional board × F03.57 8: Reserved | 0 (0~8) | RUN |
| F03.56 (0x0338) | Max. FWD Speed Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC Set the max. forward running speed limit under torque control | 100.0% (0.0%~100.0%) | RUN |
| F03.57 (0x0339) | Max. REV Speed Limit under Torque Control | V/F SVC FVC PMVF PMSVC PMFVC Set the max. reverse running speed limit under torque control | 100.0% (0.0%~100.0%) | RUN |
| F03.58 (0x033A) | Torque Gain Switching Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the given torque gain switching frequency | 1.00Hz (0.00Hz~ Max. frequency) | RUN |
| F03.59 (0x033B) | Torque Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the given torque gain | 100.0% (0.0%~500.0%) | RUN |

F03.6x: PM High-Frequency Injection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------|--|------------------------|----------|
| F03.60 (0x033C) | HF Injection | V/F SVC FVC PMVF PMSVC PMFVC PMSVC 0: Disable;1~5: Enable, the greater the value, the higher the injection frequency | 0 (0~5) | STOP |
| F03.61 (0x033D) | HF Injection Voltage | V/F SVC FVC PMVF PMSVC PMFVC It means the injection voltage amplitude relative to rated voltage. This is the result of auto-tuning, so there's no need to modify it | 10.0% (0.0%~100.0%) | RUN |
| F03.62 (0x033E) | HF Injection Cut-off Frequency | V/F SVC FVC PMVF PMSVC PMFVC It means the high-frequency injection range relative to motor rated frequency. It is valid when the motor speed is lower than this value | 10.0% (0.0%~20.0%) | RUN |

F03.7x: Position Compensation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------|--|------------------------|----------|
| F03.70 (0x0346) | Position Compensation | V/F SVC FVC PMVF PMSVC PMFVC Set the position compensation under speed control to realize zero servo or raise system rigidity | 50.0 (0.0~100.0) | RUN |
| F03.71 (0x0347) | Position Compensation Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the position compensation gain. | 0.0 (0.0~100.0) | RUN |
| F03.72 (0x0348) | Position Compensation Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the position compensation limit | 0.0% (0.0%~100.0%) | STOP |
| F03.73 (0x0349) | Compensation Range | V/F SVC FVC PMVF PMSVC PMFVC Set the position compensation range | 10.0% (0.0%~100.0%) | STOP |

F03.8x: Expansion Control

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------|---|--------------------------|----------|
| F03.80 (0x0350) | PM MTPA Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the MTPA gain of the permanent magnet synchronous motor. | 100.0% (0.0%~400.0%) | RUN |
| F03.81 (0x0351) | PM MTPA Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the MTPA filter time of the permanent magnet synchronous motor. | 1.0ms (0.0ms~100.0ms) | RUN |

4.7 F04: V/F Control**F04.0x: V/F Control**

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------|--|-----------------------------|----------|
| F04.00 (0x0400) | V/F Curve | V/F SVC FVC PMVF PMSVC PMFVC Select the type of V/F curve according to different load characteristics. 0: Linear V/F curve; 1~9: 1.1~1.9 power V/F curves respectively; 10: Square V/F curve; 11: Customized V/F curve; | 0 (0~11) | STOP |
| F04.01 (0x0401) | Torque boost | V/F SVC FVC PMVF PMSVC PMFVC 0.0%: Auto torque boost; 0.1%~30.0%: Manual torque boost | Up to model (0.0%~30.0%) | RUN |
| F04.02 (0x0402) | Torque Boost Cut-off Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the range of the torque boost function. The torque boost function will be cut off when the output frequency exceeds this value. | 100.0% (0.0%~100.0%) | RUN |
| F04.03 (0x0403) | Slip Compensation Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the slip compensation gain. | 0.0% (0.0%~200.0%) | RUN |
| F04.04 (0x0404) | Slip Compensation Range | V/F SVC FVC PMVF PMSVC PMFVC Set the slip compensation range. | 100.0% (0.0%~300.0%) | RUN |
| F04.05 (0x0405) | Slip Compensation Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Enter the parameters on the motor's nameplate correctly for auto-tuning for best performance. | 0.200s (0.000s~6.000s) | RUN |
| F04.06 (0x0406) | Vibration Suppression Gain | V/F SVC FVC PMVF PMSVC PMFVC Adjust this value to suppress low frequency resonance. But an excessive value will cause instability. | 100.0% (0.0%~900.0%) | RUN |

| | | | | |
|--------------------|--------------------------------------|--|--------------------------|------|
| F04.07 (0x0407) | Vibration Suppression Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the oscillation suppression filter time. | 1.0s (0.0s~100.0s) | RUN |
| F04.08 (0x0408) | Output Voltage Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the output voltage percentage. | 100.0% (25.0%~120.0%) | STOP |

F04.1x: Customized V/F Curve

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|---|--|----------|
| F04.10 (0x040A) | Self-defined Voltage 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined voltage 1. | 3.0% (0.0%~100.0%) | STOP |
| F04.11 (0x040B) | Self-defined Frequency 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Frequency 1. | 1.00Hz (0.00Hz~ Max. frequency) | STOP |
| F04.12 (0x040C) | Self-defined Voltage 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Voltage 2. | 28.0% (0.0%~100.0%) | STOP |
| F04.13 (0x040D) | Self-defined Frequency 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Frequency 2. | 10.00Hz (0.00Hz~ Max. frequency) | STOP |
| F04.14 (0x040E) | Self-defined Voltage 3 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Voltage 3. | 55.0% (0.0%~100.0%) | STOP |
| F04.15 (0x040F) | Self-defined Frequency 3 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Frequency 3. | 25.00Hz (0.00Hz~ Max. frequency) | STOP |
| F04.16 (0x0410) | Self-defined Voltage 4 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Voltage 4. | 78.0% (0.0%~100.0%) | STOP |
| F04.17 (0x0411) | Self-defined Frequency 4 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Frequency 4. | 37.50Hz (0.00Hz~ Max. frequency) | STOP |
| F04.18 (0x0412) | Self-defined Voltage 5 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Voltage 5. | 100.0% (0.0%~100.0%) | STOP |
| F04.19 (0x0413) | Self-defined Frequency 5 | V/F SVC FVC PMVF PMSVC PMFVC Set the self-defined Frequency 5. | 50.00Hz (0.00Hz~ Max. frequency) | STOP |

F04.2x: V/F Separation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------------|--|---------------------------|----------|
| F04.20 (0x0414) | Voltage | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Source A Tens-bit: Source B 0: Via voltage percentage; 1: Via panel potentiometer (on the external single-row panel) 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via PID; 7: Via RS485; 8: Via optional boards; 9: Via voltage setting; Hundreds-bit: Combination method 0: Source A; 1: Source B; 2: A+B; 3: A-B 4: MIN(A, B); 5: MAX(A, B) | 0x0000 (0x0000~0x0599) | RUN |
| F04.21 (0x0415) | Voltage Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the output voltage percentage under V/F separation control. 100.0% of it corresponds to the motor rated voltage. | 0.00% (0.00%~110.00%) | RUN |
| F04.22 (0x0416) | Voltage Acceleration Time | V/F SVC FVC PMVF PMSVC PMFVC Set the voltage acceleration time under V/F separation control. | 10.00s (0.00s~100.00s) | RUN |
| F04.23 (0x0417) | Voltage Deceleration Time | V/F SVC FVC PMVF PMSVC PMFVC Set the voltage deceleration time under V/F separation control. | 10.00s (0.00s~100.00s) | RUN |
| F04.24 (0x0418) | Stop Mode | V/F SVC FVC PMVF PMSVC PMFVC Set the stop mode under V/F separation control. 0: ACC./DEC. of output voltage and that of output frequency do not affect each other; 1: Output frequency drops after the output voltage drops to 0V. | 0 (0~1) | RUN |
| F04.25 (0x0419) | Voltage Value | V/F SVC FVC PMVF PMSVC PMFVC Set the voltage value under V/F separation control. | 0.00V (0.00V~600.00V) | RUN |

F04.3x: V/F ECO Control

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------|---|------------------------------------|----------|
| F04.30 (0x041E) | Auto ECO Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: ON | 0 (0~1) | STOP |
| F04.31 (0x041F) | Frequency Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit of the auto ECO mode. | 15.0Hz (0.0Hz~50.0Hz) | STOP |
| F04.32 (0x0420) | Voltage Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit of the auto ECO mode. | 50.0% (20.0%~100.0%) | STOP |
| F04.33 (0x0421) | Voltage Regulation Rate | V/F SVC FVC PMVF PMSVC PMFVC Set the voltage regulation rate of the auto ECO mode. | 0.010V/ms (0.010V/ms~0.200V/ms) | RUN |

| | | | | |
|--------------------|--------------------------------|--|--|-----|
| F04.34 (0x0422) | Voltage Increase Rate | \bar{V}/F SVC FVC PMVF PMSVC PMFVC Set the energy-saving step-down voltage recovery rate | 0.200V/ms (0.010V/ms~ 0.200V/ms) | RUN |
| F04.35 (0x0423) | Over-excitation Coefficient | \bar{V}/F SVC FVC PMVF PMSVC PMFVC Valid when F10.11 tens-bit is not set to zero. The output voltage increases with increasing bus voltage at the same output. | 64 (0~200) | RUN |

4.8 F05: Input Terminal

F05.0x: Digital Input Terminal

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------|--|--------------------|----------|
| F05.00 (0x0500) | X1 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 1 (0~95) | STOP |
| F05.01 (0x0501) | X2 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 2 (0~95) | STOP |
| F05.02 (0x0502) | X3 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 4 (0~95) | STOP |
| F05.03 (0x0503) | X4 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 5 (0~95) | STOP |
| F05.04 (0x0504) | X5 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 6 (0~95) | STOP |
| F05.05 (0x0505) | X6 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0~95) | STOP |
| F05.06 (0x0506) | X7 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0~95) | STOP |
| F05.07 (0x0507) | X8 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0~95) | STOP |
| F05.08 (0x0508) | X9 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0~95) | STOP |
| F05.09 (0x0509) | X10 Function | \bar{V}/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0~95) | STOP |

F05.1x: DI Terminal Detection Delay

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------|--|---------------------------|----------|
| F05.10 (0x050A) | X1 ON Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X1 terminal is switched on. | 0.010s (0.000s~6.000s) | RUN |
| F05.11 (0x050B) | X1 OFF Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X1 terminal is switched off. | 0.010s (0.000s~6.000s) | RUN |
| F05.12 (0x050C) | X2 ON Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X2 terminal is switched on. | 0.010s (0.000s~6.000s) | RUN |
| F05.13 (0x050D) | X2 OFF Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X2 terminal is switched off. | 0.010s (0.000s~6.000s) | RUN |
| F05.14 (0x050E) | X3 ON Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X3 terminal is switched on. | 0.010s (0.000s~6.000s) | RUN |
| F05.15 (0x050F) | X3 OFF Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X3 terminal is switched off. | 0.010s (0.000s~6.000s) | RUN |
| F05.16 (0x0510) | X4 ON Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X4 terminal is switched on. | 0.010s (0.000s~6.000s) | RUN |
| F05.17 (0x0511) | X4 OFF Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X4 terminal is switched off. | 0.010s (0.000s~6.000s) | RUN |
| F05.18 (0x0512) | X5 ON Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X5 terminal is switched on. | 0.010s (0.000s~6.000s) | RUN |
| F05.19 (0x0513) | X5 OFF Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when X5 terminal is switched off. | 0.010s (0.000s~6.000s) | RUN |

F05.2x: DI Terminal Characteristics

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|--|---------------------|----------|
| F05.20 (0x0514) | Terminal Control Pattern | V/F SVC FVC PMVF PMSVC PMFVC 0: Two-line 1; 1: Two-line 2; 2: Three-line 1; 3: Three-line 2 Note: See Appendix II for terminal wiring. | 0 (0~3) | STOP |
| F05.22 (0x0516) | X1~X4 Characteristics | V/F SVC FVC PMVF PMSVC PMFVC 0: ON; 1: OFF Ones-bit: X1; Tens-bit: X2; Hundreds-bit: X3; Thousands-bit: X4 | 0000 (0000~1111) | RUN |
| F05.23 (0x0517) | X5~X8 Characteristics | V/F SVC FVC PMVF PMSVC PMFVC 0: ON; 1: OFF Ones-bit: X5; Tens-bit: X6; Hundreds-bit: X7; Thousands-bit: X8 | 0000 (0000~1111) | RUN |
| F05.24 (0x0518) | X9~X10 Characteristics | V/F SVC FVC PMVF PMSVC PMFVC 0: ON; 1: OFF Ones-bit: X9; Tens-bit: X10 | 0000 (0000~1111) | RUN |

| | | | | |
|--------------------|--|--|----------------------------------|------|
| F05.25 (0x0519) | UP/DW Frequency Protection | V/F SVC FVC PMVF PMSVC PMFVC 0: Power loss data protection ON; 1: Power loss data protection OFF; 2: Modifiable during operation, cleared after shutdown | 0 (0-2) | STOP |
| F05.26 (0x051A) | UP/DW Frequency Regulation Rate | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency increase/decrease rate on the UP/DW terminal. | 0.50Hz/s (0.01Hz/s~50.00Hz/s) | RUN |
| F05.27 (0x051B) | Terminal Controlled Emergency Stop DEC. Time | V/F SVC FVC PMVF PMSVC PMFVC Set the deceleration time once emergency stop command is given via the terminals. | 1.00s (0.01s~650.00s) | RUN |

F05.3x: PUL Terminal

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|---|----------------------------------|----------|
| F05.30 (0x051E) | PUL Signal | V/F SVC FVC PMVF PMSVC PMFVC 0: X5(up to 5.00kHz) 1: Expansion X10(Max. 100.00kHz) 2: X5(Max. 100.00kHz) | 0 (0-2) | STOP |
| F05.31 (0x051F) | PUL Min. Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the min. frequency that can be accepted by the PUL terminal. If the frequency given is below this value, drive will still process by this setting. | 0.000kHz (0.000kHz~500.00kHz) | RUN |
| F05.32 (0x0520) | PUL Min. Frequency Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the min. input frequency of the PUL terminal. | 0.00% (0.00%~100.00%) | RUN |
| F05.33 (0x0521) | PUL Max. Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the max frequency accepted by the PUL. If the frequency given is above this value, drive will still process by this setting. | 50.00kHz (0.00kHz~500.00kHz) | RUN |
| F05.34 (0x0522) | PUL Max. Frequency Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the min. input frequency of the PUL terminal. | 100.00% (0.00%~100.00%) | RUN |
| F05.35 (0x0523) | Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set the size of the filter applied to the pulse signal to remove interference to the PUL terminal. | 0.100s (0.000s~9.000s) | RUN |
| F05.36 (0x0524) | PUL Cut-off Frequency | V/F SVC FVC PMVF PMSVC PMFVC Frequencies below this parameter are no longer recognized by the drive. Process as 0Hz | 0.010kHz (0.000kHz~1.000kHz) | RUN |

F05.4x: AI Type

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------|---|-----------------|----------|
| F05.41 (0x0529) | AI1 Signal Type | V/F SVC FVC PMVF PMSVC PMFVC 0: Voltage 0.00V~10.00V; 1: Current 0.00mA~20.00mA | 0 (0~1) | RUN |
| F05.42 (0x052A) | AI2 Signal Type | V/F SVC FVC PMVF PMSVC PMFVC 0: Voltage 0.00V~10.00V; 1: Current 0.00mA~20.00mA | 0 (0~1) | RUN |

| | | | | |
|--------------------|----------|--|---------------------|-----|
| F05.43 (0x052B) | AI Curve | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: AI1 Tens-bit: AI2 0: Straight line(default) 1: Curve 1 2: Curve 2 | 0000 (0000~0022) | RUN |
|--------------------|----------|--|---------------------|-----|

F05.5x: AI Linear Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|---|-------------------------------|----------|
| F05.50 (0x0532) | AI1 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Define the signal received at the AI1 terminal. The voltage signal below this value is processed as the lower limit. | 0.0% (-100.0%~100.0%) | RUN |
| F05.51 (0x0533) | AI1 Lower Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the AI1 lower limit. | 0.00% (-100.00%~100.00%) | RUN |
| F05.52 (0x0534) | AI1 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Define the signal received at the AI1 terminal. The voltage signal higher than this value is processed as the upper limit. | 100.0% (-100.0%~100.0%) | RUN |
| F05.53 (0x0535) | AI1 Upper Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the AI1 upper limit. | 100.00% (-100.00%~100.00%) | RUN |
| F05.54 (0x0536) | AI1 Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Defines the size of the filtering applied to the AI1 signal for removing interference. | 0.100s (0.000s~6.000s) | RUN |
| F05.55 (0x0537) | AI2 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Define the signal received at the AI2 terminal. The voltage signal below this value is processed as the lower limit. | 0.0% (-100.0%~100.0%) | RUN |
| F05.56 (0x0538) | AI2 Lower Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the AI2 lower limit. | 0.00% (-100.00%~100.00%) | RUN |
| F05.57 (0x0539) | AI2 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Define the signal received at the AI2 terminal. The voltage signal higher than this value is processed as the upper limit. | 100.0% (-100.0%~100.0%) | RUN |
| F05.58 (0x053A) | AI2 Upper Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of the upper limit value of AI2 corresponding to the set value. | 100.00% (-100.00%~100.00%) | RUN |
| F05.59 (0x053B) | AI2 Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Defines the size of the filtering applied to the AI2 signal for removing interference. | 0.100s (0.000s~6.000s) | RUN |

F05.6x: AI Curve 1

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------------|---|-----------------------------|----------|
| F05.60 (0x053C) | Curve 1 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit for Curve 1. | 0.0% (0.0%~100.0%) | RUN |
| F05.61 (0x053D) | Curve 1 Lower Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 0.00% (-100.00%~100.00%) | RUN |

| | | | | |
|--------------------|--|--|-------------------------------|-----|
| F05.62 (0x053E) | Curve 1 Inflection Point1 | V/F SVC FVC PMVF PMSVC PMFVC Set input voltage of Curve 1 inflection point 1. | 30.0% (0.0%~100.0%) | RUN |
| F05.63 (0x053F) | Curve 1 Inflection Point 1 Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 30.00% (-100.00%~100.00%) | RUN |
| F05.64 (0x0540) | Curve 1 inflection point2 | V/F SVC FVC PMVF PMSVC PMFVC Set Curve 1 inflection point2 input voltage | 60.0% (0.0%~100.0%) | RUN |
| F05.65 (0x0541) | Curve 1 Inflection Point2 Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 60.00% (-100.00%~100.00%) | RUN |
| F05.66 (0x0542) | Curve 1 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the upper limit for Curve 1. | 100.0% (0.0%~100.0%) | RUN |
| F05.67 (0x0543) | Curve 1 Upper Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 100.00% (-100.00%~100.00%) | RUN |

F05.7x: AI Curve 2

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---|---|-------------------------------|----------|
| F05.70 (0x0546) | Curve 2 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit for Curve 2. | 0.0% (0.0%~100.0%) | RUN |
| F05.71 (0x0547) | Curve 2 Lower Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 0.00% (-100.00%~100.00%) | RUN |
| F05.72 (0x0548) | Curve 2 Inflection Point 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the Curve 2 inflection point 1 input voltage. | 30.0% (0.0%~100.0%) | RUN |
| F05.73 (0x0549) | Curve 2 Inflection Point1 Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 30.00% (-100.00%~100.00%) | RUN |
| F05.74 (0x054A) | Curve 2 Inflection Point 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the Curve 2 inflection point 2 input voltage. | 60.0% (0.0%~100.0%) | RUN |
| F05.75 (0x054B) | Curve 2 Inflection Point2 Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 60.00% (-100.00%~100.00%) | RUN |
| F05.76 (0x054C) | Curve 2 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the upper limit for Curve 2. | 100.00% (0.00%~100.00%) | RUN |
| F05.77 (0x054D) | Curve 2 Upper Limit Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of Curve 1 lower limit. | 100.00% (-100.00%~100.00%) | RUN |

F05.8x: AI as DI Terminal

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------------|---|---------------------------|----------|
| F05.80 (0x0550) | AI as DI Terminal Characteristic | V/F SVC FVC PMVF PMSVC PMFVC 0: Valid at low level; 1: Valid at high level Ones-bit: AI1; Tens-bit: AI2 | 0000 (0000~1111) | RUN |
| F05.81 (0x0551) | AI1 Function | V/F SVC FVC PMVF PMSVC PMFVC See X terminal functions. | 0 (0~95) | STOP |
| F05.82 (0x0552) | AI High Level | V/F SVC FVC PMVF PMSVC PMFVC Any value beyond this setting is considered as high level. | 70.00% (0.00%~100.00%) | RUN |
| F05.83 (0x0553) | AI Low Level | V/F SVC FVC PMVF PMSVC PMFVC Any value below this setting is considered as low level. | 30.00% (0.00%~100.00%) | RUN |
| F05.84 (0x0554) | AI2 Function | V/F SVC FVC PMVF PMSVC PMFVC See X terminal functions. | 0 (0~95) | STOP |

| | | | | |
|--------------------|----------------|---|---------------------------|-----|
| F05.85 (0x0555) | AI2 High Level | V/F SVC FVC PMVF PMSVC PMFVC Any value beyond this setting is considered as high level. | 70.00% (0.00%~100.00%) | RUN |
| F05.86 (0x0556) | AI2 Low Level | V/F SVC FVC PMVF PMSVC PMFVC Any value below this setting is considered as low level. | 30.00% (0.00%~100.00%) | RUN |

4.9 F06: Output Terminal

F06.0x: AO (Analog Output)

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------|---|---------------------------------|----------|
| F06.00(0x0600) | AO Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: 0V~10V; 1: 4.00mA~20.00mA; 2: 0.00mA~20.00mA; 3: FM output | 0 (0~3) | RUN |
| F06.01 (0x0601) | AO Content | V/F SVC FVC PMVF PMSVC PMFVC 0: Given frequency; 1: Output frequency; 2: Output current; 3: Input voltage; 4: Output voltage; 5: Mechanical speed; 6: Given torque; 7: Output torque; 8: PID setting; 9: PID feedback; 10: Output power; 11: Bus voltage; 12: AI1 input; 13: AI2 input; 14: Reserved; 15: PUL input; 16: Module temperature 1; 17: Module temperature 2; 18: RS485 setting; 19: vY1 function | 0 (0~19) | RUN |
| F06.02(0x0602) | AO Gain | V/F SVC FVC PMVF PMSVC PMFVC Set to adjust the analog output from the terminals. | 100.0% (0.0%~300.0%) | RUN |
| F06.03 (0x0603) | AO Bias | V/F SVC FVC PMVF PMSVC PMFVC Set AO bias to adjust the zero point of the terminal output. | 0.0% (-10.0%~10.0%) | RUN |
| F06.04(0x0604) | AO Filter | V/F SVC FVC PMVF PMSVC PMFVC Set the size of the filter applied to the analog signal to remove interference. | 0.010s (0.000s~6.000s) | RUN |
| F06.05(0x0605) | AO as FM Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set AO as the lower limit of FM signal output. | 0.20kHz (0.00kHz~100.00kHz) | RUN |
| F06.06(0x0606) | AO as FM Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set AO as the upper limit of frequency modulation. | 50.00kHz (0.00kHz~100.00kHz) | RUN |

F06.1x: AO Expansion

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|----------------------|---|---------------------------|----------|
| F06.10(0x060A) | AO Expansion Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: 0V~10V; 1: 4.00mA~20.00mA; 2: 0.00mA~20.00mA; 3: FM output | 0 (0~3) | RUN |
| F06.11 (0x060B) | AO Expansion Content | V/F SVC FVC PMVF PMSVC PMFVC Select what to output from the AO expansion board. | 1 (0~19) | RUN |
| F06.12 (0x060C) | AO Expansion Gain | V/F SVC FVC PMVF PMSVC PMFVC Set to adjust the analog output from the terminals. | 100.0% (0.0%~300.0%) | RUN |
| F06.13 (0x060D) | Expansion AO Bias | V/F SVC FVC PMVF PMSVC PMFVC Set the bias to adjust the zero point of the terminal output. | 0.0% (-10.0%~10.0%) | RUN |
| F06.14(0x060E) | AO Expansion Filter | V/F SVC FVC PMVF PMSVC PMFVC Set the size of the filter applied to the analog signal to remove interference. | 0.010s (0.000s~6.000s) | RUN |

F06.2x~F06.3x: DO and RO

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|--------------------------|---|----------------------------|----------|
| F06.20 (0x0614) | Polarity | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Y terminal Tens-bit: Relay terminal Hundreds-bit: Y expansion terminal Thousands-bit: Relay expansion terminal 0: Positive 1: Negative | 0000 (0000~1111) | RUN |
| F06.21 (0x0615) | Y Terminal Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal Y. | 1 (0~63) | RUN |
| F06.22 (0x0616) | Relay Terminal Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal Y. | 4 (0~63) | RUN |
| F06.23 (0x0617) | Y Expansion Function | V/F SVC FVC PMVF PMSVC PMFVC Set the function of expanded Y terminal. | 0 (0~63) | RUN |
| F06.24 (0x0618) | Relay Expansion Function | V/F SVC FVC PMVF PMSVC PMFVC Set the function of relay expansion 2. | 0 (0~63) | RUN |
| F06.25 (0x0619) | Y Terminal ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when Y terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.26 (0x061A) | Relay Terminal ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when the relay terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.27 (0x061B) | Y Expansion ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when Y expansion terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.28 (0x061C) | Relay Expansion ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when relay expansion terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.29 (0x061D) | Y Terminal OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when Y terminal is switched off. | 0.010s (0.000s~60.000s) | RUN |
| F06.30 (0x061E) | Relay Terminal OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when relay terminal is switched off. | 0.010s (0.000s~60.000s) | RUN |

| | | | | |
|--------------------|---------------------------|---|----------------------------|-----|
| F06.31 (0x061F) | Y Expansion OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when Y expansion terminal is switched off. | 0.010s (0.000s~60.000s) | RUN |
| F06.32 (0x0620) | Relay Expansion OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when relay expansion terminal is switched off. | 0.010s (0.000s~60.000s) | RUN |

F06.4x: Frequency Detection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------------|--|---------------------------------------|----------|
| F06.40 (0x0628) | Frequency Detection 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency detection value 1. | 2.00Hz (0.00Hz~ Max. frequency) | RUN |
| F06.41 (0x0629) | Frequency Detection Range 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency detection range 1. | 1.00Hz (0.00Hz~ Max. frequency) | RUN |
| F06.42 (0x062A) | Frequency Detection 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency detection value 2. | 2.00Hz (0.00Hz~ Max. frequency) | RUN |
| F06.43 (0x062B) | Frequency Detection Range 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency detection range 2. | 1.00Hz (0.00Hz~ Max. frequency) | RUN |
| F06.44 (0x062C) | Frequency Arrival Detection Range | V/F SVC FVC PMVF PMSVC PMFVC Set the detection range of the given frequency to check if the setting is reached. | 2.00Hz (0.00Hz~ Max. frequency) | RUN |

F06.5x: Monitor Comparator Output 1

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|--|---------------------|----------|
| F06.50 (0x0632) | Comparator 1 Item | V/F SVC FVC PMVF PMSVC PMFVC Ones- and tens-bit: Set monitor parameter 00~63 to yy in Cxx.yy. Hundreds and thousands-bit: Set monitor parameter 00~07 to xx in Cxx.yy. | 0001 (0000~0763) | RUN |
| F06.51 (0x0633) | Comparator 1 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 1 upper limit. | (up to F06.50) | RUN |
| F06.52 (0x0634) | Comparator 1 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 1 lower limit. | (up to F06.50) | RUN |
| F06.53 (0x0635) | Comparator 1 Bias | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 1 bias value. | (up to F06.50) | RUN |
| F06.54 (0x0636) | Comparator 1 Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Continue operation(DO terminal only); 1: Report alarm and free stop; 2: Report warning and continue operation 3: Force stop | 0 (0~3) | RUN |
| F06.55 (0x0637) | Comparator 2 Item | V/F SVC FVC PMVF PMSVC PMFVC Ones- and tens-bit: Set monitor parameter 00~63 to yy in Cxx.yy. Hundreds and thousands-bit: Set monitor parameter 00~07 to xx in Cxx.yy. | 0002 (0000~0763) | RUN |
| F06.56 (0x0638) | Comparator 2 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 2 upper limit. | (up to F06.55) | RUN |

| | | | | |
|--------------------|--------------------------|---|----------------|-----|
| F06.57 (0x0639) | Comparator 2 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 2 lower limit. | (up to F06.55) | RUN |
| F06.58 (0x063A) | Comparator 2 Bias | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 2 bias value. | (up to F06.55) | RUN |
| F06.59 (0x063B) | Comparator 2 Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Continue operation(DO terminal only); 1: Report alarm and free stop; 2: Report warning and continue operation 3: Force stop | 0 (0-3) | RUN |

F06.6x~F06.7x: Virtual I/O Terminal

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|---|----------------------------|----------|
| F06.60 (0x063C) | vX1 Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0-95) | RUN |
| F06.61 (0x063D) | vX2 Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0-95) | RUN |
| F06.62 (0x063E) | vX3 Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0-95) | RUN |
| F06.63 (0x063F) | vX4 Function | V/F SVC FVC PMVF PMSVC PMFVC See the functions of terminal X. | 0 (0-95) | RUN |
| F06.64 (0x0640) | vX Status Source | V/F SVC FVC PMVF PMSVC PMFVC 0: By internal connection with vYn terminal 1: By physical connection with Xn terminal 2: By function code setting Ones-bit: vX1; Tens-bit: vX2 Hundreds-bit: vX3; Thousands-bit: vX4 | 0000 (0000-2222) | RUN |
| F06.65 (0x0641) | vX Setting from Function Code | V/F SVC FVC PMVF PMSVC PMFVC 0: Invalid; 1: Valid Ones-bit: vX1; Tens-bit: vX2 Hundreds-bit: vX3; Thousands-bit: vX4 | 0000 (0000-1111) | RUN |
| F06.66 (0x0642) | vY1 Function | V/F SVC FVC PMVF PMSVC PMFVC See Y terminal functions. | 0 (0-63) | RUN |
| F06.67 (0x0643) | vY2 output selection | V/F SVC FVC PMVF PMSVC PMFVC See Y terminal functions. | 0 (0-63) | RUN |
| F06.68 (0x0644) | vY3 Function | V/F SVC FVC PMVF PMSVC PMFVC See Y terminal functions. | 0 (0-63) | RUN |
| F06.69 (0x0645) | vY4 Function | V/F SVC FVC PMVF PMSVC PMFVC See Y terminal functions. | 0 (0-63) | RUN |
| F06.70 (0x0646) | vY1 ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY1 terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.71 (0x0647) | vY2 ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY2 terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.72 (0x0648) | vY3 ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY3 terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |
| F06.73 (0x0649) | vY4 ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY4 terminal is switched on. | 0.010s (0.000s~60.000s) | RUN |

| | | | | |
|--------------------|---------------|--|----------------------------|-----|
| F06.74 (0x064A) | vY1 OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY1 is switched off. | 0.010s (0.000s~60.000s) | RUN |
| F06.75 (0x064B) | vY2 OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY2 is switched off. | 0.010s (0.000s~60.000s) | RUN |
| F06.76 (0x064C) | vY3 OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY3 is switched off. | 0.010s (0.000s~60.000s) | RUN |
| F06.77 (0x064D) | vY4 OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when vY4 is switched off. | 0.010s (0.000s~60.000s) | RUN |

F06.7x: Monitor Comparator 2 Output

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|--|---------------------------|----------|
| F06.80 (0x0650) | Comparator 3 Item | V/F SVC FVC PMVF PMSVC PMFVC Ones- and tens-bit: Set monitor parameter 00~63 to yy in Cxx.yy. Hundreds and thousands-bit: Set monitor parameter 00~07 to xx in Cxx.yy. | 0003 (0000~0763) | RUN |
| F06.81 (0x0651) | Comparator 3 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 3 upper limit. | (up to F06.80) | RUN |
| F06.82 (0x0652) | Comparator 3 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 3 lower limit. | (up to F06.80) | RUN |
| F06.83 (0x0653) | Comparator 3 Bias | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 3 bias value. | (up to F06.80) | RUN |
| F06.84 (0x0654) | Comparator 3 Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Continue operation (DO terminal only); 1: Report alarm and free stop; 2: Report warning and continue operation 3: Force stop | 0 (0~3) | RUN |
| F06.85 (0x0655) | Comparator 4 Item | V/F SVC FVC PMVF PMSVC PMFVC Ones- and tens-bit: Set monitor parameter 00~63 to yy in Cxx.yy. Hundreds and thousands-bit: Set monitor parameter 00~07 to xx in Cxx.yy. | 0004 (0000~0763) | RUN |
| F06.86 (0x0656) | Comparator 4 Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 4 upper limit. | (up to F06.85) | RUN |
| F06.87 (0x0657) | Comparator 4 Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 4 lower limit. | (up to F06.85) | RUN |
| F06.88 (0x0658) | Comparator 4 Bias | V/F SVC FVC PMVF PMSVC PMFVC Set the comparator 4 bias value. | (up to F06.85) | RUN |
| F06.89 (0x0659) | Comparator 4 Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Continue operation (DO terminal only); 1: Report alarm and free stop; 2: Report warning and continue operation 3: Force stop | 0 (0~3) | RUN |
| F06.90 (0x065A) | Comparator ON Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when comparator 1-4 is turned on for output. | 0.010 (0.000s~60.000s) | RUN |
| F06.91 (0x065B) | Comparator OFF Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the delay time when comparator 1-4 is turned off for output. | 0.010 (0.000s~60.000s) | RUN |

4.10 F07: Operation Control

F07.0x: Connection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------|--|--|----------|
| F07.00 (0x0700) | Starting Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Start at starting frequency 1: Start from DC braking and then at starting frequency 2: Start from speed tracking and direction identification | 0 (0~2) | STOP |
| F07.01 (0x0701) | Pre-excitation Start Time | V/F SVC FVC PMVF PMSVC PMFVC Only SVC on asynchronous motors supports pre-excitation. | 0.00s (0.00s~60.00s) | STOP |
| F07.02 (0x0702) | Starting Frequency | V/F SVC FVC PMVF PMSVC PMFVC Drive will not start but stay in standby when the given frequency is lower than this value. | 0.00Hz (0.00Hz~Upper limit frequency set in digits) | STOP |
| F07.03 (0x0703) | Terminal Protection | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: ON Ones-bit: ON when terminals under abnormal exit; Tens-bit: ON when jogging terminals under abnormal exit; Hundreds-bit: ON when command source switched to terminals Note: The terminal protection is enabled by default when free stop, emergency stop or forced stop command are valid, report A. runx warning when protection is triggered. | 0111 (0000~1111) | STOP |
| F07.05 (0x0705) | Operation Direction | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Operation direction 0: Keep the direction; 1: Invert the direction Tens-bit: Direction disable 0: FWD/REV allowed; 1: Only FWD allowed; 2: Only REV allowed Hundreds-bit: Frequency controlled direction 0: Invalid; 1: Valid Note: This value will not be reset during initialization, and the ones-bit value will not be changed after parameter download. | 0000 (0000~1121) | STOP |
| F07.06 (0x0706) | Power-down Restart Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Invalid; 1: Start from speed tracking; 2: Start as startup mode setting. | 0 (0~2) | STOP |
| F07.07 (0x0707) | Power-Down Restart Interval | V/F SVC FVC PMVF PMSVC PMFVC Set the waiting interval to restart after power cut. | 0.50s (0.00s~60.00s) | STOP |

F07.1x: Stop Control

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|--|--|----------|
| F07.10 (0x070A) | Stop Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Deceleration stop; 1: Free stop | 0 (0~1) | RUN |
| F07.11 (0x070B) | Stop Detection Frequency | V/F SVC FVC PMVF PMSVC PMFVC In deceleration stop mode, the drive will stop if the output frequency is lower than this value. | 0.50Hz (0.00Hz~Upper limit frequency set in digits) | RUN |
| F07.12 (0x070C) | Pause-Restart Interval | V/F SVC FVC PMVF PMSVC PMFVC Set waiting time to restart after operation pause. | 0.00s (0.00s~60.00s) | STOP |

| | | | | |
|--------------------|---------------------------------------|--|------------------------|------|
| F07.15 (0x070F) | Operation below Lower Limit Frequency | V/F SVC FVC PMVF PMSVC PMFVC 0: Run at frequency command; 1: Free stop and pause; 2: Run at lower limit frequency; 3: Run at zero-speed | 2 (0-3) | RUN |
| F07.16 (0x0710) | Zero-Speed Torque Holding Factor | V/F SVC FVC PMVF PMSVC PMFVC Set the torque holding factor during zero-speed operation, 100.0% of the rated drive current. | 60.0% (0.0%~150.0%) | RUN |
| F07.17 (0x0711) | Zero-speed Torque Holding Time | V/F SVC FVC PMVF PMSVC PMFVC Set the holding time during zero-speed operation. | 0.0s (0.0s-6000.0s) | RUN |
| F07.18 (0x0712) | FED/REV Dead Time | V/F SVC FVC PMVF PMSVC PMFVC Set the zero-frequency holding time during FWD/REV switching. | 0.0s (0.0s~120.0s) | STOP |

F07.2x: DC Brake and Speed Tracking

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------------|--|----------------------------|----------|
| F07.20 (0x0714) | DC Braking Current during Start | V/F SVC FVC PMVF PMSVC PMFVC The reference is the rated current of the motor, and it's limited by the rated drive current. | 60.0% (0.0%~150.0%) | STOP |
| F07.21 (0x0715) | DC Braking Time during Start | V/F SVC FVC PMVF PMSVC PMFVC Set the DC braking duration during start. | 0.0s (0.0s~60.0s) | STOP |
| F07.22 (0x0716) | DC Braking Frequency during Shutdown | V/F SVC FVC PMVF PMSVC PMFVC Set the DC braking working frequency to stop. | 1.00Hz (0.00Hz~50.00Hz) | STOP |
| F07.23 (0x0717) | DC Braking Current during Shutdown | V/F SVC FVC PMVF PMSVC PMFVC The reference is the rated current of the motor, and it's limited by the rated drive current. | 60.0% (0.0%~150.0%) | STOP |
| F07.24 (0x0718) | DC Braking Duration during Shutdown | V/F SVC FVC PMVF PMSVC PMFVC Set the duration of DC braking during stop. | 0.0s (0.0s~60.0s) | STOP |
| F07.25 (0x0719) | Speed Tracking | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Search mode 0: Search from max. frequency; 1: Search from stop frequency Tens-bit: Search backwards 0: OFF; 1: ON Hundreds-bit: Search source 0: Software; 1: Hardware | 0000 (0000~1111) | STOP |
| F07.26 (0x071A) | Speed Tracking Time | V/F SVC FVC PMVF PMSVC PMFVC Set the speed tracking time. | 0.50s (0.00s~60.00s) | STOP |
| F07.27 (0x071B) | Speed Tracking Stop Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the speed tracking stop delay. | 1.00s (0.00s~60.00s) | STOP |
| F07.28 (0x071C) | Speed Tracking Current | V/F SVC FVC PMVF PMSVC PMFVC Set the speed tracking current. | 120.0% (0.0%~400.0%) | STOP |

F07.3x: Jogging

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------|---|---------------------------------------|----------|
| F07.30 (0x071E) | Jogging Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the jogging frequency. | 5.00Hz (0.00Hz~ Max. frequency) | RUN |
| F07.31 (0x071F) | Jogging ACC Time | V/F SVC FVC PMVF PMSVC PMFVC Set the jogging acceleration time. | 10.00s (0.00s~650.00s) | RUN |

| | | | | |
|--------------------|-------------------|---|---------------------------|------|
| F07.32 (0x0720) | Jogging DEC Time | V/F SVC FVC PMVF PMSVC PMFVC Set the jogging deceleration time. | 10.00s (0.00s~650.00s) | RUN |
| F07.33 (0x0721) | S-curve Jogging | V/F SVC FVC PMVF PMSVC PMFVC Set the S-curve for jogging. 0: Invalid; 1: Valid | 1 (0~1) | RUN |
| F07.34 (0x0722) | Jogging Stop Mode | V/F SVC FVC PMVF PMSVC PMFVC Set the stop mode for jogging. 0: By F7.10 setting; 1: Deceleration stop only | 0 (0~1) | STOP |

F07.4x: Holding and Jump Frequency during Start/Stop

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------|--|---|----------|
| F07.40 (0x0728) | Start Holding Frequency | V/F SVC FVC PMVF PMSVC PMFVC It is higher than the starting frequency and lower than the upper limit frequency set in digits. | 0.50Hz (0.00Hz~Upper limit frequency from panel) | STOP |
| F07.41 (0x0729) | Start Frequency Holding Time | V/F SVC FVC PMVF PMSVC PMFVC The set value should be greater than the starting frequency, and if it is insufficient, start at starting frequency. | 0.00s (0.00s~60.00s) | STOP |
| F07.42 (0x072A) | Stop Holding Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the holding frequency during stop. | 0.50Hz (0.00Hz~Upper limit frequency from panel) | STOP |
| F07.43 (0x072B) | Stop Frequency Holding Time | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency holding time during stop. | 0.00s (0.00s~60.00s) | STOP |
| F07.44 (0x072C) | Jump Frequency 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the jump frequency 1. | 0.00Hz (0.00Hz~Max. frequency) | RUN |
| F07.45 (0x072D) | Jump Frequency 1 Range | V/F SVC FVC PMVF PMSVC PMFVC Set the range for jump frequency 1. | 0.00Hz (0.00Hz~Max. frequency) | RUN |
| F07.46 (0x072E) | Jump Frequency 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the jump frequency 2. | 0.00Hz (0.00Hz~Max. frequency) | RUN |
| F07.47 (0x072F) | Jump Frequency 2 Range | V/F SVC FVC PMVF PMSVC PMFVC Set the range for jump frequency 2. | 0.00Hz (0.00Hz~Max. frequency) | RUN |

4.11 F08: Auxiliary Control

F08.0x: Counting and Timing

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------|--|--------------------|----------|
| F08.00 (0x0800) | Counter Source | V/F SVC FVC PMVF PMSVC PMFVC 0: X terminal; 1: PUL terminal; 2~5: Reserved | 0 (0~5) | RUN |
| F08.01 (0x0801) | Counter Frequency Division | V/F SVC FVC PMVF PMSVC PMFVC Set the frequency division for the counting circuit. | 0 (0~6000) | RUN |
| F08.02 (0x0802) | Max Counting | V/F SVC FVC PMVF PMSVC PMFVC Set the max. value for the counting circuit. | 1000 (0~65000) | RUN |

| | | | | |
|--------------------|---------------------|---|----------------------|------|
| F08.03 (0x0803) | Counter Setting | V/F SVC FVC PMVF PMSVC PMFVC Set the value for the counting circuit. | 500 (0-65000) | RUN |
| F08.04 (0x0804) | Pulse No. Per Meter | V/F SVC FVC PMVF PMSVC PMFVC Set the counting value per meter. | 10.0 (0.1-6553.5) | RUN |
| F08.05 (0x0805) | Length Setting | V/F SVC FVC PMVF PMSVC PMFVC Increase one unit of length to output, while reset when one terminal length is reached. | 1000m (0m-65535m) | STOP |
| F08.06 (0x0806) | Actual Length | V/F SVC FVC PMVF PMSVC PMFVC Set the actual length, and it will not be saved in case of power cut. | 0m (0m-65535m) | STOP |
| F08.07 (0x0807) | Timer Unit | V/F SVC FVC PMVF PMSVC PMFVC Set the time unit on the timing circuit. 0: Second(s); 1: Minute(min); 2: Hour(h) | 0 (0-2) | STOP |
| F08.08 (0x0808) | Timer Setting | V/F SVC FVC PMVF PMSVC PMFVC Set the value for timing. | 0 (0-65000) | STOP |

F08.3x: Swing Frequency

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------------------------|--|---------------------------------------|----------|
| F08.30 (0x081E) | Swing Frequency | V/F SVC FVC PMVF PMSVC PMFVC 0: Invalid; 1: Valid | 0 (0-1) | STOP |
| F08.31 (0x081F) | Swing Frequency Range | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Start method 0: Auto; 1: Manual via terminal Tens-bit: Swing frequency range 0: Center frequency-based; 1: Max. frequency-based Hundreds-bit: Preset frequency 0: OFF; 1: ON | 0000 (0000-0111) | STOP |
| F08.32 (0x0820) | Swing Frequency Preset | V/F SVC FVC PMVF PMSVC PMFVC Set the preset swing frequency. | 0.00Hz (0.00Hz~ Max. frequency) | STOP |
| F08.33 (0x0821) | Preset Swing Frequency Interval | V/F SVC FVC PMVF PMSVC PMFVC Set the preset swing frequency waiting time. | 0.0s (0.0s-3600.0s) | STOP |
| F08.34 (0x0822) | Swing Frequency Range | V/F SVC FVC PMVF PMSVC PMFVC Set the swing frequency range value. | 10.0% (0.0%-50.0%) | STOP |
| F08.35 (0x0823) | Kick Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the kick frequency. | 10.0% (0.0%-50.0%) | STOP |
| F08.36 (0x0824) | Triangular Wave Rise Time | V/F SVC FVC PMVF PMSVC PMFVC Set the triangular wave rise time. | 5.00s (0.00s-650.00s) | STOP |
| F08.37 (0x0825) | Triangular Wave Drop Time | V/F SVC FVC PMVF PMSVC PMFVC Set the triangular wave drop time. | 5.00s (0.00s-650.00s) | STOP |
| F08.41 (0x0829) | Monitoring 1 Ratio | V/F SVC FVC PMVF PMSVC PMFVC Thousands-bit: Decimal digit setting Hundreds-bit: C0x setting Tens-, ones-bit: Set yy in C0x.yy | 2000 (0000-3763) | RUN |
| F08.42 (0x082A) | Monitoring 1 Proportional Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Set the proportion coefficient for monitoring value 1, the calculated monitoring value is C02.23 | 1.00 (0.00-600.00) | RUN |
| F08.43 (0x082B) | Monitoring 2 Ratio | V/F SVC FVC PMVF PMSVC PMFVC Thousands-bit: Decimal digit setting Hundreds-bit: C0x setting Tens-, ones-bit: Set yy in C0x.yy | 2001 (0000-3763) | RUN |

| | | | | |
|--------------------|--|--|-----------------------|-----|
| F08.44 (0x082C) | Monitoring 2 Proportional Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Set the proportional coefficient for monitoring value 2, and the calculated monitoring value is C02.24. | 1.00 (0.00~600.00) | RUN |
|--------------------|--|--|-----------------------|-----|

4.12 F09: Auxiliary Control 2

F09.0x: Maintenance

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------------|---|---------------------------|----------|
| F09.02 (0x0902) | Maintenance Warning | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Cooling fan; 0: Invalid; 1: Valid Tens-bit: Main relay; 0: Invalid; 1: Valid; Hundreds-bit: Reserved; Thousands-bit: Reserved | 0x0000 (0x0000~0x1111) | RUN |
| F09.03 (0x0903) | Fan Maintenance | V/F SVC FVC PMVF PMSVC PMFVC Set it to 0 when replacing with a new fan in hour. | 0 (0~65535) | STOP |
| F09.04 (0x0904) | Main Relay Maintenance | V/F SVC FVC PMVF PMSVC PMFVC When replacing the main relay, set it to 0.0%. | 0.0% (0.0%~150.0%) | STOP |

4.13 F10: Protection Parameters

F10.0x: Current Protection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------|--|-------------------------|----------|
| F10.00 (0x0A00) | OC Suppression | V/F SVC FVC PMVF PMSVC PMFVC Auto limit the output current below the set overcurrent suppression point to prevent overcurrent faults triggered by excessive current. 0: Always ON; 1: ON during ACC/DEC and OFF at constant speed | 0 (0~1) | RUN |
| F10.01 (0x0A01) | OC Suppression Point | V/F SVC FVC PMVF PMSVC PMFVC Set load current limit level, 100% of the drive rated current | 160.0% (0.0%~300.0%) | RUN |
| F10.02 (0x0A02) | OC Suppression Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the response effect of overcurrent suppression | 100.0% (0.0%~500.0%) | RUN |
| F10.03 (0x0A03) | Current Protection 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the current-related protection on/off. Ones-bit: CBC 0: OFF; 1: ON Tens-bit: OC protection interference suppression 0: Normal; 1: Level 1; 2: Level 2 Hundreds-bit: SC protection interference suppression 0: Normal; 1: Level 1; 2: Level 2 Thousand bits: SC, OC, OU, fault reset delay 0: OFF; 1: ON | 0001 (0000~f221) | STOP |
| F10.04 (0x0A04) | Current Protection 2 | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Three-phase current sum protection 0: OFF; 1: ON Tens-bit: Three-phase current imbalance detection, report E.oLF4. 0: OFF; 1: ON | 0001 (0000~0011) | STOP |

| | | | | |
|--------------------|--------------------------------------|---|----------------------|------|
| F10.05 (0x0A05) | Current Imbalance Threshold | V/F SVC FVC PMVF PMSVC PMFVC The ratio of the largest to the smallest phase of the three-phase current. This is used to judge current imbalance faults by comparing it with the set value. | 160% (0%~500%) | STOP |
| F10.06 (0x0A06) | Current Imbalance Filter Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Increase this parameter under high current fluctuation. | 2.0s (0.0s~60.0s) | STOP |

F10.1x: Voltage Protection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|--|---|----------|
| F10.10 (0x0A0A) | Operation Pause Delay | V/F SVC FVC PMVF PMSVC PMFVC When the set value is zero, trigger the UV fault as usual. While if the set value is non-zero, trigger the UV warning, the output will be suppressed, and the system will pause. If the UV still exists after the delay, report fault, and if the voltage recovers during delay, operation is immediately resumed. | 0.0s (0.0s~10.0s) | STOP |
| F10.11 (0x0A0B) | Bus OV Suppression | V/F SVC FVC PMVF PMSVC PMFVC If the bus voltage is higher than the overvoltage suppression point, acceleration and deceleration will be slowed down or stopped to prevent overvoltage faults. Ones-bit: OV suppression 0: OFF; 1: ON Tens-bit: Overexcitation 0: OFF; 1: ON during deceleration; 2: ON during operation | 0011 (0000~0021) | STOP |
| F10.12 (0x0A0C) | Bus OV Suppression Point | V/F SVC FVC PMVF PMSVC PMFVC Set the bus voltage value to trigger the overvoltage suppression function. | T3: 750V S2: 370V (0V~OV point) T3 OV point: 820V S2 OV point: 400V | STOP |
| F10.13 (0x0A0D) | Bus OV Suppression Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the response effect of overvoltage suppression. | 100.0% (0.0%~500.0%) | RUN |
| F10.14 (0x0A0E) | Dynamic Braking | V/F SVC FVC PMVF PMSVC PMFVC Set the dynamic braking ON or OFF. 0: OFF; 1: ON, with overvoltage suppression off 2: ON, with overvoltage suppression on. | 2 (0~2) | RUN |
| F10.15 (0x0A0F) | Dynamic Braking Voltage | V/F SVC FVC PMVF PMSVC PMFVC Set the dynamic brake voltage to start when the bus voltage is higher than this value. | T3: 740V S2: 360V (0V~OV point) T3 OV point: 820V S2 OV point: 400V | RUN |
| F10.16 (0x0A10) | Bus UV Suppression | V/F SVC FVC PMVF PMSVC PMFVC Auto adjust the operation frequency when the bus voltage is lower than the under-voltage suppression point to prevent under-voltage faults. 0: OFF; 1: ON | 0 (0~1) | STOP |
| F10.17 (0x0A11) | Bus UV Suppression Point | V/F SVC FVC PMVF PMSVC PMFVC Set the bus voltage value to trigger the undervoltage suppression function. | T3: 430V S2: 240V (0V~OV point) T3 OV point: 820V S2 OV point: 400V | STOP |
| F10.18 (0x0A12) | Bus UV Suppression Gain | V/F SVC FVC PMVF PMSVC PMFVC Set the response effect of undervoltage suppression. | 100.0% (0.0%~500.0%) | RUN |

| | | | | |
|--------------------|-------------------------|--|---|------|
| F10.19 (0x0A13) | Bus UV Protection Point | V/F SVC FVC PMVF PMSVC PMFVC Set the lower limit voltage of the busbar voltage allowed, report undervoltage fault when below this value. | T3: 320V S2: 190V (0V~OV point) T3 OV point: 820V S2 OV point: 400V | STOP |
|--------------------|-------------------------|--|---|------|

F10.2x: Auxiliary Protection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--|---|---------------------------|----------|
| F10.20 (0x0A14) | I/O Phase Loss Protection | V/F SVC FVC PMVF PMSVC PMFVC Set the I/O phase loss protection function on or off. Ones-bit: Output phase loss protection 0: OFF; 1: ON Tens-bit: Input phase loss protection 0: OFF; 1: ON, report A.iLF when input phase loss is detected, continue operation; 2: ON, report E.iLF when input phase loss is detected, free stop Hundreds-bit: Reserved Thousands-bit: Reserved | 0021 (000~1121) | STOP |
| F10.21 (0x0A15) | Input Phase Loss Threshold | V/F SVC FVC PMVF PMSVC PMFVC Set the voltage detection percentage for the input phase loss detection, 100% of the rated bus voltage. | 10.0% (0.0%~30.0%) | STOP |
| F10.22 (0x0A16) | Ground Short Circuit Protection | V/F SVC FVC PMVF PMSVC PMFVC Set the drive output and fan to ground short circuit protection on/off. Ones-bit: Output to ground short circuit protection 0: OFF; 1: ON; 2: Detect before operation Tens-bit: Fan to ground short circuit protection 0: OFF; 1: ON Hundreds-bit: 24V power supply short circuit protection 0: OFF; 1: ON | 0111 (0000~0112) | STOP |
| F10.23 (0x0A17) | Fan ON/OFF | V/F SVC FVC PMVF PMSVC PMFVC Set the drive fan operation mode. 0: Fan runs after the drive is powered up; 1: Fan runs according to temperature, and runs with the drive. 2: Fan runs for the set time of F10.24 and stops. It relates to temperature. | 1 (0~2) | RUN |
| F10.24 (0x0A18) | Fan Delay | V/F SVC FVC PMVF PMSVC PMFVC Set the time from operation command release to fan stopping. | 30.00s (0.00s~600.00s) | STOP |
| F10.25 (0x0A19) | Drive OT Warning oH1 | V/F SVC FVC PMVF PMSVC PMFVC Set the value for overheat detection, report warning when it is above this value. | 80.0°C (0.0°C~100.0°C) | RUN |
| F10.26 (0x0A1A) | Motor OT and Module Temperature Sensor | V/F SVC FVC PMVF PMSVC PMFVC Set the function related to motor over-temperature protection with the IO expansion board. Ones-bit: Motor temperature sensor type 0: PT1000 1: KTY84 | 0061 (0000~0091) | RUN |

| | | | | |
|--------------------|---------------------------------|--|----------------------------|-----|
| | | <p>IO expansion board dip switches to KTY, and F10.26 is valid.</p> <p>IO expansion board dip switches to PT100, and PT100 sensor is valid.</p> <p>Tens-bit: Motor temperature detection duration 0: 2s; 1: Fault identification off; 2: 5s; 3: 30s; 4: 60s; 5: 120s; 6: 300s(5 min)-default 7: 600s 8: 1200s; 9: 1800s(30 min)</p> <p>Note: When the output current is lower than 1/2 of the rated current of the motor, the time is twice the set value.</p> <p>Hundreds-bit: Internal module temperature sensor disconnection detection 0: ON, this function is not related to the expansion board; 1: OFF.</p> <p>Thousands-bit: Motor temperature disconnection mode 0: Detection OFF; 1: Report alarm and free stop; 2: Report warning and continue operation</p> | | |
| F10.27 (0x0A1B) | Motor OT Alarm (Expansion) | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the value for over-temperature, report fault when it is above this value.</p> | 110.0°C (0.0°C~200.0°C) | RUN |
| F10.28 (0x0A1C) | Motor OT Warning (Expansion) | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the value for over-temperature, report warning when it is above this value.</p> | 90.0°C (0.0°C~F10.27) | RUN |

F10.3x: Load Protection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------|--|---------------------|----------|
| F10.31 (0x0A1F) | Load Warning Threshold | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the load warning threshold under vector control. Ones-bit: Load warning reference 0: Output torque; 1: Output current</p> | 0000 (0000-0001) | STOP |
| F10.32 (0x0A20) | Load Detection/Warning Mode | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the drive load detection mode and the warning mode at this time. Ones-bit: Load detection mode 1 0: Detection OFF; 1: Detect overload; 2: Detect overload only at constant speed; 3: Detect underload; 4: Detect underload at constant speed only; Tens-bit: Load detection 1 warning mode 0: Continue the operation, report A. LD1; 1: Free stop, report E. LD1 Hundreds-bit: Load detection mode 2 0: Detection off; 1: Detect overload; 2: Detect overload only at constant speed; 3: Detect underload; 4: Detect underload at constant speed only; Thousands-bit: Load detection 2 warning mode 0: Continue the operation, report A. LD1; 1: Free stop, report E. LD1</p> | 0000 (0000-1414) | STOP |

| | | | | |
|--------------------|----------------------------|---|-------------------------|------|
| F10.33 (0x0A21) | Load Warning 1 | V/F SVC FVC PMVF PMSVC PMFVC Set the load warning value 1 for detection. For V/F control, it is 100% of the rated motor current. For vector control, it is 100% of the motor rated output torque. | 130.0% (0.0%~200.0%) | STOP |
| F10.34 (0x0A22) | Load Warning 1 Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the detection duration of load warning 1, if the load is higher than the load warning level for the set time here, report load warning 1. | 5.0s (0.0s~60.0s) | STOP |
| F10.35 (0x0A23) | Load Warning 2 | V/F SVC FVC PMVF PMSVC PMFVC Set the load warning value 2 for detection. For V/F control, it is 100% of the rated motor current. For vector control, it is 100% of the motor rated output torque. | 30.0% (0.0%~200.0%) | STOP |
| F10.36 (0x0A24) | Load Warning 2 Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the detection duration of load warning 2, if the load is higher than the load warning threshold for the set time here, report load warning 2. | 5.0s (0.0s~60.0s) | STOP |

F10.4x: Stall Protection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|---|-----------------------|----------|
| F10.40 (0x0A28) | Speed Deviation Protection | V/F SVC FVC PMVF PMSVC PMFVC Set the detection mode and warning mode of excessive deviation between the motor's given speed and the feedback speed. Ones-bit: Detection mode 0: Detection OFF; 1: Detect only at constant speed; 2: ON; Tens-bit: Warning mode 0: Free stop and report fault; 1: Report alarm and continue operation | 0000 (0000~0012) | STOP |
| F10.41 (0x0A29) | Speed Deviation Threshold | V/F SVC FVC PMVF PMSVC PMFVC Set the detection value for excessive speed deviation, 100% of F01.10 [Max. Frequency]. | 10.0% (0.0%~60.0%) | STOP |
| F10.42 (0x0A2A) | Speed Deviation Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the time for excessive speed deviation detection. If the deviation between the given speed and the feedback speed is greater than F10.41 for this time, report excessive speed deviation warning. | 2.0s (0.0s~60.0s) | STOP |
| F10.43 (0x0A2B) | Overspeed Protection | V/F SVC FVC PMVF PMSVC PMFVC Set the detection mode selection and warning mode of overspeed. Ones-bit: Detection mode 0: Detection OFF; 1: Detect only at constant speed; 2: ON; Tens-bit: Warning mode 0: Free stop and report fault; 1: Report alarm and continue operation | 0002 (0000~0012) | STOP |

| | | | | |
|--------------------|---------------------|--|---------------------------|------|
| F10.44 (0x0A2C) | Overspeed Threshold | V/F SVC FVC PMVF PMSVC PMFVC Set the value of the overspeed warning for detection, 100% of F01.10 [Max. Frequency]. | 110.0% (0.0%~150.0%) | STOP |
| F10.45 (0x0A2D) | Overspeed Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the duration of overspeed detection, if the feedback speed is higher than F10.44 and lasts for the set time here, report warning. | 0.100s (0.000s~2.000s) | STOP |

F10.5x: Fault Recovery Protection and Motor Overload

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------|---|-------------------------|----------|
| F10.50 (0x0A32) | Auto-Recovery No. | V/F SVC FVC PMVF PMSVC PMFVC Set the number of times allowed to perform fault auto-recovery. Note: 0 indicates that the fault auto-recovery function is disabled; otherwise, it is enabled. | 0 (0~10) | STOP |
| F10.51 (0x0A33) | Fault Auto-recovery Interval | V/F SVC FVC PMVF PMSVC PMFVC Set the waiting time after a fault occurs until reset. | 1.0s (0.0s~100.0s) | STOP |
| F10.52 (0x0A34) | Recovered No. | V/F SVC FVC PMVF PMSVC PMFVC Indicate the times of already performed auto fault recovery, read-only. | 0 | READ |
| F10.53 (0x0A35) | OV Auto-recovery No. | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Reserved; Tens-bit: Overvoltage auto-recovery times 0: OFF; 1~F: ON | 0000 (0000~00F0) | STOP |
| F10.54 (0x0A36) | Operation Pause No. | V/F SVC FVC PMVF PMSVC PMFVC Record the times when operation set on F10.10 is paused, it is a read-only parameter, and will be cleared by re-power-up. | 0 (0~10) | READ |
| F10.55 (0x0A37) | Motor OL Model | V/F SVC FVC PMVF PMSVC PMFVC 0: Common motor 1: Variable frequency motor(50Hz); 2: Variable frequency motor(60Hz); 3: Motor without cooling fan | 0 (0~3) | RUN |
| F10.56 (0x0A38) | Motor Insulation Class | V/F SVC FVC PMVF PMSVC PMFVC 0: Insulation class A; 1: Insulation class E 2: Insulation class B; 3: Insulation class F 4: Insulation class H; 5: Special class S | 3 (0~5) | STOP |
| F10.57 (0x0A39) | Motor Work Pattern | V/F SVC FVC PMVF PMSVC PMFVC 0-1: S1 pattern(continuous operation); 2: S2 pattern; 3-9: S3-S9 | 0 (0~9) | STOP |
| F10.58 (0x0A3A) | Motor OL Threshold | V/F SVC FVC PMVF PMSVC PMFVC Set the motor overload threshold. Record the overload quantity when actual current is greater than the value here. | 105.0% (0.0%~130.0%) | STOP |
| F10.59 (0x0A3B) | Motor OL Current Coefficient | V/F SVC FVC PMVF PMSVC PMFVC Motor overload current = actual current * motor overload current coefficient | 100.0% (0.0%~250.0%) | STOP |

4.14 F11: Panel Parameters

F11.0x: Key Operation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---|---|---------------------|----------|
| F11.00 (0x0B00) | Key Lock | V/F SVC FVC PMVF PMSVC PMFVC 0: No lock; 1: Lock parameter modified via panel; 2: Lock functional parameters and non-start/stop key; 3: Lock all the functional parameters and keys | 0 (0~3) | RUN |
| F11.01 (0x0B01) | Key Lock Password | V/F SVC FVC PMVF PMSVC PMFVC Set the key lock password. | 0 (0~65535) | RUN |
| F11.02 (0x0B02) | Multi-Function Key | V/F SVC FVC PMVF PMSVC PMFVC 0: Invalid; 1: REV; 2: FWD jogging; 3: REV jogging; 4: Switch command source between the panel and terminal; 5: Switch command source between the panel and communication; 6: Switch command source between terminal and communication; 7: Switch command source among panel, terminal and communication cyclically | 0 (0~7) | STOP |
| F11.03 (0x0B03) | STOP Key | V/F SVC FVC PMVF PMSVC PMFVC 0: Non-panel control invalid; 1: Non-panel stop works according to the stop mode; 2: Non-panel stop works according to the free stop mode | 0 (0~2) | STOP |
| F11.04 (0x0B04) | UP/DW(Knob) of Status Interface | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: UP/DW key for modification 0: Invalid; 1: Valid to modify F01.09[Panel Giving Frequency]; 2: Valid to modify F13.01[Panel Giving PID]; 3: Valid to modify the function code via panel UP/DW key Tens-bit: Power loss protection of data 0: OFF; 1: ON Hundreds-bit: Modification condition 0: Modifiable during operation and stop; 1: Modifiable during operation, kept during stop; 2: Modifiable during operation, cleared after shutdown | 0011 (0000~0213) | STOP |
| F11.05 (0x0B05) | UP/DW Key for Parameter Code Quick Change | V/F SVC FVC PMVF PMSVC PMFVC Ones- and tens-bit: Set 00~99 to yy in Fxx.yy Hundreds- and thousands-bit: set 00~15 to xx in Fxx.yy | 0109 (0000~2999) | RUN |

| | | | | |
|--------------------|-------------|---|---------------------|------|
| F11.06 (0x0B06) | Command Key | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Ones-bits: Internal/external command keys (RUN, STOP and RESET)</p> <p>0: External first, when external keys are valid, internal are invalid;</p> <p>1: Internal first, when internal keys are valid, external are invalid;</p> <p>2: When both internal and external are valid, STOP/RESET are prior; and when both forward and reverse are valid, they are used as stop.</p> <p>Tens-bit: Reserved</p> <p>Hundreds-bit: Reserved</p> <p>Thousands-bit: Reserved</p> | 0000 (0000-2122) | STOP |
|--------------------|-------------|---|---------------------|------|

F11.Ix: Cyclic Monitoring of Status Interface

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--|--|---------------------|----------|
| F11.10 (0x0B0A) | Left/Right Key on Status Interface | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Ones-bit: Left shift key to adjust the first row of monitoring</p> <p>0: Invalid; 1: Valid</p> <p>Tens-bit: Right shift key to adjust the second row of monitoring</p> <p>0: Invalid; 1: Valid</p> <p>When the Left/Right shift key are invalid, the monitor display value is shown as parameter 1 after re-powering up.</p> | 0011 (0000-0011) | STOP |
| F11.11 (0x0B0B) | 1st Row Parameter 1 for Cyclic Display | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Ones- and tens-bit: Set monitor parameter 00-63 to yy in Cxx.yy.</p> <p>Hundreds and thousands-bit: Set monitor parameter 00-07 to xx in Cxx.yy.</p> | 0000 (0000-0763) | RUN |
| F11.12 (0x0B0C) | 1st Row Parameter 2 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0001 (0000-0763) | RUN |
| F11.13 (0x0B0D) | 1st Row Parameter 3 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0002 (0000-0763) | RUN |
| F11.14 (0x0B0E) | 1st Row Parameter 4 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0011 (0000-0763) | RUN |
| F11.15 (0x0B0F) | 2nd Row Parameter 1 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0002 (0000-0763) | RUN |
| F11.16 (0x0B10) | 2nd Row Parameter 2 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0004 (0000-0763) | RUN |
| F11.17 (0x0B11) | 2nd Row Parameter 3 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0010 (0000-0763) | RUN |
| F11.18 (0x0B12) | 2nd Row Parameter 4 for Cyclic Display | V/F SVC FVC PMVF PMSVC PMFVC Same | 0012 (0000-0763) | RUN |

F11.2x: Monitoring Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------------|---|---------------------------|----------|
| F11.20 (0x0B14) | Panel Display Item | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Ones-bit: Output frequency display 0: Target frequency; 1: Operating frequency >=2: Target frequency, filter depth becomes larger with this value Tens-bit: Reserved Hundreds-bit: Power dimension 0: In percentage (%); 1: In kilowatt(kW) Thousands-bit: Reserved | 0x0002 (0x0000~0x111F) | RUN |
| F11.21 (0x0B15) | Speed Display Factor | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Adjust the display of C00.05 speed. | 100.0% (0.0%~500.0%) | RUN |
| F11.22 (0x0B16) | Power Display Factor | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Adjust the display of C00.10 power. | 100.0% (0.0%~500.0%) | RUN |
| F11.23 (0x0B17) | Monitoring Parameter Group Display | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Ones-bit: Reserved Tens-bit: C05 display 0: Auto switching with control modes; 1: V/F mode related parameters; 2: V/C mode related parameters Hundreds-bit: C00.40~C00.63 display 0: OFF; 1: ON Thousands-bit: Communication fault code switching 0: OFF; 1: ON, fault code is the same as AC300 during 485 communication. 2: ON, fault code is the same as AC70 during 485 communication. | 0x0000 (0x0000~0xFFFF) | RUN |
| F11.24 (0x0B18) | Monitoring Parameter Filter | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Ones-bit: Output current display with filtering 0~F: The larger the value, the deeper the filtering | 0x0002 (0x0000~0x000F) | RUN |
| F11.25 (0x0B19) | Motor Auto-Tuning Display | <u>V/F</u> SVC FVC PMVF PMSVC PMFVC Set the auto-tuning process of the motor on the display. 0: OFF; 1: ON | 0 (0~1) | STOP |
| F11.27 (0x0B1B) | Fault Auto-Recovery Display | <u>V/F</u> SVC FVC PMVF PMSVC <u>PMFVC</u> Ones-bit: Fault display during auto-recovery 0: OFF; 1: ON | 0x0001 (0x0000~0x0001) | RUN |

F11.3x: Special Functions of Panel

| Code (Address) | Name | Content | Default (Range) | Property |
|---------------------------|--|---|------------------------|----------|
| F11.31 (0x0B1F) RUN | Potentiometer Giving Voltage Lower Limit | <u>V/F</u> SVC FVC PMVF PMSVC <u>PMFVC</u> Set the lower limit voltage via the panel potentiometer (valid on the optional external single-row panel). | 0.50V (0.00V~3.00V) | RUN |

| | | | | |
|----------------------------|---|---|----------------------------|------|
| F11.32 (0x0B20) RUN | Potentiometer Giving Voltage Lower Limit Percentage | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the corresponding value of the lower limit set from the panel potentiometer (valid on the optional external single-row panel). | 0.00% (0.00%~100.00%) | RUN |
| F11.33 (0x0B21) RUN | Potentiometer Giving Upper Voltage Limit | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the upper limit voltage via the panel potentiometer(valid on the optional external single-row panel). | 2.80V (0.00V~3.00V) | RUN |
| F11.34 (0x0B22) RUN | Potentiometer Giving Upper Voltage Limit Percentage | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the corresponding percentage of the upper limit set via the panel potentiometer (valid on the optional external single-row panel). | 100.00% (0.00%~100.00%) | RUN |
| F11.35 (0x0B23) STOP | Panel Potentiometer | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the panel potentiometer source. 0: Reserved; 1: Potentiometer of the external panel | 1 (0~1) | STOP |

4.15 F12: Communication Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------|--|--------------------------|----------|
| F12.00 (0x0C00) | Master/Slave | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Slave; 1: Master | 0 (0~1) | STOP |
| F12.01 (0x0C01) | Modbus Address | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set different values for different slaves. | 1 (1~247) | STOP |
| F12.02 (0x0C02) | Baud Rate | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: 1200bps; 1: 2400bps; 2: 4800bps; 3: 9600bps; 4: 9200bps; 5: 38400bps; 6: 57600bps | 3 (0~6) | STOP |
| F12.03 (0x0C03) | Modbus Data Format | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0:(N, 8, 1) no parity, data bit: 8, stop bit: 1 1:(E, 8, 1) even parity, data bit: 8, stop bit: 1 2:(O, 8, 1) odd parity, data bit:8, stop bit:1 3:(N, 8, 2) no parity, data bit: 8, stop bit: 2 4:(E, 8, 2) even parity, data bit: 8, stop bit: 2 5:(O, 8, 2) odd parity, data bit: 8, stop bit: 2 | 0 (0~5) | STOP |
| F12.04 (0x0C04) | Modbus Response Mode | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Response to write operation; 1: No response to write operation | 0 (0~1) | RUN |
| F12.05 (0x0C05) | Modbus Response Delay | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the Modbus communication response delay | 0ms (0ms~500ms) | RUN |
| F12.06 (0x0C06) | Modbus Failure Timeout | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the Modbus communication failure timeout | 1.0s (0.1s~100.0s) | RUN |
| F12.07 (0x0C07) | Communication Disconnection | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Timeout detection off; 1: Report fault and free stop; 2: Report warning and continue operation; 3: Force stop | 0 (0~3) | RUN |
| F12.08 (0x0C08) | Data Bias(0x3000) | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the bias to correct communication data to 0x3000. | 0.00 (-100.00~100.00) | RUN |

| | | | | |
|--------------------|-------------------|---|-------------------------|-----|
| F12.09 (0x0C09) | Data Gain(0x3000) | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set to perform linear correction on communication data to 0x3000. | 100.0% (0.0%-500.0%) | RUN |
|--------------------|-------------------|---|-------------------------|-----|

F12.0x: Modbus slave parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------|--|--------------------------|----------|
| F12.00 (0x0C00) | Master/Slave | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Slave; 1: Master | 0 (0-1) | STOP |
| F12.01 (0x0C01) | Modbus Address | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set different values for different slaves. | 1 (1-247) | STOP |
| F12.02 (0x0C02) | Baud Rate | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: 1200bps; 1: 2400bps; 2: 4800bps; 3: 9600bps; 4: 9200bps; 5: 38400bps; 6: 57600bps | 3 (0-6) | STOP |
| F12.03 (0x0C03) | Modbus Data Format | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0:(N, 8, 1) no parity, data bit: 8, stop bit: 1 1:(E, 8, 1) even parity, data bit: 8, stop bit: 1 2:(O, 8, 1) odd parity, data bit:8, stop bit:1 3:(N, 8, 2) no parity, data bit: 8, stop bit: 2 4:(E, 8, 2) even parity, data bit: 8, stop bit: 2 5:(O, 8, 2) odd parity, data bit: 8, stop bit: 2 | 0 (0-5) | STOP |
| F12.04 (0x0C04) | Modbus Response Mode | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Response to write operation; 1: No response to write operation | 0 (0-1) | RUN |
| F12.05 (0x0C05) | Modbus Response Delay | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the interval between the completion of receiving data and replying to the master with answer data. | 0ms (0ms-5000ms) | RUN |
| F12.06 (0x0C06) | Modbus Failure Timeout | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> The time between two communications to detect a communication disconnection. | 1.0s (0.1s-100.0s) | RUN |
| F12.07 (0x0C07) | Communication Disconnection | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Timeout detection off; 1: Report fault and free stop; 2: Report warning and continue operation; 3: Force stop | 0 (0-3) | RUN |
| F12.08 (0x0C08) | Data Bias(0x3000) | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the bias value for the communication giving frequency(100.00 corresponds to 100.00Hz). | 0.00 (-100.00-100.00) | RUN |
| F12.09 (0x0C09) | Data Gain(0x3000) | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the gain for the communication giving frequency. Given frequency = actual communication giving value x gain + bias. | 100.0% (0.0%-500.0%) | RUN |

F12.1x: Modbus Master Parameters

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------------|--|---------------------------|----------|
| F12.10 (0x0C0A) | Master Sending Parameter Cycle | V/F SVC FVC PMVF PMSVC PMFVC Ones, tens, hundreds, and thousands all can be selected with: 0: Invalid; 1: Operation command; 2: Given frequency; 3: Output frequency 4: Upper limit frequency; 5: Given torque 6: Output torque; 7: Reserved 8: Reserved; 9: PID setting A: PID feedback; B: Reserved C: Active current component | 0x0031 (0x0000~0xCCCC) | RUN |
| F12.11 (0x0C0B) | User-Defined Frequency Address | V/F SVC FVC PMVF PMSVC PMFVC Customize an address to give the frequency. | 0x0000 (0x0000~0xFFFF) | RUN |
| F12.12 (0x0C0C) | User-Defined Command Address | V/F SVC FVC PMVF PMSVC PMFVC Customize an address to give the command. | 0x0000 (0x0000~0xFFFF) | RUN |
| F12.13 (0x0C0D) | FWD Command Value | V/F SVC FVC PMVF PMSVC PMFVC Set command value for forward running. | 0x0001 (0x0000~0xFFFF) | RUN |
| F12.14 (0x0C0E) | REV Command Value | V/F SVC FVC PMVF PMSVC PMFVC Set command value for reverse running. | 0x0002 (0x0000~0xFFFF) | RUN |
| F12.15 (0x0C0F) | Stop Command Value | V/F SVC FVC PMVF PMSVC PMFVC Set the command value for stop. | 0x0005 (0x0000~0xFFFF) | RUN |
| F12.16 (0x0C10) | Reset Command Value | V/F SVC FVC PMVF PMSVC PMFVC Set the command value for reset. | 0x0007 (0x0000~0xFFFF) | RUN |
| F12.19 (0x0C13) | Master Sending Item | V/F SVC FVC PMVF PMSVC PMFVC Master Sending Item 0: Send operation command; 1: Send operation status | 0 (0~1) | RUN |

F12.2x: Modbus Special Functions

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------|---|-----------------|----------|
| F12.20 (0x0C14) | RJ45 Communication Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Dual-line panel communication; 1: Modbus slave (set related parameters via F12.2x); 2: Modbus master (set sending parameters via F12.1x); 3: VEICHI-customized Note: T3-45kW and above models only support two-line panel communication. | 0 (0~3) | STOP |
| F12.21 (0x0C15) | RJ45 Communication Address | V/F SVC FVC PMVF PMSVC PMFVC Set the slave addresses when RJ45 port is for Modbus communication. | 1 (1~247) | STOP |
| F12.22 (0x0C16) | RJ45 Baud Rate | V/F SVC FVC PMVF PMSVC PMFVC Set the baud rate when RJ45 port is for Modbus communication. 0: 1200bps; 1: 2400bps; 2: 4800bps; 3: 9600bps; 4: 19200bps; 5: 38400bps | 3 (0~5) | STOP |

| | | | | |
|--------------------|---------------------|---|-----------------------|------|
| F12.23 (0x0C17) | RJ45 Data Format | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the data format when RJ45 port is for Modbus communication.</p> <p>0:(N, 8, 1) no parity, data bit: 8, stop bit: 1 1:(E, 8, 1) even parity, data bit: 8, stop bit: 1 2:(O, 8, 1) odd parity, data bit:8, stop bit:1 3:(N, 8, 2) no parity, data bit: 8, stop bit: 2 4:(E, 8, 2) even parity, data bit: 8, stop bit: 2 5:(O, 8, 2) odd parity, data bit: 8, stop bit: 2</p> | 0 (0-5) | STOP |
| F12.24 (0x0C18) | RJ45 Response Mode | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the transmission response when RJ45 port is for Modbus communication.</p> <p>0: Response to write operation; 1: No response to write operation</p> | 0 (0-1) | RUN |
| F12.25 (0x0C19) | RJ45 Response Delay | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the communication response delay when RJ45 port is for Modbus communication.</p> | 0ms (0ms-5000ms) | RUN |
| F12.26 (0x0C1A) | RJ45 Timeout | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the timeout value when RJ45 port is for Modbus communication.</p> | 1.0s (0.1s-100.0s) | RUN |
| F12.27 (0x0C1B) | RJ45 Disconnection | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the mode when RJ45 interface for Modbus communication is disconnected.</p> <p>0: Timeout detection off; 1: Report fault and free stop; 2: Report warning and continue operation; 3: Force stop</p> | 0 (0-3) | RUN |

F12.3x: PROFIBUS-DP

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------------|--|-----------------|----------|
| F12.30 (0x0C1E) | DP Address | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the communication addresses.</p> | 1 (1-247) | RUN |
| F12.32 (0x0C20) | DP Master-Slave Failure Mode | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>DP master-slave communication fault selection</p> <p>0: Timeout detection off; 1: Report alarm and free stop; 2: Report warning and continue operation</p> | 0 (0-2) | STOP |

Note: Expansion boards are not allowed to be plugged or unplugged with power-on.

F12.4x: CANopen

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------|--|-----------------|----------|
| F12.40 (0x0C28) | CANopen Mode | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>0: Slave; 1: VEICHI-customized master</p> | 1 (0-1) | RUN |
| F12.41 (0x0C29) | Communication Address | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>Set the address of the slave.</p> | 1 (1-65535) | RUN |
| F12.42 (0x0C2A) | Baud Rate | <p>V/F SVC FVC PMVF PMSVC PMFVC</p> <p>0: 20kbps; 1: 50kbps; 2: 100kbps; 3: 125kbps; 4: 250kbps; 5: 500kbps; 6: 1Mbps</p> | 3 (0-6) | RUN |

| | | | | |
|--------------------|---------------------------|--|------------|-----|
| F12.43 (0x0C2B) | Master-Slave Failure Mode | V/F SVC FVC PMVF PMSVC PMFVC CAN master-slave communication fault selection 0: Timeout detection off; 1: Report alarm and free stop; 2: Report warning and continue the operation. | 0 (0~2) | RUN |
|--------------------|---------------------------|--|------------|-----|

Note: Expansion boards are not allowed to be plugged or unplugged with power-on.

F12.5x~F12.6x: Expansion Communication of EX_A and EX_B

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------------------------|---|---------------------|----------|
| F12.50 (0x0C32) | Expansion Communication Disconnection | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: EX_A port disconnection mode 0: Detection off; 1: Report alarm and continue operation; 2: Report warning and continue operation Tens-bit: EX_B port disconnection mode 0: Detection off; 1: Report alarm and continue operation; 2: Report warning and continue operation | 0000 (0000~0022) | RUN |
| F12.51 (0x0C33) | EX_A Parameter Update | V/F SVC FVC PMVF PMSVC PMFVC 0: No update; 1: Initial values updated on power-up; 2: EX_A parameters restored to initial values | 0 (0~2) | RUN |
| F12.52 (0x0C34) | EX_B Parameter Update | V/F SVC FVC PMVF PMSVC PMFVC 0: No update; 1: Initial values updated on power up; 2: EX_B parameters restored initial values | 0 (0~2) | RUN |
| F12.53 (0x0C35) | EX_A Monitor Frame Address Group 1 | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit and tens-bit: Address lower 8 bits within 00~63 Hundreds-bit and thousands-bit: Address higher 8 bits within 00~07 | 0001 (0000~0763) | RUN |
| F12.54 (0x0C36) | EX_A Monitor Frame Address Group 2 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0002 (0000~0763) | RUN |
| F12.55 (0x0C37) | EX_A Monitor Frame Address Group 3 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0007 (0000~0763) | RUN |
| F12.56 (0x0C38) | EX_A Monitor Frame Address Group 4 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0011 (0000~0763) | RUN |
| F12.57 (0x0C39) | EX_B Monitor Frame Address Group 1 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0001 (0000~0763) | RUN |
| F12.58 (0x0C3A) | EX_B Monitor Frame Address Group 2 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0002 (0000~0763) | RUN |
| F12.59 (0x0C3B) | EX_B Monitor Frame Address Group 3 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0007 (0000~0763) | RUN |
| F12.60 (0x0C3C) | EX_B Monitor Frame Address Group 4 | V/F SVC FVC PMVF PMSVC PMFVC Same | 0011 (0000~0763) | RUN |

Note: Expansion boards are not allowed to be plugged or unplugged with power-on.

4.16 F13: PID Control

F13.00~F13.06: PID Setting and Feedback

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------------|---|---------------------------|----------|
| F13.00 (0x0D00) | PID Controller Signal Source | V/F SVC FVC PMVF PMSVC PMFVC 0: Via panel; 1: Via panel potentiometer 2: Via analog current/voltage AI1; 3: Via analog current/voltage AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485; 7: Via optional boards; 8: Via terminals; 9: Via active current given via communication | 0 (0-9) | RUN |
| F13.01 (0x0D01) | Panel Giving PID Setting/Feedback | V/F SVC FVC PMVF PMSVC PMFVC This parameter is valid when F13.00 or F13.03 is set to [PID Setting] and [PID Feedback] via the panel. | 50.0% (0.0%~100.0%) | RUN |
| F13.02 (0x0D02) | PID Change Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the time required when PID increases from 0.0% to 100.0%. | 1.00s (0.00s~60.00s) | RUN |
| F13.03 (0x0D03) | PID Feedback Source | V/F SVC FVC PMVF PMSVC PMFVC 0: Via panel; 1: Via panel potentiometer; 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485; 7: Via optional boards; 8: Via terminals; 9: Via local active current | 2 (0-9) | RUN |
| F13.04 (0x0D04) | Feedback Low-Pass Filter Time | V/F SVC FVC PMVF PMSVC PMFVC The longer the filter time, the greater the anti-interference effect, but the response becomes slower. | 0.010s (0.000s~6.000s) | RUN |
| F13.05 (0x0D05) | Feedback Signal Gain | V/F SVC FVC PMVF PMSVC PMFVC Set for linear proportional regulation of the feedback input signal. | 1.00 (0.00~10.00) | RUN |
| F13.06 (0x0D06) | Feedback Signal Range | V/F SVC FVC PMVF PMSVC PMFVC The PID feedback signal range is dimensionless units which are used to regulate PID feedback and display. | 100.0 (0.0~100.0) | RUN |

F13.07~F13.24: PID Regulation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------|--|-------------------------|----------|
| F13.07 (0x0D07) | PID Control | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Feedback characteristics 0: Positive; 1: Negative Thousands-bit: Differential regulation 0: Differentiate the deviation; 1: Differentiate the feedback | 0100 (0000~1111) | RUN |
| F13.08 (0x0D08) | PID Preset Output | V/F SVC FVC PMVF PMSVC PMFVC When PID operation is initiated, output as the pre-settings. | 100.0% (0.0%~100.0%) | RUN |
| F13.09 (0x0D09) | PID Preset Output Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the time for the PID preset output, and performs as the normal PID setting after it is finished. | 0.0s (0.0s~6500.0s) | RUN |

| | | | | |
|--------------------|---------------------------------|---|---------------------------|-----|
| F13.10 (0x0D0A) | PID Deviation Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the maximum deviation of PID feedback from PID setting. | 0.0% (0.0%~100.0%) | RUN |
| F13.11 (0x0D0B) | Proportional Gain P1 | V/F SVC FVC PMVF PMSVC PMFVC Set the proportional gain of PID parameter group 1. | 0.100 (0.000~4.000) | RUN |
| F13.12 (0x0D0C) | Integral Time I1 | V/F SVC FVC PMVF PMSVC PMFVC Set the integral time of PID parameter group 1. | 1.0s (0.0s~600.0s) | RUN |
| F13.13 (0x0D0D) | Differential Time D1 | V/F SVC FVC PMVF PMSVC PMFVC Set differential time of PID parameter group 1. | 0.000s (0.000s~6.000s) | RUN |
| F13.14 (0x0D0E) | Proportional Gain P2 | V/F SVC FVC PMVF PMSVC PMFVC Set the proportional gain of PID parameter group 2. | 0.100 (0.000~4.000) | RUN |
| F13.15 (0x0D0F) | Integral Time I2 | V/F SVC FVC PMVF PMSVC PMFVC Set the integral time of PID parameter group 2. | 1.0s (0.0s~600.0s) | RUN |
| F13.16 (0x0D10) | Differential Time D2 | V/F SVC FVC PMVF PMSVC PMFVC Set differential time of PID parameter group 2. | 0.000s (0.000s~6.000s) | RUN |
| F13.17 (0x0D11) | PID Switching | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: Switch via DI terminals; 2: Switch according to deviation | 0 (0~2) | RUN |
| F13.18 (0x0D12) | Switching Deviation Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Gain 1 parameter is used when the PID deviation is lower than this value. | 20.0% (0.0%~100.0%) | RUN |
| F13.19 (0x0D13) | Switching Deviation Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Gain 2 parameter is used when the PID deviation is greater than this value. | 80.0% (0.0%~100.0%) | RUN |
| F13.21 (0x0D15) | Differentiation Range | V/F SVC FVC PMVF PMSVC PMFVC Set the differential range. | 5.0% (0.0%~100.0%) | RUN |
| F13.22 (0x0D16) | PID Output Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC Set PID output upper limit. | 100.0% (0.0%~100.0%) | RUN |
| F13.23 (0x0D17) | PID Output Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC Set PID output lower limit. | 0.0% (-100.0%~F13.22) | RUN |
| F13.24 (0x0D18) | PID Output Filter Time | V/F SVC FVC PMVF PMSVC PMFVC Set PID output filter time. | 0.000s (0.000s~6.000s) | RUN |

F13.25~F13.28: PID Feedback Disconnection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------------------------------|--|-------------------------|----------|
| F13.25 (0x0D19) | Disconnection Mode | V/F SVC FVC PMVF PMSVC PMFVC 0: Continue PID operation without reporting fault; 1: Stop and report fault; 2: Continue PID operation, and report alarm; 3: Run at current frequency, and report alarm | 0 (0~3) | STOP |
| F13.26 (0x0D1A) | Disconnection Detection Duration | V/F SVC FVC PMVF PMSVC PMFVC Set the PID feedback disconnection detection duration. | 1.0s (0.0s~120.0s) | RUN |
| F13.27 (0x0D1B) | Disconnection Alarm Upper Limit | V/F SVC FVC PMVF PMSVC PMFVC If the feedback signal exceeds this value and continues for F13.26, the sensor is considered disconnected. | 100.0% (0.0%~100.0%) | RUN |
| F13.28 (0x0D1C) | Disconnection Alarm Lower Limit | V/F SVC FVC PMVF PMSVC PMFVC If the feedback signal exceeds this value and continues for F13.26, the sensor is considered disconnected. | 0.0% (0.0%~100.0%) | RUN |

F13.29~F13.33: PID Sleep

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|------------------|---|--|----------|
| F13.29 (0x0D1D) | Sleep | V/F SVC FVC PMVF PMSVC PMFVC Set sleep function on or off; 0: OFF; 1: ON | 0 (0~1) | RUN |
| F13.30 (0x0D1E) | Sleep Frequency | V/F SVC FVC PMVF PMSVC PMFVC When the sleep function is valid, the PID output frequency is lower than [F13.30] and continues for F13.31 [Sleep Delay], then sleep function works. | 10.00Hz (0.00Hz~ Max. frequency) | RUN |
| F13.31 (0x0D1F) | Sleep Delay | V/F SVC FVC PMVF PMSVC PMFVC When the sleep function is valid, the PID output frequency is lower than [F13.30] and continues for F13.31 [Sleep Delay], then sleep function works. | 60.0s (0.0s~3600.0s) | RUN |
| F13.32 (0x0D20) | Wakeup Deviation | V/F SVC FVC PMVF PMSVC PMFVC When PID feedback is smaller/greater than (positive characteristic/negative characteristic) PID setting minus/plus (positive characteristic/negative characteristic) F13.32 [Wake-up Deviation] and continues for F13.33 [Wake-up Delay], the drive exits from sleep status and start the normal operation. | 5.0% (0.0%~50.0%) | RUN |
| F13.33 (0x0D21) | Wakeup Delay | V/F SVC FVC PMVF PMSVC PMFVC When PID feedback is smaller/greater than (positive characteristic/negative characteristic) PID setting minus/plus (positive characteristic/negative characteristic) F13.32 [Wake-up Deviation] and continues for F13.33 [Wake-up Delay], the drive exits from sleep status and start the normal operation. | 1.0s (0.0s~60.0s) | RUN |

4.17 F14: Multi-seg Speed and Simple PLC**F14.00~F14.14: Multi-seg Speed Frequency**

| Code (Address) | Name | Content | Default (Range) | Property |
|-----------------|-------------------|---|--|----------|
| F14.00 (0x0E00) | PLC Multi-speed 1 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 1 with PLC. | 10.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.01 (0x0E01) | PLC Multi-speed 2 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 2 with PLC. | 20.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.02 (0x0E02) | PLC Multi-speed 3 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 3 with PLC. | 30.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.03 (0x0E03) | PLC Multi-speed 4 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 4 with PLC. | 40.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.04 (0x0E04) | PLC Multi-speed 5 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 5 with PLC. | 50.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.05 (0x0E05) | PLC Multi-speed 6 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 6 with PLC. | 40.00Hz (0.00Hz~ Max. frequency) | RUN |

| | | | | |
|--------------------|--------------------|---|--|-----|
| F14.06 (0x0E06) | PLC Multi-speed 7 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 7 with PLC. | 30.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.07 (0x0E07) | PLC Multi-speed 8 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 8 with PLC. | 20.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.08 (0x0E08) | PLC Multi-speed 9 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 9 with PLC. | 10.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.09 (0x0E09) | PLC Multi-speed 10 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 10 with PLC. | 20.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.10 (0x0E0A) | PLC Multi-speed 11 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 11 with PLC. | 30.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.11 (0x0E0B) | PLC Multi-speed 12 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 12 with PLC. | 40.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.12 (0x0E0C) | PLC Multi-speed 13 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 13 with PLC. | 50.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.13 (0x0E0D) | PLC Multi-speed 14 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 14 with PLC. | 40.00Hz (0.00Hz~ Max. frequency) | RUN |
| F14.14 (0x0E0E) | PLC Multi-speed 15 | V/F SVC FVC PMVF PMSVC PMFVC Set multi-seg speed 15 with PLC. | 30.00Hz (0.00Hz~ Max. frequency) | RUN |

F14.15: PLC Operation Mode

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|----------|---|---------------------|----------|
| F14.15 (0x0E0F) | PLC mode | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Cycle mode 0: Stop after single cycle; 1: Run in continuous cycles; 2: Keep the final value after single cycle Tens-bit: Timing unit 0: Second(s); 1: Minute(min); 2: Hour(h) Tens-bit: Power loss protection 0: OFF; 1: ON Hundreds-bit: Start mode 0: Restart from the first segment; 1: Restart from the segment of shutdown; 2: Continue operation for the remaining of the shutdown segment | 0000 (0000~2122) | RUN |

F14.16~F14.30 : PLC Runtime

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------|--|---|----------|
| F14.16 (0x0E10) | Segment 1 Runtime | V/F SVC FVC PMVF PMSVC PMFVC Set the segment 1 runtime by PLC. | 10.0 (s/m/h) (0.0 (s/m/h)~ 6500.0(s/m/h)) | RUN |

| | | | | |
|--------------------|--------------------|---|---|-----|
| F14.17 (0x0E11) | Segment 2 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 2 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.18 (0x0E12) | Segment 3 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 3 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.19 (0x0E13) | Segment 4 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 4 runtime by PLC. | 10.0 (s/m/h) (0.0 (s/m/h)~ 6500.0(s/m/h)) | RUN |
| F14.20 (0x0E14) | Segment 5 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 5 runtime by PLC. | 10.0 (s/m/h) (0.0 (s/m/h)~ 6500.0(s/m/h)) | RUN |
| F14.21 (0x0E15) | Segment 6 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 6 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.22 (0x0E16) | Segment 7 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 7 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.23 (0x0E17) | Segment 8 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 8 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.24 (0x0E18) | Segment 9 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 9 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.25 (0x0E19) | Segment 10 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 10 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.26 (0x0E1A) | Segment 11 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 11 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.27 (0x0E1B) | Segment 12 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 12 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~6500.0(s/m/ h)) | RUN |
| F14.28 (0x0E1C) | Segment 13 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 13 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |
| F14.29 (0x0E1D) | Segment 14 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 14 runtime by PLC. | 10.0(s/m/h) (0.0 (s/m/h)~ 6500.0(s/m/h)) | RUN |
| F14.30 (0x0E1E) | Segment 15 Runtime | \sqrt{F} SVC FVC PMVF PMSVC PMFVC Set the segment 15 runtime by PLC. | 10.0(s/m/h)(0.0(s/ m/h)~ 6500.0(s/m/h)) | RUN |

F14.31~F14.45 : PLC Operation Direction and Time

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---------------------------------------|--|---------------------|----------|
| F14.31 (0x0E1F) | Segment 1 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Ones-bit: Direction of the current segment (compared with operation command) 0: Same direction 1: Reverse direction Tens-bit: ACC/DEC. time 0: Time 1; 1: Time 2; 2: Time 3; 3: Time 4; | 0000 (0000~0031) | RUN |
| F14.32 (0x0E20) | Segment 2 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.33 (0x0E21) | Segment 3 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.34 (0x0E22) | Segment 4 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.35 (0x0E23) | Segment 5 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.36 (0x0E24) | Segment 6 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.37 (0x0E25) | Segment 7 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.38 (0x0E26) | Segment 8 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.39 (0x0E27) | Segment 9 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.40 (0x0E28) | Segment 10 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.41 (0x0E29) | Segment 11 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.42 (0x0E2A) | Segment 12 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.43 (0x0E2B) | Segment 13 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.44 (0x02C) | Segment 14 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |
| F14.45 (0x0E2D) | Segment 15 Direction and ACC/DEC Time | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Setting is the same as F14.31. | 0000 (0000~0031) | RUN |

4.18 F15: Reserved**4.19 F16: Tension Control****F16.01~F16.02: Tension Mode**

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------|--|-----------------------|----------|
| F16.01 (0x5001) | Winding Mode | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> 0: Winding; 1: Unwinding; 2: Terminal selection | 0 (0~2) | RUN |
| F16.02 (0x5002) | Mechanical Transmission Ratio | <u>V/F</u> <u>SVC</u> <u>FVC</u> <u>PMVF</u> <u>PMSVC</u> <u>PMFVC</u> Set the transmission ratio between the motor and the reel. | 1.00 (0.01~300.00) | RUN |

F16.03~F16.09: Tension Setting

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------|--|-----------------------------|----------|
| F16.03 (0x5003) | Tension Source | √F SVC FVC PMVF PMSVC PMFVC Ones-bit: Source A Tens-bit: Source B 0: Via the panel keys; 1: Via panel potentiometer (on optional external single-row panels) 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485 (0x300B) Hundreds-bit: Decimal place 0: 0.1 unit 1: 1 unit 2: 10 unit | 0x0000 (0x0000~0x0266) | STOP |
| F16.04 (0x5004) | Panel Giving Tension | √F SVC FVC PMVF PMSVC PMFVC Set and modify tension via the panel. Motor power above 37kW has no decimal points. | 0N (0N~ Max. tension) | STOP |
| F16.05 (0x5005) | Max. tension | √F SVC FVC PMVF PMSVC PMFVC Set the maximum tension limit for all channels. Motor power above 37kW has no decimal points. | 1000N (0N~ 6000N) | STOP |
| F16.06 (0x5006) | Taper tension factor | √F SVC FVC PMVF PMSVC PMFVC Set the taper tension factor. | 0.0% (0.0%~100.0%) | STOP |
| F16.07 (0x5007) | Taper Compensation | √F SVC FVC PMVF PMSVC PMFVC Set the taper compensation correction factor. | 0mm (0mm~10000mm) | STOP |
| F16.08 (0x5008) | Zero-speed Threshold | √F SVC FVC PMVF PMSVC PMFVC Set zero-speed threshold value. | 1.00Hz (0.00Hz~50.00Hz) | RUN |
| F16.09 (0x5009) | Zero-speed Tension Gain | √F SVC FVC PMVF PMSVC PMFVC Set the tension gain in zero speed mode. | 100.0% (0.0%~500.0%) | RUN |

F16.12~F16.16: Friction Compensation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--|--|---------------------------------------|----------|
| F16.12 (0x500C) | Static Friction Compensation Factor | √F SVC FVC PMVF PMSVC PMFVC Set the static friction compensation factor. | 0.0% (0.0%~50.0%) | RUN |
| F16.13 (0x500D) | Static Friction Compensation Delay | √F SVC FVC PMVF PMSVC PMFVC Set the static friction compensation delay time. | 2.0s (0.0s~60.0s) | RUN |
| F16.14 (0x500E) | Static Friction Compensation Cut-off Frequency | √F SVC FVC PMVF PMSVC PMFVC Set the static friction compensation cut-off frequency. | 2.00Hz (0.00Hz~ Max. frequency) | RUN |
| F16.15 (0x500F) | Sliding Friction Compensation Factor | √F SVC FVC PMVF PMSVC PMFVC Set the sliding friction compensation factor. | 0.0% (0.0%~50.0%) | RUN |
| F16.16 (0x5010) | Sliding Friction Compensation Cut-off Factor | √F SVC FVC PMVF PMSVC PMFVC Set the sliding friction compensation cut-off factor | 0.0% (0.0%~50.0%) | RUN |

F16.30~F16.32: Material Fracture Detection

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------------|--|---------------------------|----------|
| F16.30 (0x501E) | Material Fracture Detection | V/F SVC FVC PMVF PMSVC PMFVC Ones-bit: Detection signal input source 0: Detection OFF; 1: Via keyboard potentiometer 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; Tens-bit: Material fracture mode 0: Report warning and continue the operation; 1: Report fault and stop | 0x0000 (0x0000~0x0015) | RUN |
| F16.31 (0x501F) | Material Fracture Threshold | V/F SVC FVC PMVF PMSVC PMFVC Set material fracture threshold value for detection. | 100.0% (0.0%~100.0%) | RUN |
| F16.32 (0x5020) | Material Fracture Detection Delay | V/F SVC FVC PMVF PMSVC PMFVC Set material fracture detection delay. | 2.0s (0.1s~60.0s) | RUN |

F16.36~F16.38: Pre-drive

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--------------------------|---|-------------------------|----------|
| F16.36 (0x5024) | Pre-drive | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: Manual trigger; 2: Automatic trigger | 0 (0~2) | STOP |
| F16.37 (0x5025) | Pre-drive Frequency Gain | V/F SVC FVC PMVF PMSVC PMFVC Set pre-drive frequency gain. | 105.0% (0.0%~200.0%) | STOP |
| F16.38 (0x5026) | Pre-drive Torque Gain | V/F SVC FVC PMVF PMSVC PMFVC Set pre-drive frequency gain. | 105.0% (0.0%~200.0%) | STOP |

F16.42~F16.43: Stop Braking

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|------------------------|---|---------------------------------------|----------|
| F16.42 (0x502A) | Stop Braking Frequency | V/F SVC FVC PMVF PMSVC PMFVC Set the stop braking frequency. | 2.00Hz (0.01Hz~ Max. frequency) | RUN |
| F16.43 (0x502B) | Stop Braking Time | V/F SVC FVC PMVF PMSVC PMFVC Set the stop braking time. | 0.0s (0.0s~600.0s) | RUN |

F16.44~F16.55: Roll Diameter

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-----------------------------|---|------------------------|----------|
| F16.44 (0x502C) | Diameter Calculation Method | V/F SVC FVC PMVF PMSVC PMFVC 0: Initial roll diameter without calculation; 1: Calculated by linear velocity; 2: Calculated by thickness; 3: Reserved; 4: Set via AI1; 5: Set via AI2; 6: Reserved 7: Set via PUL; 8: Set via RS485(0x300C) | 0 (0~8) | STOP |
| F16.45 (0x502D) | Max. Roll Diameter | V/F SVC FVC PMVF PMSVC PMFVC Set the max. roll diameter. | 500mm (1mm~10000mm) | STOP |

| | | | | |
|--------------------|---------------------------------|--|---------------------------------------|------|
| F16.46 (0x502E) | Roll Diameter | V/F SVC FVC PMVF PMSVC PMFVC Set the roll diameter value. | 100mm (1mm~ Max. roll diameter) | STOP |
| F16.47 (0x502F) | Initial Roll Diameter Source | V/F SVC FVC PMVF PMSVC PMFVC 0: Via terminals F16.48~F16.50 1: Reserved; 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; | 0 (0~5) | STOP |
| F16.48 (0x5030) | Initial Roll Diameter 1 | V/F SVC FVC PMVF PMSVC PMFVC Set initial roll diameter 1. | 100mm (1mm~ Max. roll diameter) | RUN |
| F16.49 (0x5031) | Initial Roll Diameter 2 | V/F SVC FVC PMVF PMSVC PMFVC Set initial roll diameter 2. | 100mm (1mm~ Max. roll diameter) | RUN |
| F16.50 (0x5032) | Initial Roll Diameter 3 | V/F SVC FVC PMVF PMSVC PMFVC Set initial roll diameter 3. | 100mm (1mm~ Max. roll diameter) | RUN |
| F16.51 (0x5033) | Roll Diameter Reset | V/F SVC FVC PMVF PMSVC PMFVC 0: Manual; 1: Auto | 0 (0~1) | RUN |
| F16.54 (0x5036) | Roll Diameter Change Rate Limit | V/F SVC FVC PMVF PMSVC PMFVC Set the roll diameter change rate limit. | 10.00mm/s (0.00mm/~200.00m m) | RUN |
| F16.55 (0x5037) | Roll Diameter Change Direction | V/F SVC FVC PMVF PMSVC PMFVC Set the roll diameter change direction limit. | 0 (0~1) | RUN |

F16.56~F16.63: Roll Diameter Calculation by Linear Speed

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|---|--|--|----------|
| F16.56 (0x5038) | Linear Velocity Input Source | V/F SVC FVC PMVF PMSVC PMFVC 0: Via terminals F16.60/F16.61; 1: Via panel keys; 2: Via panel potentiometer(on optional external single-row panels); 3: Via AI1; 4: Via AI2; 5: Reserved; 6: Via PUL terminal; 7: Via RS485(0x300D) | 0 (0~7) | RUN |
| F16.57 (0x5039) | Max. Linear Speed | V/F SVC FVC PMVF PMSVC PMFVC Set the maximum linear speed limit value for all channels. | 1000.0m/min (0.0m/min~6500.0m/min) | RUN |
| F16.58 (0x503A) | Panel Giving Linear Speed | V/F SVC FVC PMVF PMSVC PMFVC Set and modify linear speed via the panel keys. | 20.0 (0.0~ Max. linear speed) | RUN |
| F16.59 (0x503B) | Min. Linear Speed for Roll Diameter Calculation | V/F SVC FVC PMVF PMSVC PMFVC Set the min. linear speed for roll diameter calculation. | 2.0m/min (0.0m/min~Max. linear speed) | RUN |
| F16.60 (0x503C) | Linear Speed 1 | V/F SVC FVC PMVF PMSVC PMFVC Set linear speed 1 value. | 20.0m/min (0.0m/min~Max. linear speed) | RUN |

| | | | | |
|--------------------|--|---|---|-----|
| F16.61 (0x503D) | Linear Speed 2 | V/F SVC FVC PMVF PMSVC PMFVC Set linear speed 2 value. | 20.0m/min (0.0m/min~Max. linear speed) | RUN |
| F16.63 (0x503F) | Min. Frequency for Roll Diameter Calculation | V/F SVC FVC PMVF PMSVC PMFVC Set the min. frequency for roll diameter calculation. | 1.00Hz (0.00Hz~10.00Hz) | RUN |

F16.68~F16.70: Thickness-based Roll Diameter Calculation

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|--|---|-----------------------------|----------|
| F16.68 (0x5044) | Pulse Per Revolution of Winding Roller | V/F SVC FVC PMVF PMSVC PMFVC Set the number of pulses received by the winding roller for one revolution when calculating the roll diameter by thickness. | 1 (1~65000) | RUN |
| F16.69 (0x5045) | Lap Per Layer | V/F SVC FVC PMVF PMSVC PMFVC Set the number of revolutions required for a full layer of the winding. | 1 (1~10000) | RUN |
| F16.70 (0x5046) | Panel Giving Thickness | V/F SVC FVC PMVF PMSVC PMFVC Set the material thickness via panel keys. | 0.01mm (0.01mm~100.00mm) | RUN |

F16.75~F16.82: Tension PID

| Code (Address) | Name | Content | Default (Range) | Property |
|--------------------|-------------------------------------|---|------------------------|----------|
| F16.75 (0x504B) | Tension PID | V/F SVC FVC PMVF PMSVC PMFVC 0: OFF; 1: ON | 0 (0~1) | STOP |
| F16.76 (0x504C) | Tension PID output reference source | V/F SVC FVC PMVF PMSVC PMFVC 0: Given tension as reference source; 1: Max. tension as reference source | 0 (0~1) | STOP |
| F16.77 (0x504D) | Max.Tension PID Percentage | V/F SVC FVC PMVF PMSVC PMFVC Set the percentage of max. tension PID output. | 10.0% (0.0%~50.0%) | RUN |
| F16.78 (0x504E) | Tension PID Feedback Source | V/F SVC FVC PMVF PMSVC PMFVC 0: Via panel keys; 1: Via panel potentiometer(on optional external single-row panels); 2: Via AI1; 3: Via AI2; 4: Reserved; 5: Via PUL terminal; 6: Via RS485(0x300E) | 2 (0~6) | RUN |
| F16.79 (0x504F) | Panel Giving Tension PID Feedback | V/F SVC FVC PMVF PMSVC PMFVC Set and modify tension PID feedback with the panel. | 50.0% (0.0%~100.0%) | RUN |
| F16.80 (0x5050) | Tension PID Feedback Gain | V/F SVC FVC PMVF PMSVC PMFVC Set gain for all feedback signals. | 1.00 (0.00~10.00) | RUN |
| F16.81 (0x5051) | Proportional gain P1 | V/F SVC FVC PMVF PMSVC PMFVC Set tension PID proportional gain. | 0.500 (0.000~8.000) | RUN |
| F16.82 (0x5052) | Integral time T | V/F SVC FVC PMVF PMSVC PMFVC Set the tension PID integral time | 0.5s (0.0s~600.0s) | RUN |

4.20 F25: AI and AO Correction

This group of function codes and descriptions are described in detail in the corresponding technical manuals.

4.21 C0x: Monitoring Parameters

C00: Basic Monitoring

| Code(Address) | Name | Code(Address) | Name |
|-----------------|---------------------------------|----------------|-------------------------------------|
| C00.00(0x2100) | Given Frequency | C00.20(0x2114) | Analog Output |
| C00.01 (0x2101) | Output Frequency | C00.21(0x2115) | AO Expansion |
| C00.02(0x2102) | Output Current | C00.22(0x2116) | Counter Record |
| C00.03(0x2103) | Input Voltage | C00.23(0x2117) | Current Runtime |
| C00.04(0x2104) | Output Voltage | C00.24(0x2118) | Cumulative Runtime |
| C00.05(0x2105) | Mechanical Speed | C00.25(0x2119) | Rated Drive Power |
| C00.06(0x2106) | Given Torque | C00.26(0x211A) | Drive Rated Voltage |
| C00.07(0x2107) | Output Torque | C00.27(0x211B) | Drive Rated Current |
| C00.08(0x2108) | PID Setting | C00.28(0x211C) | Software Version |
| C00.09(0x2109) | PID Feedback | C00.29(0x211D) | PG Feedback Frequency |
| C00.10(0x210A) | Output Power | C00.30(0x211E) | Timer Duration |
| C00.11(0x210B) | Bus Voltage | C00.31(0x211F) | PID output value |
| C00.12(0x210C) | Module Temperature 1 | C00.32(0x2120) | Software Sub-Version |
| C00.13(0x210D) | Module Temperature 2 | C00.33(0x2121) | Encoder Feedback Angle |
| C00.14(0x210E) | Input Terminal X Status (Note) | C00.34(0x2122) | Accumulated Z-Pulse Error |
| C00.15(0x210F) | Output Terminal Y Status (Note) | C00.35(0x2123) | Z-Pulse Count |
| C00.16 (0x2110) | AI1 | C00.36(0x2124) | Fault Code |
| C00.17(0x2111) | AI2 | C00.37(0x2125) | Cumulative Power Consumption (Low) |
| C00.18(0x2112) | Panel Potentiometer Input | C00.38(0x2126) | Cumulative Power Consumption (High) |
| C00.19(0x2113) | PUL Input | C00.39(0x2127) | Power Factor Angle |

Note: For example, C00.14 is displayed as  , when terminals X1 and X2 are ON, and C00.15 is displayed as  , when terminal Y and relay are ON.

C01: Fault Monitoring

| Code(Address) | Name | Code(Address) | Name |
|----------------|-------------------------------|----------------|---|
| C01.00(0x2200) | Fault Type | C01.12(0x220C) | Previous 1 Fault Operation Frequency |
| C01.01(0x2201) | Fault Diagnosis | C01.13(0x220D) | Previous 1 Fault Output Voltage |
| C01.02(0x2202) | Fault Operation Frequency | C01.14(0x220E) | Previous 1 Fault Output Current |
| C01.03(0x2203) | Fault Output Voltage | C01.15(0x220F) | Previous 1 Fault Bus Voltage |
| C01.04(0x2204) | Fault Output Current | C01.16(0x2210) | Previous 1 Fault Module Temperature |
| C01.05(0x2205) | Fault Bus Voltage | C01.17(0x2211) | Previous 1 Fault Drive Status |
| C01.06(0x2206) | Fault Module Temperature | C01.18(0x2212) | Previous 1 Fault Input Terminal Status |
| C01.07(0x2207) | Fault Drive Status | C01.19(0x2213) | Previous 1 Fault Output Terminal Status |
| C01.08(0x2208) | Fault Input Terminal X Status | C01.20(0x2214) | Previous 2 Fault Type |
| C01.09(0x2209) | Fault Output Terminal Status | C01.21(0x2215) | Previous 2 Fault Diagnosis |
| C01.10(0x220A) | Previous 1 Fault Type | C01.22(0x2216) | Previous 3 Fault Type |
| C01.11(0x220B) | Previous 1 Fault Diagnosis | C01.23(0x2217) | Previous 3 Fault Diagnosis |

Note: Drive fault status bit meaning:

Ones-bit: operation direction, 0: Forward; 1: Reverse

Tens-bit: Operation status, 0: Stop; 1: Constant speed; 2: Accelerate; 3: Decelerate

Hundreds-bit: OV/OC, 0: Normal; 1: OV; 2: OC; 3: OV and OC

Thousands-bit: Reserved

C02: App Monitoring

| Code(Address) | Name | Code(Address) | Name |
|-----------------------------------|--|-----------------------------------|--|
| C02.00(0x2300) | PID Setting | C02.19(0x2313) | CBC No. |
| C02.01(0x2301) | PID Feedback | C02.20(0x2314)~ C02.22(0x2316) | Reserved |
| C02.02(0x2302) | PID Output | C02.23(0x2317) | Proportional Monitor Display 1 |
| C02.03(0x2303) | PID Control Status | C02.24(0x2318) | Proportional Monitor Display 2 |
| C02.05(0x2305) | PLC Operation Stage | C02.25(0x2319) | IO Expansion AI1 |
| C02.06(0x2306) | PLC Segment Frequency | C02.26(0x231A) | IO Expansion Analog 2 |
| C02.07(0x2307) | PLC Segment Runtime | C02.27(0x231B) | IO Expansion Analog 3 |
| C02.08(0x2308) | FWD/REV Command | C02.28(0x231C) | IO Expansion Input Terminal Status |
| C02.09(0x2309) | Jogging Command | C02.29(0x231D) | IO Expansion for Motor Temperature Detection |
| C02.10(0x230A) | Voltage/Current before AI1 Correction | C02.30(0x231E) | IO Expansion PUL Count Low |
| C02.11(0x230B) | Voltage/Current before AI2 Correction | C02.31(0x231F) | IO Expansion PUL Count High |
| C02.12(0x230C) | Voltage/Current before AO Correction | C02.32(0x2320)~ C02.47(0x232F) | Power Loss Protection 1~16 |
| C02.13(0x230D) | Voltage/Current before AO Expansion Correction | C02.48(0x2330)~ C02.49(0x2331) | Reserved |
| C02.14(0x230E) | Reserved | C02.50(0x2332)~ C02.59(0x233B) | Cache Register 0~9 |
| C02.15(0x230F) | Drive Overload Timing Factor | C02.60(0x233C) | Expansion A Version |
| C02.16(0x2310) | Motor Overload Timing Factor | C02.61(0x233D) | Expansion B Version |
| C02.17(0x2311)~ C02.18(0x2312) | Reserved | C02.62(0x233E) | External Panel Version |

C03: Maintenance and Tension Monitoring

| Code(Address) | Name | Code(Address) | Name |
|-----------------------------------|------------------------------|-----------------------------------|-------------------------------|
| C03.00(0x2400) | Current Runtime | C03.22(0x2416) | Current Linear Speed |
| C03.01(0x2401) | Cumulative Runtime(hour) | C03.23(0x2417) | Current Roll Diameter |
| C03.02(0x2402) | Cumulative Runtime(hour) | C03.24(0x2418) | Tension Source Torque |
| C03.03(0x2403) | Cumulative Runtime(minute) | C03.25(0x2419) | Tension PID Setting |
| C03.04(0x2404) | Fan Runtime | C03.26(0x241A) | Tension PID Feedback |
| C03.05(0x2405) | Fan Maintenance | C03.27(0x241B) | Tension PID Output |
| C03.06(0x2406) | Reserved | C03.28(0x241C) | Static Friction Compensation |
| C03.07(0x2407) | Main Relay Maintenance | C03.29(0x241D) | Dynamic Friction Compensation |
| C03.08(0x2408) | Reserved | C03.30(0x241E) | Total Friction Compensation |
| C03.09(0x2409) | Special 485 Monitoring Value | C03.31(0x241F)~ C03.39(0x2427) | Reserved (for Tension) |
| C03.10(0x240A)~ C03.19(0x2413) | Reserved | C03.50(0x2432) | Machine Code 1 |
| C03.20(0x2414) | Final Tension | C03.51(0x2433) | Machine Code 2 |

| | | | |
|----------------|-----------------------|----------------|----------------|
| C03.21(0x2415) | Initial Roll Diameter | C03.52(0x2434) | Machine Code 3 |
|----------------|-----------------------|----------------|----------------|

4.2.2 Terminal I/O Function

| X | Description | X | Description | X | Description |
|----|---|----|---|-------|--|
| 0 | None; | 24 | PID setting switching 1 | 48 | Command source to panel |
| 1 | FWD | 25 | PID setting switching 2 | 49 | Command channel to terminal |
| 2 | REV | 26 | PID setting switching 3 | 50 | Command source to communication |
| 3 | Three-line operation(Xi) | 27 | PID feedback switching 1 | 51 | Command source expansion board |
| 4 | FWD jogging | 28 | PID feedback switching 2 | 52 | Operation disable |
| 5 | REV jogging | 29 | PID feedback switching 3 | 53 | Forward operation off |
| 6 | Free stop | 30 | PLC pause | 54 | Reverse operation off |
| 7 | Emergency stop | 31 | PLC reboot | 55 | Reserved |
| 8 | Fault reset | 32 | ACC/DEC time terminal 1 | 56 | Reserved |
| 9 | External fault input | 33 | ACC/DEC time terminal 2 | 57 | Reserved |
| 10 | Frequency increase(UP) | 34 | ACC/DEC pause | 58 | Reserved |
| 11 | Frequency decrease(DW) | 35 | Swing frequency trigger | 59 | Reserved |
| 12 | Frequency reset(UP/DW reset) | 36 | Swing frequency pause | 60 | Speed/torque control switching |
| 13 | Source A to source B | 37 | Swing frequency reset | 61 | Reserved |
| 14 | Combined frequency source to source A | 38 | Panel keys and display self-test | 62 | Jogging frequency limit as torque mode frequency upper limit |
| 15 | Combined frequency source to source B | 39 | X5 or X10 (Expansion) frequency detection | 63~87 | Reserved |
| 16 | Multi-seg speed terminal 1 | 40 | Timer trigger terminal | 88 | Roll diameter reset |
| 17 | Multi-seg speed terminal 2 | 41 | Timer reset terminal | 89 | Initial roll diameter terminal 1 |
| 18 | Multi-seg speed terminal 3 | 42 | Counter clock input terminal | 90 | Initial roll diameter terminal 2 |
| 19 | Multi-seg speed terminal 4 | 43 | Counter reset terminal | 91 | Liner speed terminal |
| 20 | PID control canceled | 44 | DC brake command | 92 | Tension given channel switching |
| 21 | PID control paused | 45 | Pre-excitation command terminal | 93 | Reserved |
| 22 | PID characteristic switching | 46 | Reserved | 94 | Winding/Unwinding switching |
| 23 | PID parameter switching | 47 | Reserved | 95 | Pre-drive terminal |
| Y | Description | Y | Description | Y | Description |
| 0 | No output | 15 | Program cycle completion | 30 | 0x3018 controlled output |
| 1 | Drive in operation | 16 | Programmed segment completion | 31 | Drive overheat |
| 2 | Drive in reverse operation | 17 | PID feedback above upper limit | 32 | Reserved |
| 3 | Drive in forward operation | 18 | PID feedback below lower limit | 33 | Reserved |
| 4 | Fault tripping alarm 1 (report during fault auto-recovery) | 19 | PID feedback sensor disconnection | 34 | Reserved |
| 5 | Fault tripping alarm 2 (no report during fault auto-recovery) | 20 | Reserved | 35 | Reserved |
| 6 | Stop due to external faults | 21 | Timer setting arrival | 36 | Reserved |
| 7 | Drive undervoltage | 22 | Counter maximum arrival | 37 | Comparator 1 |
| 8 | AC drive ready | 23 | Counter setting arrival | 38 | Comparator 2 |
| 9 | Output frequency detection 1(FDT1) | 24 | Dynamic braking now | 39 | Reserved |
| 10 | Output frequency detection 2(FDT2) | 25 | Reserved | 40~47 | Expansion for industry applications |

| | | | | | |
|----|-------------------------------|----|------------------------|-------|-----------------|
| 11 | Given frequency arrival | 26 | Emergency stopping now | 48 | Comparator 3 |
| 12 | Zero-speed operating now | 27 | Load warning 1 | 49 | Comparator 4 |
| 13 | Upper limit frequency arrival | 28 | Load warning 2 | 50~63 | Optional boards |
| 14 | Lower limit frequency arrival | 29 | Drive in warning | - | - |

4.23 Fault and Warning Code List

Note: The numbers in brackets in the code column are error codes and warning codes. (Dec indicates decimal).

| Display (Dec.) | Name | Type | Display (Dec.) | Name | Type |
|----------------|--|---------|-------------------------------------|------------------------------------|---------|
| E. SC1 (1) | System failure during acceleration | Error | E. LD2 (80) | Load protection 2 | Fault |
| E. SC2 (2) | System failure during deceleration | Fault | E. CPu (81) | CPU timeout | Fault |
| E. SC3 (3) | System failure during constant speed | Fault | E. LoC (85) | Locked chip | Fault |
| E. SC4 (4) | System failure during stop | Fault | E. EEP (86) | Parameter storage failure | Fault |
| E. oC1 (5) | OC during acceleration | Fault | E. PG (87) | PLL error | Fault |
| E. oC2 (6) | OC during deceleration | Fault | E. buS1 (91) | Expansion A disconnected | Fault |
| E. oC3 (7) | OC during constant speed | Fault | E. buS2 (92) | Expansion B disconnected | Fault |
| E. ou1 (9) | OV during acceleration | Fault | E. buS3 (93) | CAN Expansion error | Fault |
| E. ou2 (10) | OV during deceleration | Fault | E. buS4 (94) | Others Expansion error | Fault |
| E. ou3 (11) | OV during constant speed | Fault | E. buS5 (95) | Others Expansion error | Fault |
| E. Lu (13) | UV during operation | Fault | E. buS6 (96) | Others Expansion disconnected | Fault |
| E. oL1 (14) | Motor OL | Fault | E. CP1 (97) | Monitor comparator output 1 error | Fault |
| E. oL2 (15) | Drive OL 1 | Fault | E. CP2 (98) | Monitor comparator output 2 error | Fault |
| E. oL3 (16) | AC drive overload 2, CBC keeps occurring | Fault | E. DAT (99) | Parameter setting error | Fault |
| E. oL4 (17) | Drive OL 3 | Fault | E. FA1 (110) | Reserved for expansion 1 | Fault |
| E. iLF (18) | Input phase loss | Fault | E. FA2 (111) | Reserved for expansion 2 | Fault |
| E. oLF (19) | Three-phase output phase loss | Fault | E. FA3 (112) | Reserved for expansion 3 | Fault |
| E. oLF1 (20) | U-phase output phase loss | Fault | E. FA4 (113) | Reserved for expansion 4 | Fault |
| E. oLF2 (21) | V-phase output phase loss | Fault | E. FA5 (114) | Reserved for expansion 5 | Fault |
| E. oLF3 (22) | W-phase output phase loss | Fault | E. FA6 (115) | Reserved for expansion 6 | Fault |
| E. oH1 (30) | Rectifier module OT | Fault | E. FA7 (116) | Reserved for expansion 7 | Fault |
| E. oH2 (31) | IGBT module OT | Fault | E. FA8 (117) | Reserved for expansion 8 | Fault |
| E. oH3 (32) | Motor overtemperature | Fault | E. FrA (118) | Material fracture | Fault |
| E. EF (33) | External fault | Fault | The following are the warning codes | | |
| E. CE(34) | Modbus communication error | Fault | | | |
| E. HAL1 (35) | Large U-phase zero drift | Fault | A. Lu1(128) | UV during stop | Warning |
| E. HAL2 (36) | Large V-phase zero drift | Fault | A. ou (129) | OV during stop | Warning |
| E. HAL (37) | Non-0 current sum of three phases | Fault | A. iLF (130) | Input phase loss | Warning |
| E. HAL3 (38) | Large W-phase zero drift | Fault | A. PiD (131) | PID feedback disconnection | Warning |
| E. SGxx (40) | Short circuit to ground | Fault | A. EEP (132) | Parameter save error | Warning |
| E. FSG (41) | Fan short circuit | Fault | A. DEF (133) | Excessive speed deviation | Warning |
| E. PiD (42) | PID feedback disconnection | Fault | A. SPD (134) | Overspeed | Warning |
| A. CoP (43) | Parameter copy error | Warning | A. GPS1(135) | GPS lockout | Warning |
| E. PG1 (44) | PG parameter setting error | Fault | A. GPS2(136) | GPS disconnection | Warning |
| E. PG2(44) | Encoder Z-pulse error | Fault | A. CE (137) | Modbus communication disconnection | Warning |
| E. PG3 (44) | Resolver check error | Fault | A. LD1(138) | Load protection 1 | Warning |

| | | | | | |
|--------------|---------------------------------------|-------|--------------|--|---------|
| E. PG4 (44) | Resolver disconnection | Fault | A. LD2(139) | Load protection 2 | Warning |
| E. PG5 (44) | ABZ encoder disconnection | Fault | A. buS(140) | Expansion disconnection | Warning |
| E. PG6 (44) | Spindle encoder disconnection | Fault | A. oH1(141) | Module OT | Warning |
| E. PG7 (44) | Spindle encoder Z-pulse deviation | Fault | A. oH3(142) | Motor OT | Warning |
| E. PG8 (44) | Encoder Z-pulse logic error | Fault | A. run1(143) | Operation command conflict | Warning |
| E. PG9 (44) | Spindle encoder Z-pulse logic error | Fault | A. run2(148) | Jogging terminal startup protection | Warning |
| E. PG10 (44) | Encoder Z-pulse disconnection | Fault | A. run3(149) | Terminal startup protection | Warning |
| E. PG11 (44) | Spindle encoder Z-pulse disconnection | Fault | A. PA2(144) | External panel disconnection | Warning |
| E. PG12 (44) | Encoder feedback error | Fault | A. CoP (145) | Parameter copy error | Warning |
| E. PG13 (44) | Encoder hardware disconnection | Fault | A. CP1 (146) | Monitor comparator output 1 error | Warning |
| E. bru (50) | Braking unit error | Fault | A. CP2 (147) | Monitor comparator output 2 error | Warning |
| E. TExx (52) | Motor parameter auto-tuning error | Fault | A. FA1(150) | Reserved for expansion 1 | Warning |
| E. iAE1 (71) | Motor angle tuning fault 1 | Fault | A. FA2(151) | Reserved for expansion 2 | Warning |
| E. iAE2 (72) | Motor angle tuning fault 2 | Fault | A. FA3(152) | Reserved for expansion 3 | Warning |
| E. iAE3 (73) | Motor angle tuning fault 3 | Fault | A. FA4(153) | Reserved for expansion 4 | Warning |
| E. PST1 (74) | PM step loss 1 | Fault | A. FA5 (154) | Reserved for expansion 5 | Warning |
| E. PST2 (75) | PM step loss 2 | Fault | A. FA6 (155) | Reserved for expansion 6 | Warning |
| E. PST3 (76) | PM step loss 3 | Fault | A. FrA(157) | Material fracture | Warning |
| E. DEF (77) | Excessive speed deviation | Fault | A. OH4(158) | Motor temperature sensor disconnection | Warning |
| E. SPD (78) | Overspeed | Fault | A.161(161) | Fan span | Warning |
| E. LD1 (79) | Load protection 1 | Fault | A.163(163) | Main relay span | Warning |

Chapter 5 Regular Inspection and Maintenance

5.1. Inspection

The drives consist of semiconductor devices, passive electronic devices, and motion devices, all of which have a service life, and even under normal operating conditions, some of the devices may change in characteristics or fail if their service life is exceeded. To prevent malfunction, preventive inspections and maintenance such as daily inspections, periodic inspections, and device replacement must be performed. It is recommended that inspections be performed every 3 to 4 months after the machine is installed.

Daily inspection: To avoid damage to the drive and shortening of its service life, check the following items on a daily basis.

| Item | Content | Solutions |
|----------------|---|--|
| Power | Check that the supply voltage meets the requirements and that there is | Follow the instructions on the nameplate. |
| Surroundings | Check whether the installation environment meets the requirements. | Confirm the source and handle it properly. |
| Cooling system | Check whether there is abnormal heating and discoloration of the drive and motor, and the working condition of the cooling fan. | Confirm whether there is overload, tighten the screws, whether the heat sink is dirty, and whether the fan is blocked. |
| Motor | Check whether the motor has abnormal vibration or sound. | Tighten mechanical and electrical connections and |
| Load | Check whether the output current of the drive is higher than the rated value of the motor and it runs for a certain period of time. | Check whether there was an overload condition, and whether the selection of AC drive is correct. |

- Periodic inspection: In general, it is appropriate to conduct periodic inspections every 3 to 4 months, however, please determine the actual inspection period for each machine based on its usage and working environment.

| Item | Content | Solutions |
|--------------------------|--|---|
| Overall | Insulation resistance check; environment check | Tighten and replace defective parts; clean and |
| Electrical connections | <ul style="list-style-type: none"> • Check if the wires and connections are free of discoloration, broken insulation, cracks and signs of deterioration; • Check if the connection terminals are not worn, damaged, or loose; • Check grounding | <ul style="list-style-type: none"> • Replace the damaged wires; • Tighten the loose terminals and replace the damaged ones; • Measure the grounding resistance and tighten the corresponding grounding terminals |
| Mechanical connections | <ul style="list-style-type: none"> • Check if there are abnormal vibration and noise, and loose fixing | <ul style="list-style-type: none"> • Tighten, lubricate, and replace defective parts |
| Semiconductor or devices | <ul style="list-style-type: none"> • Check for dirt and dust • Check for visible changes in appearance | <ul style="list-style-type: none"> • Clean the operating environment • Replace damaged parts |
| Electrolytic capacitor | <ul style="list-style-type: none"> • Check for fluid leakage, discoloration, cracks, and exposed, expanded, ruptured, or leaked | <ul style="list-style-type: none"> • Replace damaged parts |
| Peripherals | <ul style="list-style-type: none"> • Check appearance and insulation of peripheral equipment | <ul style="list-style-type: none"> • Clean the environment and replace damaged |
| Printed circuit board | <ul style="list-style-type: none"> • Check for odor, discoloration, and severe rust, and whether connectors are correct | <ul style="list-style-type: none"> • Fasten connectors • Clean the printed circuit board • Replace the damaged printed circuit board |
| Cooling system | <ul style="list-style-type: none"> • Check the cooling fan for damage and blockage; • Check for dirt and dust on the cooling fin • Check that the air inlet and exhaust ports are not clogged or contaminated with foreign matter | <ul style="list-style-type: none"> • Clean the operating environment • Replace damaged parts |
| Panel | <ul style="list-style-type: none"> • Check the cooling fan for damage and blockage | <ul style="list-style-type: none"> • Replace damaged parts |
| Motor | <ul style="list-style-type: none"> • Check whether the motor has abnormal vibration or sound | <ul style="list-style-type: none"> • Tighten mechanical and electrical connections and lubricate mechanical parts |



⚠ : Do not carry out work with the power supply on, as there is a risk of electric shock and death. Before performing wiring, inspection, maintenance, etc., disconnect the power supply to all associated equipment and make sure that the DC voltage in the main circuit has dropped to a safe level for 5 minutes.

5.2 Maintenance

All equipment and components have a service life, proper maintenance can prolong the life, but it does not fix the damage of the equipment and devices, please replace the devices according to the requirements.

| Name | Life | Name | Life | Name | Life |
|------|-------------|------------------------|-------------|-----------------------|--------------|
| Fan | 2 ~ 3 years | Electrolytic capacitor | 4 ~ 5 years | Printed circuit board | 8 ~ 10 years |

Replacement of other devices requires maintenance techniques and product knowledge, and replacement must be strictly tested before it is put into use, so we do not recommend users to replace other internal devices. If replacement is indeed necessary, please contact the agent from whom you purchased the product or our sales department.

5.3 Product Warranty

1. If the product malfunctions during the warranty period, please refer to the warranty terms for coverage in the warranty card.
2. Primary troubleshooting will be carried out by your company, but the service can be provided by VEICHI or service network for a fee at your request. If the cause of malfunction is found to be on VEICHI, the service will be free of charge according to mutual negotiation.
3. Liability exemption: Inconvenience caused to your company or your customers due to the failure of VEICHI products and the damage caused to the non-VEICHI products, regardless of whether they are within the warranty period, do not belong to the scope of VEICHI warranty.

Appendix I: Modbus Communication Protocol

• Communication frame structure

The communication data format is as follows:

Composition of bytes: Start bit, 8 data bits, parity bit and stop bit.

| | | | | | | | | | | |
|-----------|------|------|------|------|------|------|------|------|--------|----------|
| Start bit | Bit1 | Bit2 | Bit3 | Bit4 | Bit5 | Bit6 | Bit7 | Bit8 | Parity | Stop bit |
|-----------|------|------|------|------|------|------|------|------|--------|----------|

The information of a frame must be transmitted in one continuous data stream, and if it is longer than 1.5 bytes of interval before the end of transmission of the entire frame, the receiving device will clear this incomplete information and incorrectly assume that the subsequent byte is the address field of the next new frame. Similarly, if the start of a new frame is shorter than 3.5 bytes interval from the previous frame, the receiving device will consider it to be the sequent part of the previous frame. The final CRC parity will be incorrect due to the misalignment of the frame, resulting in a communication error.

Standard structure of an RTU frame:

| | |
|------------------|--|
| Frame header | Transmission time for 3.5 bytes |
| Slave address | Communication address: 0~247 in decimal (0 is the broadcast address) |
| Command code | 03H: Read slave parameters 06H: Write slave parameters 08H: Circuit self-detection |
| Data area | Parameter address, number of parameters, parameter value, etc. |
| CRC CHK low | Check value: 16-bit CRC value |
| CRC CHK high | |
| End of the frame | Transmission time for 3.5 bytes |

• Command code and communication data description

Take the read parameter command code as an example.

For example, if there is an AC drive with a slave address of 01H and a memory starting address of 2100H(C00.00 Monitoring Parameters),

read three consecutive words, the frame is described as follows:

| RTU master command | | RTU slave response (normal) | |
|-----------------------|-----|-------------------------------|-----|
| Slave address | 01H | Slave address | 01H |
| Command code | 03H | Command code | 03H |
| Starting address high | 21H | Byte count low | 06H |
| Starting address low | 00H | Data address 2100H high | 13H |
| Data count high | 00H | Data address 2100H low | 88H |
| Data count low | 03H | Data address 2101H high | 00H |
| CRC CHK low | 0FH | Data address 2101H low | 00H |
| CRC CHK high | F7H | Data address 2102H high | 00H |
| - | - | Data address 2102H low | 00H |
| - | - | CRC CHK low | C3H |
| - | - | CRC CHK high | C9H |
| - | - | RTU slave response(abnormal): | |
| - | - | Slave address | 01H |

| | | | |
|---|---|--------------|-----|
| - | - | Command code | 83H |
| - | - | Wrong code | 04H |
| - | - | CRC CHK low | 40H |
| - | - | CRC CHK high | F3H |

● Communication control parameter group address description

| Description | Address | Description | | R/W |
|--|------------------|--|--|-----|
| Communication giving Frequency | 0X3000 or 0x2000 | 0~50000 corresponds to 0.00Hz~500.00Hz | | W/R |
| Communication command | 0X3000 or 0x2001 | 0x0000: None 0x0001: FWD 0x0002: REV 0x0003: FWD jogging 0x0004: REV jogging | 0x0005: Deceleration stop 0x0006: Free stop 0x0007: Fault reset 0x0008: Operation disable 0x0009: Operation enable | W/R |
| Drive status | 0x3002 or 0x2002 | Bit0 | 0: Stop; 1: Operation | R |
| | | Bit1 | 0: Non-accelerating; 1: Accelerating | |
| | | Bit2 | 0: Non-decelerating; 1: Decelerating | |
| | | Bit3 | 0: Forward; 1: Reverse | |
| | | Bit4 | 0: No fault; 1: Drive fault | |
| | | Bit5 | 0: GPRS unlocked; 1: GPRS locked | |
| | | Bit6 | 0: No warning; 1: Drive in warning | |
| Drive fault code | 0x3003 or 0x2003 | Current fault code (see fault code table) | | R |
| Communication giving upper limit frequency | 0x3004 or 0x2004 | 0~32000 corresponds to 0.00Hz~320.00Hz | | W/R |
| Communication giving torque | 0x3005 or 0x2005 | 0~1000 corresponds to 0.0%~100.0% | | W/R |
| FWD upper frequency limit under torque control | 0x3006 or 0x2006 | 0~1000 corresponds to 0.0%~100.0% | | W/R |
| REV upper frequency limit under torque control | 0x3007 or 0x2007 | 0~1000 corresponds to 0.0%~100.0% | | W/R |
| PID setting via communication | 0x3008 or 0x2008 | 0~1000 corresponds to 0.0%~100.0% | | W/R |
| PID feedback via communication | 0x3009 or 0x2009 | 0~1000 corresponds to 0.0%~100.0% | | W/R |
| Fault/Warning code reading | 0x3010 or 0x2010 | 0~127 are fault codes, 128 and above are warning codes | | R |
| Output terminal status | 0x3018 or 0x2018 | Drive output terminals externally occupied Bit0—Y Bit1—A1—TB1—TC1 Bit2—Y1 expansion (required IO expansion) Bit3—Relay expansion (required IO expansion) | | W |
| AO | 0x3019 or 0x2019 | 0~10000 corresponds to output 0V~10V, 0mA~20mA | | W |

Note: For other function code addresses, please see the "Address" column in the function code list.

When the write command(06H) is used to write the F00~F15 parameter group, if its high half byte of the address field is 0, it will be written into the RAM of drive only, and will not be stored during power down; if it is 1, then it will be written into EEPROM, that is to say, it will be stored during power down.

Take F00.xx as an example: 0x00xx (write RAM), 0x10xx (store in EEPROM); F01.xx: 0x01xx (write RAM), 0x11xx (store in EEPROM), and so are the other parameters. When reading the parameters in Group F00~F15, the high half byte of the address can be 0, such as the read parameter F03.xx: 0x03xx.

When the write command(06H) is used to write the F16~F29 parameter group, if its high half byte of the address field is 5, it will be written

into the RAM of drive only, and will not be stored during power down; if it is D, it will be written into EEPROM, that is to say, it will be stored during power down.

Take parameter F16.xx for example: 0x50xx(write to RAM) 0xD0xx(store in EEPROM); F17.xx: 0x51xx(write RAM) 0xD1xx(store in EEPROM), and so are the other parameters. When reading the parameters in Group F16-F29, the high half byte of the address can be 5, such as the read parameter F18.xx: 0x52xx.


● **Meaning of error codes of the abnormal response messages from slave**

| Code | Description | Code | Description | Code | Description |
|------|------------------------------|------|--|------|----------------------------------|
| 1 | Command code error | 3 | CRC parity error | 4 | Illegal address |
| 5 | Illegal data | 6 | Parameters not for modification during operation | 8 | Drive busy (saving to EEPROM) |
| 9 | Parameter value beyond range | 10 | Reserved parameters not for modification | 11 | Error in reading parameter bytes |

Appendix II: Terminal Wiring Methods

0: Two-wire Control 1


Operation and direction are set at the same time. Two-wire mode is most commonly used in this mode. The factory default is that the X1(FWD operation) and X2(REV operation) terminal control the motor to run forward and reverse. This is shown in the figure below:



0: Two-wire control 1

1: Two-wire Control 2


Running and direction are separated. X1 (FWD operation) in this mode is used to enable motor operation. The direction is defined by the status of the X2 terminal (REV operation). This is shown in the figure below:



1: Two-wire control 2

2: Three-wire Control 1


The three-wire control terminal (Xi) of this mode is for stop and the operation command is generated by X1(FWD operation) and the direction is controlled by X2(REV operation). Input via the terminal (Xi) in the three-wire control mode is valid.



2: Three-wire control 1

3: Three-wire Control 2

The three-line control terminal (Xi) of this mode is for stop and the operation command is generated by X1(FWD operation) or X2(REV operation), and the two controls the direction simultaneously.




3: Three-wire control 2

Note: SB1: Stop; SB2: FWD operation; SB3: REV operation; "Xi" is a multifunction input terminal set to "3" [3-line control (Xi)].


Appendix III: External Panel Dimensions and Models

External dual-row panel and opening dimensions

Model: KBD300-25(Notes: LCD and LED panel external dimensions and opening dimensions are fully compatible (unit in the drawing: mm)).




AC310 external dual-row panel dimensions



AC310 external dual-row panel pocket and opening dimensions

External single-row panel and opening dimensions



Model: KBD10-15(Notes: Mounting plate opening size: 61mmx36mm (unit in the drawing: mm)).

AC310 series external single-row panel dimensions

Version Change Log

| Date | Version | Content |
|---------|---------|--|
| 2019.03 | V1.0 | First version issued |
| 2021.12 | V1.1 | Replaced AC300 model with AC310 |
| 2024.03 | V1.2 | <ol style="list-style-type: none"> 1. Optimized the font size of the manual 2. Modified speed control range 3. Modified speed stabilizing accuracy 4. Modified starting torque 5. Changed fonts and optimized language 6. Added F08: Auxiliary Control 2 Parameter 7. Added the related parameters of F15, F16 and F25 8. Added Appendix III: External Panel Dimensions and Models 9. Added the power of T3 model, T2 and T6 models 10. Added instructions for DC reactor and braking unit 11. Added the related parameter description of F06 12. Added the related parameters of C02 and C03 13. Added purpose of F00.01 14. Added F00.05 [User Password] and F00.06 [Panel Language] 15. Modified max. frequency range 16. Added F01.14 [Frequency Command Resolution] 17. Added F01.46 [Random PWM Depth] 18. Added the related parameters of F02.47, F02.48 and F02.49 19. Added F02.61 [Pole Search Current] 20. Added F03.19 [Torque Limit] 21. Added F03.58 [Torque Gain] and F03.59 [Gain Switching Frequency] 22. Added F04.2X V/F separation parameters 23. Added F06.05 and F06.06 [AO as FM Upper/Lower Limit] 24. Added F06.23 and F06.24 Expansion output functions 25. Added F10.05 and F10.06 current imbalance related parameters 26. Added motor overheat related parameters of expansions on F10.26, F10.27 and F10.28 27. Added the related parameters of F10.55~F10.59 28. Added the related parameter description of panel potentiometer of F11.3X 29. Added F12.19 [Master Sending Command] 30. Added F12.2X of Modbus special functions 31. Added F12.32 [DP Master-Slave Failure Mode] 32. Added F12.43 [CAN Master-Slave Failure Mode] 33. Added Y terminal 41-47 for industry application expansion and 48-63 for optional board expansion 34. Added AC310-T2 model, 0.75 kW-4.00kW 35. Added model and size of AC310-T6 36. Added frequency command resolution 10rpm 37. Added AO expansion: High-speed FM output 38. Added thousands-bit description on Current Protection 1 39. Added the relationship between current and the settings of Motor OT and Module Temperature Sensor |

VEICHI

SUZHOU VEICHI ELECTRIC Co.,Ltd.

Address:No.1000 Songjia road,Wuzhong Economic and Technological Development Zone,Suzhou

Phone:+86-512-6617 1988

Facebook:<https://www.facebook.com/veichiglobal/>

Whatsapp:+86-138 2881 8903

E-mail:overseas@veichi.com Web:<https://www.veichi.com/>



Official Website

Version: V1.3

Suzhou Veichi Electric Co.,Ltd.all rights reserved,subject to change without notice.