

■

VEICHI



VEICHI

SS70 built-in bypass soft starter user manual

VEICHI

Address: No.1000 Songjia Road, Guo Lane Street, Wuzhong Economic and Technological Development Zone, Suzhou,China
Telephone: (0512) 66171988
Portraiture:400-600-0303
Zip code:215000
E-mail: zqb@veichi.com



SS70 built-in bypass soft starter user manual

Suzhou VEICHI Electric Co., Ltd provides customers with a full range of technical support, users can contact the nearest well office, agents or customer service center, or directly contact the company headquarters.

The information in this manual is subject to change without notice

The agent or distributor shall not be responsible for any errors or omissions in this manual or for any inevitable damage that may be caused by the execution or use of this manual.

The information in this user manual is protected by the copyright law. Without the written authorization of the copyright owner, all or part of the contents in this manual may not be photocopied or copied in any form, and the copy shall be investigated.

Copyright©2021
All Rights Reserved

VEICHI

Address: No.1000 Songjia Road, Guo Lane Street, Wuzhong Economic and Technological Development Zone, Suzhou, China
Telephone: (0512) 66171988
Portraiture:400-600-0303
Zip code:215000
E-mail: zqb@veichi.com

This manual does not guarantee the implementation of industrial ownership and other rights, nor the right of its implementation,
Moreover, the Company is not liable for the problems of industrial ownership arising from the use of the contents contained in this manual.

CONTENTS

| | | | |
|---|----|--|----|
| Preface..... | 1 | Chapter 5 function detailed description and application setting..... | 19 |
| Chapter One security information | 2 | 5.0 Startup Mode (F-00)..... | 21 |
| 1.1 State the matters for attention..... | 2 | 5.1 Soft start time (F-01) | 21 |
| 1.2 About the soft starter..... | 3 | 5.2 2 Soft stop time (F-02)..... | 21 |
| Chapter 2, product specification parameters and arrival inspection | 4 | 5.3 Start and stop voltage (F-03)..... | 21 |
| 2.1 Product technology and technical specifications..... | 4 | 5.4 Current limit amplyude (F-04) | 21 |
| 2.2, product system, column introduction. | 5 | 5.5 step voltage (F-07)..... | 21 |
| 2.2.1 Arrival inspection..... | 5 | 5.6 Running Over current (F-11)..... | 22 |
| 2.2.2 Description of SS70 model and nameplate | 5 | 5.7 Overload Protection (F-12) | 22 |
| 2.2.3 3 Selection of specifications and accessories..... | 6 | 5.8 Display mode (F-14) | 22 |
| Chapter 3, installation and wiring | 8 | 5.9 Electric over temperature (F-15) | 22 |
| 3.1 Installation of the soft starter..... | 8 | 5.10 Overvoltage protection (F-16) | 22 |
| 3.2 Wiring of the soft starter..... | 9 | 5.11 Undervoltage protection (F-17) | 22 |
| 3.2.1 Overview..... | 9 | 5.12 Output phase loss (F-18)..... | 22 |
| 3.2.2 Main loop input and output terminals and external lead control terminals..... | 10 | 5.13 Module Overttemperature (F-19) | 22 |
| 3.2.3 Control loop configuration and wiring | 12 | 5.14 Timeout Protection (F-20) | 22 |
| 3.2.4 Requirements for site wiring and grounding requirements | 13 | 5.15 Imbalance (F-21) | 22 |
| 3.2.5 Precautions. | 14 | 5.16 Fire counting (F-22) | 22 |
| Chapter 4: Operation instructions of the soft starter..... | 15 | 5.17 Communication control (F-23-F-29).... | 23 |
| 4.1 Term description..... | 15 | 5.18 Analog Output (F-30)..... | 23 |
| 4.2 Description of the LCD keyboard display unit..... | 15 | 5.19 Fire Mode (F-31)..... | 23 |
| 4.2.1 Keyfunction description | 15 | 5.20 Initialization (F-32) | 23 |
| 4.2.2 4 Light instructions | 16 | 5.21 Language Selection (F-33) | 23 |
| 4.2.3 Introduction and operation of the information screen | 16 | 5.22 Motor current (F-34) | 23 |
| 4.2.4 Setting process of function code parameters. | 18 | 5.23 Factory Password (F-35) | 23 |
| | | Chapter 6 Fault exception handling | 24 |
| | | Chapter 7 Maintenance and Maintenance..... | 27 |
| | | 7.1 Daily maintenance and inspection | 27 |
| | | 7.2 Periodic maintenance | 27 |
| | | 7.3 Storage of the soft starter | 28 |
| | | 7.4 Product Warranty | 28 |
| | | Appendix 1: Application example diagram..... | 30 |
| | | Appendix 2: Overall dimension drawing..... | 31 |

PREFACE

Thank you for purchasing SS70 built-in bypass contactor soft starter. Thank you for your support of Thinkvert. We will repay your love with excellent product performance!

The SS70 built-in bypass contactor soft starter components, materials and the latest microcomputer control technology. This product is a star-stomanaufactured using high-qualifdevice that integrates motor soft start, soft stop, energy saving and multiple protection functions and is dedicated to use a constant speed AC motor as the driving power. Compared with thtraditional starting method, after using the SS70 built-in bypass contactor soft starter, the voltage, torque and current on the motor can work smoothly, so the mechanical impact of the load will be completely improved; rich motor protection functions, It has played a very important role in extending the service life of the motor; at the same time, it has the communication function with the host computer control system, which can effectively implement the networking function of the system.

In order to facilitate your use, this manual will provide you with relevant precautions such as installation wiring, parameter setting, fault diagnosis and daily maintenance. In order to ensure that you can correctly install and use the SS70 built-in bypass contactor soft starter and give full play to its superior performance, please read this user manual carefully before installation and keep it properly.

As a power electronic device, during the operation and use of the soft starter, for the safety of you and the equipment, be sure to leave it to professional motor engineers to install and debug and set the parameters. Thank you!


Reader object


This manual is suitable for reading by the following persons:


Equipment installation personnel, maintenance, care personnel, designers


Chapter 1 Safety Information

1.1 Statement of precautions

|  Statement |
|--|
| <ul style="list-style-type: none"> • Before operating this equipment, please read the operation user manual carefully and strictly follow the operation specifications of the manual. • During installation and maintenance operations, strictly follow the relevant national standards and industry practices of the manual. • The manufacturer is not responsible for any adverse consequences caused by not following the corresponding guidelines and specifications. <ul style="list-style-type: none"> • Make sure that the soft-start wiring is correct and the safety measures are adequately prepared before closing. • Before maintaining the soft starter or motor, all power inputs must be disconnected. • Do not place flammable materials near the soft starter, otherwise there is a danger of fire. <ul style="list-style-type: none"> • it is strictly prohibited to install the soft starter in an environment containing explosive gas, otherwise there is a danger of explosion. • Wiring must be performed by qualified personnel, otherwise there is a danger of electric shock. • When optional accessories are required, it is recommended to use special accessories for soft starters from Aikeweier Technology Co., Ltd. to avoid potential safety hazards. • The main circuit terminal and the wire nose must be firmly connected, and the exposed part of the cable nose for main circuit wiring must be wrapped with insulating tape to avoid potential safety hazards. |

|  Cautions |
|---|
| <ul style="list-style-type: none"> • After the product is connected to the main power supply, the voltage inside the local devices and local locations on the PCB is equal to the main voltage. If it is touched in violation of the regulations, it will be very dangerous and may cause electric shock injury or death. • After this product is connected to the main power, even after the control voltage is disconnected or the starter is stopped, the sample full voltage signal will still appear at the output of the soft starter. • Pay attention to the danger of electric shock. Do not touch the soft starter with wet hands. • In order to ensure your safe use and prevent accidental electric shock, please ensure that the product is well grounded. • It is strictly forbidden to connect the power factor compensation capacitor to the output of the starter. |

|  Implementation Standards |
|---|
| <ul style="list-style-type: none"> • This product is designed according to the requirements of the starter product standard EN I IEC60947-4-2 class equipment level standard. • For further information, please refer to other related technical notes of Thinkvert Technology Limited. |

|  Cautions |
|--|
| <ul style="list-style-type: none"> • During transportation, do not pull the soft starter through the display unit and cover to avoid personal injury or damage to objects. • Do not drop foreign objects such as screws, gaskets, and metal rods into the soft start, otherwise there is a danger of fire and damage to the device. • Do not install in places where water droplets may splash, such as water pipes. • If the soft starter is damaged or the parts are incomplete, please do not install or run it, otherwise there is a danger of fire and personal injury. • Do not install in direct sunlight. |

1.2 About soft starter

Capacitors with improved power factor or varistors for lightning protection can cause soft starter fault trips or damage to the components. Be sure to remove them. As shown in Figure 1-1:




Figure 1-1 The use of capacitors at the output of the soft starter is prohibited

Switching devices such as contactors at the output

If you need to install a switching device such as a contactor between the output side of the soft starter and the motor, make sure to switch on and off when the soft starter is output, otherwise the soft starter may be damaged.

Input voltage exceeded

Use the soft starter within its rated voltage range. In

special occasions, please use a step-up or step-down device.

Lightning protection

The soft starter is equipped with a lightning overcurrent protection device, which has a certain self-protection ability for induction lightning.

Altitude and derating use

In areas with an altitude of more than 1,000 meters, the heat dissipation effect of the soft starter becomes poor due to the thin air, so it must be derated. Figure 1-2 shows the relationship between the rated current of the soft starter and the altitude.




Figure 1-2 Relationship between rated output current of soft starter and altitude

Chapter 2 Product Specifications and Arrival Inspection

2.1 Product technical specifications

Table 2-1 Product technical specifications

| Item | Descriptor | |
|---------------------------|--|--|
| Applicable standards | GB14048.6-2016 (IEC60947-4-2) | |
| Adapted motor type | Three-phase asynchronous motor | |
| Motor Power | 11A.....1260A(5.5~630KW) | |
| Input | Control voltage | AC220V±15%: AC110V±15% (Note when ordering) |
| | Rated voltage | AC380V±15%: 50Hz/60Hz: 690V±15% (Note when ordering) |
| Adjustable starting time | 1~120S adjustable | |
| Adjustable stop time | 0~120S adjustable | |
| Control Mode | 1. Ramp voltage 2. Ramp current 3. Current limit mode | |
| I/O | Digital input | 3 channels (X1- X3) |
| | Analog output | 1channel 4~20mA/0-10V |
| | Relay output | 2 relay outputs |
| | Run command input | Keyboard display unit setting, control terminal setting RS485 communication is given |
| Communication | Protocol | Standard Modbus protocol, 1 channel |
| Display unit | LCD display | Can display current, voltage, alarm and other motor parameters |
| Protection and monitoring | Short circuit overvoltage overcurrent, undervoltage, phase loss, overcurrent, temperature protection | |
| Environment | Use place | Indoor, free from direct sunlight, dust-free, corrosive and flammable gases, oil mist, water vapor, dripping water or salt, etc. |
| | Altitude | If the altitude exceeds 1000m, the capacity should be reduced accordingly For every 100m increase, the current decreases by 0.5% |
| | Ambient temperature | 10 C ~+40C the change of air temperature is less than 0.5 C / min; derating should be used above 40 C, and the output current will be derated by 2% for each exceeding 1 C, the maximum temperature is 50 C |
| | Humidity | Less than 95% RH, no condensation |
| | Storage temperature | -40℃~70℃ |
| Structure | Level of protection | IP20 |
| | Cooling method | Radiator, natural cooling |
| Installation method | Vertical installation inside the cabinet | |

2.2 Product Series Introduction

2.2.1 Arrival inspection

Before leaving the factory, this product has undergone strict quality inspection and is packed with anti-collision and anti-shock packaging. However, accidents may occur accidentally during transportation and handling. Therefore, after you receive the product, please immediately check the arrival of the product.

① Check whether the soft starter caused damage during transportation.

② Check the nameplate of the motor soft starter to ensure that the product you receive is the product you ordered.

③ The packing box contains a SS70 built-in bypass soft starter, a user manual, a certificate and a warranty card. If any of the above listed items is missing or damaged, please contact your local agent, dealer or our technical service center directly.

2.2.2 Model and nameplate of SS70 built-in bypass contactor soft starter

The model description of the SS70 built-in bypass soft starter is shown in Figure 2-1a, and the nameplate description is shown in Figure 2-1b:




Figure 2-1a Model of SS70 built-in bypass contactor soft starter

Example instructions:

SS70-008-40 meaning: This SS70 built-in bypass soft starter has display function in Chinese and English, working voltage of 380V, rated power of 55KW.

SS70 built-in bypass contactor soft starter nameplate description as shown in Figure 2-1b




Figure 2-1b SS70 series nameplate

2.2.3 Selection of specifications and accessories

The body type and matching power of the SS70 built-in bypass soft starter are shown in the table:

Size number and matching power of SS70-380V are shown below

| Model | Adapt to the motor power (KW) | Rated current (A) 380V | Enclosure mode | One line specifications | Control power supply minimum capacity /VA |
|-------------|-------------------------------|---------------------------|----------------|-------------------------|---|
| SS70-008-40 | 7.5 | 22 | M-SS-01 | 6mm ² | 195 |
| SS70-011-40 | 11 | 27 | M-SS-01 | 10mm ² | 195 |
| SS70-015-40 | 15 | 30 | M-SS-01 | 10mm ² | 195 |
| SS70-018-40 | 18.5 | 34 | M-SS-01 | 16mm ² | 195 |
| SS70-022-40 | 22 | 38 | M-SS-01 | 16mm ² | 195 |
| SS70-030-40 | 30 | 65 | M-SS-02 | 25mm ² | 300 |
| SS70-037-40 | 37 | 70 | M-SS-02 | 25mm ² | 300 |
| SS70-045-40 | 45 | 88 | M-SS-02 | 35mm ² | 300 |
| SS70-055-40 | 55 | 110 | M-SS-03 | 50 mm ² | 400 |
| SS70-075-40 | 75 | 140 | M-SS-03 | 70 mm ² | 400 |
| SS70-090-40 | 90 | 172 | M-SS-04 | 25*3 Copper row | 905 |
| SS70-110-40 | 110 | 200 | M-SS-04 | 25*3 Copper row | 905 |
| SS70-132-40 | 132 | 280 | M-SS-05 | 40*3 Copper row | 1600 |
| SS70-160-40 | 160 | 320 | M-SS-05 | 40*3 Copper row | 1600 |
| SS70-185-40 | 185 | 355 | M-SS-05 | 40*5 Copper row | 1600 |
| SS70-200-40 | 200 | 380 | M-SS-05 | 40*5 Copper row | 1600 |
| SS70-220-40 | 220 | 440 | M-SS-05 | 40*5 Copper row | 1600 |
| SS70-250-40 | 250 | 480 | M-SS-05 | 40*5 Copper row | 1600 |
| SS70-280-40 | 280 | 560 | M-SS-06 | 50*5 Copper row | 3678 |
| SS70-315-40 | 315 | 600 | M-SS-06 | 50*6 Copper row | 3678 |
| SS70-355-40 | 355 | 700 | M-SS-06 | 50*6 Copper row | 3678 |
| SS70-400-40 | 400 | 780 | M-SS-06 | 50*8 Copper row | 3678 |
| SS70-450-40 | 450 | 820 | M-SS-06 | 50*8 Copper row | 3678 |
| SS70-500-40 | 500 | 960 | Cabinet | 50*10 Copper row | 3678 |
| SS70-630-40 | 630 | 1100 | Cabinet | 50*12 Copper row | 3678 |

Note:

- When ordering, please inform the supplier of the product model, specifications, load and use conditions in order to correctly select the product.
 - The standard soft start configuration of this model includes the bypass contactor and the current detection transformer.
- The accessories in the above table are for reference only.

The body type and matching power of the SS70 built-in bypass soft starter are shown in the table:

Size number and matching power of SS70-690V are shown below

| Model | Adapt to the motor power (KW) | Rated current (A) 690V | Enclosure mode | Control power supply minimum capacity /VA |
|-------------|-------------------------------|---------------------------|----------------|---|
| SS70-030-69 | 30 | 31 | M-SS-02 | 300 |
| SS70-037-69 | 37 | 38 | M-SS-02 | 300 |
| SS70-045-69 | 45 | 46 | M-SS-02 | 300 |
| SS70-055-69 | 55 | 57 | M-SS-02 | 300 |
| SS70-075-69 | 75 | 77 | M-SS-02 | 300 |
| SS70-090-69 | 90 | 93 | M-SS-03 | 400 |
| SS70-110-69 | 110 | 114 | M-SS-03 | 400 |
| SS70-132-69 | 132 | 136 | M-SS-04 | 905 |
| SS70-160-69 | 160 | 165 | M-SS-04 | 905 |
| SS70-185-69 | 185 | 191 | M-SS-04 | 905 |
| SS70-200-69 | 200 | 207 | M-SS-05 | 1600 |
| SS70-220-69 | 220 | 227 | M-SS-05 | 1600 |
| SS70-250-69 | 250 | 258 | M-SS-05 | 1600 |
| SS70-280-69 | 280 | 289 | M-SS-05 | 1600 |
| SS70-315-69 | 315 | 325 | M-SS-05 | 1600 |
| SS70-355-69 | 355 | 367 | M-SS-05 | 1600 |
| SS70-400-69 | 400 | 413 | M-SS-05 | 1600 |
| SS70-450-69 | 450 | 465 | M-SS-05 | 1600 |
| SS70-500-69 | 500 | 517 | M-SS-06 | 3678 |
| SS70-630-69 | 630 | 651 | M-SS-06 | 3678 |

Note:

- When ordering, please inform the supplier of the product model, specifications, load and use conditions in order to correctly select the product.
 - The standard soft start configuration of this model includes the bypass contactor and the current detection transformer.
- The accessories in the above table are for reference only.

Chapter 3 Installation and Wiring

3.1 Installation of the soft starter

The soft starter should be installed indoors and in a well-ventilated place; vertical installation, do not install it upside down, obliquely or horizontally; install the base should be firm and flat. Leave enough space around.

When choosing an installation environment, you should pay attention to the following:

- 1) The ambient temperature should be in the range of $-10\text{ }^{\circ}\text{C} + 40\text{ }^{\circ}\text{C}$. If the temperature exceeds $40\text{ }^{\circ}\text{C}$, heat dissipation measures or derating should be adopted;
- 2) The humidity requirement is lower than 95%, and no water condensation occurs;
- 3) Install in a place where the vibration is less than $5.9\text{m/s}^2 (0.6g)$;
- 4) Avoid installation in direct sunlight;
- 5) Avoid installing in dusty and metal powder places;
- 6) It is strictly forbidden to install in places with corrosive or explosive gas;

Notice:

If there are special installation requirements, please consult and confirm in advance.

Installation interval and distance requirements, as shown in Figure 3-1a:

When multiple soft starters are installed, as shown in Figure 3-1b, when the two soft starters are installed up and down, a deflector should be added in the middle as shown in Figure 3-1c.





Figure 3-1a Installation space distance (mm)





Figure 3-1b Multiple installation



The ventilation direction is shown in Figure 3-1d:




Figure 3-1d Ventilation direction

Please install according to the above installation space to ensure that this product can work normally in a good environment. For special installation requirements, please contact the manufacturer in advance.

3.2 Wiring of soft starter



Gaution

- Only after confirming that the power supply of the soft starter is reliably cut off and the ownership indicator of the display panel goes out, wait 3 minutes before opening the panel.
- Only after confirming that the power of the main circuit of the soft starter has been reliably disconnected, the wiring of the main circuit and the control circuit can be performed.
- Please carefully check the voltage level of the soft starter before power on, otherwise equipment damage and personal injury may be caused.

3.2.1 Overview

SS70 series wiring part is divided into main circuit and control circuit. Users can choose different connections according to different needs.

The main circuit consists of three-phase input power cables and motor power cables, as shown in Figure 3-2b




Figure 3-2a Conventional soft starter wiring diagram

Figure 3-2b SS70 soft starter wiring diagram

3.2.2 I/O terminals of main circuit and external control terminals

The sequence of the input and output terminals of the main circuit is shown in Figure 3-3:
The main circuit input and output terminal functions are shown in Table 3-1

Table 3-1 Main circuit input and output terminal function table

| Terminal symbol | Description |
|-----------------|-----------------------|
| 1/L1 3/L2 5/L3 | 3phase AC power input |
| 2/T1 4/T2 6/T3 | Motor input |




Figure 3-3 Input and output terminals

The control terminals of SS70 series soft starter as the Figure 3-4:



Figure 1-1 Arrangement of built-in soft starter control terminals of SS70 series


Control terminal function description:

SS70 has 14 external control terminals for external signal control, remote control and system control, as shown in Table 3-5:

Table 3-5 External control terminal

| Terminal number | Terminal name | Description | Terminal number | Terminal name | Description | |
|-----------------|---------------------------------|--------------------------------|--------------------|-------------------------------------|-----------------------------------|-----------------|
| M² Bus | PIN1 : COM | Isolated 12V output | EAR/7 | PE | Ground | |
| | PIN8 : Isolated 12V output | | PA/8 | Programmable relay | Programmable | |
| | PIN4 : 485-A | PB/9 | Common terminal | | | |
| | PIN5 : 485-B | Modbus-RTU | | TA/10 | Fault output relay | Common terminal |
| C1/1 | Analog output | Optional 4~20mA/0~10V | TB/11 | Fault output normally open terminal | | |
| C2/2 | | X1/3 | Programmable input | Programmable | | |
| X2/4 | External control start terminal | X2/4 and COM /6 close to start | L/13 | Control power input terminal | AC220V, 50Hz (optional 110V, 60z) | |
| X3/5 | External control stop terminal | X3/5 and COM/6 open to stop | N/14 | | | |
| COM/6 | Common terminal | Logic input common | | | | |

Figure 3-6 shows the standard wiring diagram of the SS70 built-in bypass soft starter:



Attention:
SS70 Series built-in soft starter adopts two start-stop control modes: panel, control terminal two lines and three lines
1. two-line control is hold signal three-line control is trigger signal.
2. With the two-line control, the panel control is invalid.
3. When using the three-line control, the panel control is effective
4. X3 and COM must be kept closed for panel control.

Figure 3-6 Standard wiring diagram of the SS70 built-in bypass soft starter

3.2.3 Control circuit configuration and wiring




Figure 3-7 Overall structure of SS70 built-in bypass soft starter



Notice :

It is recommended to use a wire of 1mm² or more as the terminal connection wire.

3.2.4 Field wiring requirements and grounding requirements

1, Field wiring requirements:

In order to avoid mutual coupling and interference during the operation of the equipment, control cables, power cables, and motor cables should be installed separately. Generally, there should be a sufficient distance between them and as far as possible, especially when the cables are installed in parallel and extend long distance. When the signal cable must pass through the power cable or the motor cable, keep the two vertically crossed, as shown in Figure 3-7.




Figure 3-7 System wiring requirements

The main cable of the soft starter should be a cable with a specified area. The control cable is generally a shielded cable, and the shielded metal mesh should be connected to the ground terminal or ground point of the soft starter through the cable clamps at both ends.

2. Grounding requirements:

Dedicated ground electrode (recommended), as shown in Figure 3-8a:




Figure 3-8a Grounding schematic 1

Common ground electrode (allowed), as shown in Figure 3-8b:




Figure 3-8b Grounding schematic 2

Common ground wire (not allowed), as shown in Figure 3-8c:




Figure 3-8c Grounding schematic 3

In addition, you should pay attention to the following:

a) In order to ensure that the impedance of different grounding systems is as low as possible, the largest standard size of the grounding cable should be used as much as possible.

b) It is better to use flat cables, because cables with the same cross-sectional area have a lower high-frequency impedance than flat conductors.

c) One end of the grounding cable in the motor cable (4-core) between the motor and the soft starter is grounded on the soft starter side, and the other end is connected to the motor ground end; if the soft starter and the motor have a dedicated grounding end, the effect will be more good.

d) The grounding cable should be far away from the wiring to the 1 / 0 of the third device, and the grounding point should be as short as possible, and the grounding point should be as close to the soft starter as possible.

3.2.5 Precautions

- 1) The soft starter should be installed in an environment that meets the requirements of the standard, and should be kept away from dangerous places with flammable gas, explosive gas or dust to prevent fire or explosion.
- 2) After the soft starter is powered on, it is forbidden to contact the internal electrical components and perform any inspection.
- 3) When connecting the input circuit of the soft starter, the power must be cut off first.
- 4) Do not connect the power supply voltage exceeding the allowable fluctuation range to the soft starter, otherwise the device will be damaged.
- 5) Every time, check the circuit connection for errors, otherwise the soft starter will be damaged.
- 6) Make sure that the soft starter is safely grounded before running.
- 7) The control circuit wiring should be as far away as possible from the main power circuit connection cable to prevent malfunction due to interference noise.
- 8) If the control circuit connection line must pass through the main power line, it should be made straight through; if the connection line is longer, twisted pair or shielded line should be used.

Chapter 4 Soft Starter Operation Instructions

4.1 Terminology

The parameters of the SS70 are mentioned in this chapter. For details, please refer to the chapter Fifth on page P19.

4.2 LCD keyboard display unit description

The SS70 LCD display description is shown in Figure 4-1:




Figure 4-1 LCD keyboard display unit

4.2.1 Keyboard Function Description

There are 6 keys on the operation panel, and the function definition of each key is shown in Table 4-1.

Table 4-1 Key functions

| Key | Name | Functions |
|------------|---------------|---|
| MODE | Programming | Enter and exit programming state |
| SET | Setting | Data write confirmation under parameter setting modification state |
| RUN | Running | When the keyboard mode is valid, press this key to start the output in the stop state |
| ▲ | Increment | Data and function code are incremented; information screen group is switched up |
| ▼ | Decrement | Data and function code are decremented; information screen group is switched down |
| STOP/RESET | Stop Reset | When the keyboard mode is valid, press this key to stop output in the running state Return to initial screen when fault reset / parameter setting; |

When an alarm occurs in the SS70 built-in bypass type soft starter, the four indicators flash simultaneously. Please perform troubleshooting before starting. Press the increment key (▲) or decrement key (▼) in each message screen group. You can switch up or down in the screen content of each group.

4.2.2 Indicator description

SS70 operation panel has 4 indicators, stop indicator, soft start indicator, run indicator, soft stop indicator. The meaning of each indicator is shown in Table 4-2:

Table 4-2 Indicator function description

| indicator | Meaning | Indicator color | Sign |
|----------------|----------------------------|-----------------|----------------|
| Stop | Light on, stopped | Red | Stop |
| Soft start | Light on, soft start state | Green | S, Run |
| Run | Light on, running | Green | Run |
| Soft stop | Light on, soft stop state | Red | S, Stop |
| All lights off | Light on, fault state | No | All lights off |

Note :

When an alarm occurs in the soft starter, all four indicators are off. Please perform troubleshooting before starting.

4.2.3 Information screen introduction and operation

The info of SS70 screen has nine items: 1, Average current; 2, Phase A current; 3, Phase B current; 4, Phase C current; 5, Input voltage; 6, The output voltage; 7, Module temperature; 8, alarm record; 9, Version Information. Power on the soft starter, enter the main information screen content after displaying the startup status screen, and you can view the information in sequence by pressing the increment key (▲) or decrement key (▼) to view the information in turn.

The information screen is shown in Table 4-3:

Table 4-3 Main information screen display table

| Name | Screen display | Introduction |
|---------------------|--|--|
| screen | Average current | Display motor terminal voltage display content is average current value |
| | Phase A current | Display, phase A current |
| | Phase B current | Display, phase B current |
| | Phase C current | Display, phase C current |
| | Input voltage | The displayed content is the average voltage value of the detected three-phase voltage |
| | The output voltage | Display motor terminal voltage |
| | Module temperature | The temperature value is the value detected by the soft starter temperature sensor to the thyristor radiator |
| alarm record | 0000: First alarm | The last one alarms |
| | 0000: Second alarm | The last two alarms |
| | 0000: Third alarm | The last three alarms |
| | 0000: Fourth alarm | The last four alarms |
| | the displayed code corresponds to page 23 of Chapter 6, Troubleshooting and Exception Handling | |
| Version Information | The version information displayed on this screen is the version number of the operation display unit | |

Press the increment key (▲) or decrement key (▼), in the operation panel to switch up or down in the screen content. Figure 4-2 shows the screen content switching operation process:




Figure 4-2 shows the screen content switching operation process

4.2.4 Function code parameter setting process

1) Soft starter function code mode

SS70 built-in bypass type soft starter has 36 function codes in total: F-00 ~ F-35. For example, "F-00" means the first function code.

2) Menu structure of display unit

When setting the function code through the digital tube display unit, the function code number corresponds to the first-level menu, and the function code parameter corresponds to the second-level menu.

3) Function code setting example

The built-in bypass soft starter of SS70 adopts decimal representation. Each of them is independent when editing. The value range of some bits can be decimal (0-9). The parameter value has one, ten, one hundred, and thousand digits. Use the (Run) key to select the digit to be modified, and use the increase key (▲) or decrease key (▼) to increase or decrease the value. Take the parameter function menu to change the soft stop time from 10s to 25S (F-01 changed from 10S to 25S) as an example to explain the setting operation process, as shown in Figure 4-3:

Chapter 5 Detail Function Description and Settings

This chapter mainly explains the function parameters of SS70 built-in bypass type soft starter in detail. According to the function, it is divided into 33 function codes, which are:

| | |
|-------------------------------|--------------------------------|
| F-00: Starting mode; | F-01: soft start time; |
| F-02: soft stop time; | F-03: start-stop voltage; |
| F-04: current limiter; | F-07: Spike voltage; |
| F-08: Jump time; | F-09: Jump interval; |
| F-10: number of hops; | F-11: Run over stream; |
| F-12: Overload protection; | F-13: Overload mode; |
| F-14: Display mode; | F-15: motor over-temperature; |
| F-16: Overvoltage protection; | F-17: undervoltage protection; |
| F-18: phase-out; | F-19: module over-temperature; |
| F-20: timeout protection; | F-21: unbalanced; |
| F-22: Fire count; | F-23: Start delay; |
| F-24: mailing address; | F-25: Baud rate; |
| F-26: Parity check; | F-27: K1 programming; |
| F-29: X1 programming; | F-30: Analog output; |
| F-31: Fire mode; | F-32: Initialization; |
| F-33: Language selection; | F-34: Motor current; |
| F-35: manufacturer's code; | |

The function code described as follows:

| Code | Name | Setting Range | Defaults |
|------|------|---------------|----------|
|------|------|---------------|----------|

5.0 Start Mode (F-00)

| | | | |
|------|------------|---------|-------------|
| F-00 | Start Mode | 范围: 0-2 | Defaults: 0 |
|------|------------|---------|-------------|

- 0: Ramp current
- 1: Current limiting
- 2: Ramp voltage




Figure 5-1 Initial voltage and time

The current in F-01 is the ramp current




Figure 5-2 Limiting current amplitude

The shaded area is the set current limit




Figure 5-3 Ramp voltage

0-T1 is the ramp voltage

5.1 Soft Start Time (F-01)

| | | | |
|------|-----------------|---------------|--------------|
| F-01 | Soft start time | scope: 1-120S | Defaults: 10 |
|------|-----------------|---------------|--------------|

The soft start time is the time required from the start of the startup to the completion of the start process.

In order to obtain the best start-stop effect, different starting voltages and times can be set for adjustment. See Figure 5-1 for start mode for details.

5.2 Soft Stop Time (F-02)

| | | | |
|------|----------------|---------------|-------------|
| F-02 | Soft stop time | scope: 0-120S | Defaults: 0 |
|------|----------------|---------------|-------------|

In order to enable the mechanical load to stop smoothly without generating secondary impact and to minimize mechanical and electrical damage, F-02 and F-03 can be combined to achieve a stable stop of the mechanical load, as shown in Figure 5-4. As shown:



Note:

When the soft stop time is set to 0, the motor will stop freely.

5.3 Stop and start voltage (F-03)

| | | | |
|------|--------------------|-----------------|--------------|
| F-03 | Start-stop voltage | scope: 20-75%Ue | Defaults: 25 |
|------|--------------------|-----------------|--------------|

The start-stop voltage refers to the voltage value at which the initial output voltage of the soft start and the output control voltage at the time of stopping are reduced to the minimum. In order to obtain the best start-stop effect, different start / stop voltages and times can be set to adjust. Set the percentage of the range value based on Ue.




Figure 5-4 Stop voltage and time

Ue in the figure shows the stop voltage value the soft stop time is determined by F-02.

5.4 Current Limit Amplitude (F-04)

| | | | |
|------|---------------|-------------------|---------------|
| F-04 | Current limit | scope: 150-600%Ie | Defaults: 350 |
|------|---------------|-------------------|---------------|




Figure 5-5 Current limit amplitude diagram

The starting current of the soft starter is limited to a setting range based on the rated current, as shown in Figure 5-5.

5.5 Jump voltage (F-07)

| | | | |
|------|--------------|-----------------|---------------|
| F-07 | Jump voltage | scope: 20%-100% | Defaults: 100 |
|------|--------------|-----------------|---------------|

| | | | |
|------|-----------|----------------|-------------|
| F-08 | Jump time | scope: 0T-500T | Defaults: 0 |
|------|-----------|----------------|-------------|

Jump time is the time for one jump

Unit: period (grid frequency)



Note:

When set to 0, the jump time is turned off.

| | | | |
|------|---------------|--------------|-------------|
| F-09 | Jump interval | scope: 0-50T | Defaults: 0 |
|------|---------------|--------------|-------------|

Jump interval is the time between two jumps.

During the jump interval meter, the thyristor is turned off without output. Unit: period (grid frequency).



Note:

When set to 0, the jump interval is turned off.

| | | | |
|------|------------|--------------|-------------|
| F-10 | Jump times | scope: 0-100 | Defaults: 0 |
|------|------------|--------------|-------------|



Note:

When set to 0, the jump interval is turned off.

5.6 Running over current (F-11)

| | | | |
|------|------------------|-----------------|----------|
| F-11 | Run over current | scope: 0-400%Ie | 出厂值: 150 |
|------|------------------|-----------------|----------|

The soft starter detects that the running current exceeds this set value of F-11 during the running process. After the duration reaches T, the system makes an overcurrent protection action and stops and displays an overcurrent alarm, as shown in Figure 5-6




Figure 5-6 Overcurrent protection



Note:

When set to 0, no operation overcurrent protection is performed.

When the overcurrent time t is less than the set overcurrent detection time T, overcurrent protection is triggered.

When the overcurrent time t is greater than the set overcurrent detector time T, an alarm is issued.

5.7 Overload protection (F-12)

| | | | |
|------|---------------------|------------|-------------|
| F-12 | overload protection | scope: 0-4 | Defaults: 3 |
|------|---------------------|------------|-------------|

Select different protection levels according to the load of the soft starter. Table 5-1 shows the corresponding current multiples and trip times of different levels.

Overload protection level 1 is light load, level 2 is light load, level 3 is standard and level 4 is heavy load.

| Time gear Delay time Tuning current Overload current | 1 | 2 | 3 | 4 |
|---|--------|--------|--------|--------|
| | 1.2 | 40~60S | 1~2m | 2~3m |
| 1.5 | 20~40S | 20~40S | 1~1.5m | 1.5~3m |
| 4 | 2~5S | 5~8S | 8~11S | 11~20S |
| 6 | 1~2S | 2~4S | 4~5S | 4~8S |

Table 5-1 Overload level current multiple and trip time

When the running current value exceeds the current multiple of the corresponding protection level, it will act within this protection level trip time, and the protection level coefficients are downward compatible. The overload level curve is shown in Figure 5-7.




Figure 5-7 Overload level curve

| | | | |
|------|---------------|------------|-------------|
| F-13 | Overload mode | Range: 0~1 | Defaults: 0 |
|------|---------------|------------|-------------|

- 0: Soft start, the running process is valid.
1: The running process is valid.

5.8 Display Mode (F-14)

| | | | |
|------|--------------|------------|-------------|
| F-14 | Display Mode | Range: 0~2 | Defaults: 0 |
|------|--------------|------------|-------------|

- 0: Temperature interface displays module temperature
1: Temperature interface displays motor temperature
2: Switch motor temperature and module temperature display at the same time

5.9 Electric over temperature (F-15)

| | | | |
|------|---------------------------|----------------|---------------|
| F-15 | Electric over temperature | Range: 0-100 C | Defaults: 0 C |
|------|---------------------------|----------------|---------------|

0: Closed

Note:

This feature requires the installation of a PT100 temperature expander

5.10 Overvoltage protection (F-16)

| | | | |
|------|------------------------|----------------|---------------|
| F-16 | Overvoltage protection | Range: 0-1000V | Defaults: 480 |
|------|------------------------|----------------|---------------|

For the three-phase voltage is too high, the soft starter will detect whether the voltage value exceeds the set value of the F-16 function code, and after the system alarm time continues, the soft starter will perform over-voltage protection and alarm.

Note:

When the over-voltage protection setting value is 0, the over-voltage protection does not work.

5.11 Undervoltage protection (F-17)

| | | | |
|------|-------------------------|----------------|---------------|
| F-17 | Undervoltage protection | Range: 0-1000V | Defaults: 280 |
|------|-------------------------|----------------|---------------|

The soft starter performs protection operation when it detects that the input three-phase voltage is lower than the set value.

When it is lower than the set value of the F-17 function code and continues to exceed the set time, the soft starter performs undervoltage protection and alarms.

Note:

When the under voltage protection setting value is 0, the soft starter does not perform under voltage protection operation.

5.12 Output phase loss (F-18)

| | | | |
|------|-------------------|--------------|--------------|
| F-18 | Output phase loss | Range: 0~30% | Defaults: 5% |
|------|-------------------|--------------|--------------|

0: off

Others: If there is less than setting% le in three phases, it is lack of phase and undercurrent.

5.13 Module Overtemperature (F-19)

| | | | |
|------|----------------------|---------------|--------------|
| F-19 | SCR Over Temperature | Range: 0-90 C | Defaults: 85 |
|------|----------------------|---------------|--------------|

The soft starter detects that the temperature of the module is higher than the set value of F-19, and performs protection operation after continuously exceeding the set time

Note:

When the module over-temperature protection setting value is 0, the soft starter does not perform over-temperature protection operation.

5.14 Timeout protection (F-20)

| | | | |
|------|--------------------|---------------|--------------|
| F-20 | Timeout protection | Range: 0-120S | Defaults: 20 |
|------|--------------------|---------------|--------------|

During the start of the soft starter, when the time of the start process exceeds the value set by this function code, it will output a start timeout alarm.

Note:

When set to 0, no timeout alarm protection is performed.

5.15 Imbalance (F-21)

| | | | |
|------|------------|----------------|---------------|
| F-21 | Imbalanced | Range: 0%~100% | Defaults: 50% |
|------|------------|----------------|---------------|

Maximum and minimum current values in %Ie basis for three-phase current

The difference is greater than the read set value Ie, the system alarm.

Note:

When set to 0, unbalance protection is not performed

5.16 Fire counting (F-22)

| | | | |
|------|---------------|--------------|-------------|
| F-22 | Fire counting | Range: 0~999 | Defaults: 0 |
|------|---------------|--------------|-------------|

Enter fire mode once and count once

5.17 Communication & control (F-23-F-29)

| | | | |
|------|---------------|--------------|-------------|
| F-23 | Delayed start | Range: 0~60s | Defaults: 0 |
|------|---------------|--------------|-------------|

0: off

| | | | |
|------|---------------|--------------|-------------|
| F-24 | Communication | Range: 0~255 | Defaults: 1 |
|------|---------------|--------------|-------------|

| | | | |
|------|-----------|------------|-------------|
| F-25 | Baud rate | Range: 0~2 | Defaults: 0 |
|------|-----------|------------|-------------|

- 0: 4800bps
1: 9600bps
2: 19200bps

| | | | |
|------|--------------|------------|-------------|
| F-26 | Parity check | Range: 0-2 | Defaults: 0 |
|------|--------------|------------|-------------|

- 0: No parity
1: odd
2: even

| | | | |
|------|----------------|-------------|-------------|
| F-27 | K1 Programming | Range: 0-11 | Defaults: 0 |
|------|----------------|-------------|-------------|

- 1: Bypass state output
11: Fire mode output
Others: Closed

| | | | |
|------|------------|-------------|-------------|
| F-29 | X1 program | Range: 0-11 | Defaults: 0 |
|------|------------|-------------|-------------|

- 1: Reset
2: Emergency stop
11: Fire mode input
Other: Closed

5.18 Analog output (F-30)

| | | | |
|------|---------------|---------------|-------------|
| F-30 | Analog output | Range: 0~9999 | Defaults: 0 |
|------|---------------|---------------|-------------|

0: off

Others: Set current corresponding to analog 20mA output

5.19 Fire Mode (F-31)

| | | | |
|------|-----------|----------------|-------------|
| F-31 | Fire Mode | Range: 0~9999A | Defaults: 0 |
|------|-----------|----------------|-------------|

- 119: Fire mode
120: Fire mode, no counting mode
Others: Closed

5.20 Initialization (F-32)

| | | | |
|------|----------------|------------|-------------|
| F-32 | Initialization | Range: 0-2 | Defaults: 0 |
|------|----------------|------------|-------------|

- 0: Invalid
1: Restore factory settings
2: Clear alarm records

5.21 language selection (F-33)

| | | | |
|------|--------------------|------------|-------------|
| F-33 | language selection | Range: 0-1 | Defaults: 0 |
|------|--------------------|------------|-------------|

- 0: Chinese
1: English

5.22 Motor current (F-34)

| | | | |
|------|---------------|----------------|---------------|
| F-34 | Motor current | Range: 1-9999A | Defaults: 11A |
|------|---------------|----------------|---------------|


Motor rated current.

5.23 Factory Password (F-35)

| | | | |
|------|------------------|---------------|----------------|
| F-35 | Factory Password | Range: 0-9999 | Defaults: **** |
|------|------------------|---------------|----------------|

The factory password is only used by the manufacturer to set. The end user does not need to set it.

Chapter 6 Fault countermeasures and Exception Handling



Warning/Danger

- The fault technical troubleshooting and maintenance operation should be carried out only when the disconnected power supply soft starter display (LCD or status indicator) goes off and confirms that the bus voltage is below 36V, otherwise it may cause personal injury, electric shock, fire and other dangers.
- Only professional personnel can replace the parts. It is strictly forbidden to leavewire ends or metal objects in the machine, otherwise it may cause fire and other dangers.
- After replacing the control motherboard, it must be confirmed that the motherboard is working normally before the power operation, otherwise the property damage.

SS70 built-in bypass soft starter not only reflects superior performance when starting and stopping, but also accurate and reliable in product protection. SS70 built-in bypass soft starter has various protection functions to comprehensively protect motor and drag equipment, such as phase absence, overvoltage, underpressure, underpressure, overtemperature, imbalance, overtime, overload, overcurrent, and external fault input. When the system detects alarm signal, the LCD display the relevant alarm information, and the system will prohibit output within a weekly wave to protect the products and equipment and personal safety. Complete product common fault types and handling methods are shown in the following table:

| Error alarm Display type | Possible reason | Solutions | Operating status | | | |
|------------------------------|---|--|------------------|---------|-----------|------|
| | | | Soft start | Running | Soft stop | Stop |
| X3 and COM are not connected | External control terminal X3 and COM are not connected during panel control | Connect external control terminal X3 and COM correctly | | | | ✓ |
| Er01 Run overcurrent | In the normal running process, when the measured running current > F-04 set value, the system will give an alarm within a cycle. | <ol style="list-style-type: none"> 1. Check whether the motor model is consistent with the nameplate of the soft starter: whether the rated power, the voltage is consistent, whether the rated power exceeds the rated power of the nameplate of the soft starter. If not, please replace the match before debugging. 2. Check whether there is a short circuit or grounding phenomenon between the motor and the soft starter. 3. Check for an overload. 4. Increase the setting value of function code F-11. 5. Check part of the application setting and whether the load type is within the scope of the soft starter. 6. Turn off the overcurrent protection function and change the F-11 settings to 0. | | ✓ | | |
| Er02 Module overtemperature | When the system monitors the temperature of the drive module > F-19 setting value through the sensor, the system submits the overtemperature alarm. | <ol style="list-style-type: none"> 1. Check whether the ambient temperature is too high (if there is direct sunlight, whether it is installed in the closed environment), resulting in the temperature of the radiator module in the soft starter can not drop in time, exceeding the set value of the function code (F-19) over temperature protection, the corresponding cooling treatment (such as air cooling or shutdown cooling treatment). 2. Check whether the soft starter accessories has heat source (such as electric furnace, heater, etc.), remove the heat source and use the soft starter. 3. If the soft starter starts and stops frequently in a short time, the internal power device 1 will be in a high current running state, and the radiator module will be overwork. Please wait for a period of time (> 5 minutes) until the radiator module cools before operating. | | ✓ | ✓ | |
| Er03 Start timeout | During the motor starting process, when the starting time does not accelerate to full speed (fully operation state) in F-20 time, the system output alarm | <ol style="list-style-type: none"> 1. Please check whether the rated power of the user motor exceeds the rated power of the soft starter. 2. Please check the heavy load, and please increase the soft start time. | | | | |
| Er04 System phase loss | The system has three-phase power supply, any phase is missing or connected, and the output end of the motor is missing, and the phase, the system will give an alarm output in the first time | <ol style="list-style-type: none"> 1. Check whether the three-phase input power supply has any phase deficiency phenomenon. 2. Check the good contact of the three-phase power input to the soft starter. 3. Check the connection between motor to soft starter for disconnection. 4. Check the connection between motor to soft starter for poor contact or grounding. | ✓ | ✓ | | ✓ |

| Fault alarm display type | Cause of action | Solution | Operating status | | | |
|-----------------------------------|---|---|------------------|---------|-----------|------|
| | | | Soft start | Running | Soft stop | Stop |
| Er05 Power supply overvoltage | When the system detects the grid voltage; F-16 setting value of the input three-phase power supply, the system will submit the alarm within one cycle. | 1. Check whether the three-phase input voltage value exceeds the set value of the grid voltage; F-16 is exceeded, disconnect the power supply and wait for the power voltage value to return to the normal value (below the set value of the overvoltage protection of function code (F-16)). 2. Check the voltage level consistent with the nameplate on the machine. 3. This protection is closed when the function code (F-16) is set to 0. | ✓ | ✓ | ✓ | ✓ |
| Er06 Power supply undervoltage | The grid voltage of the three-phase input power supply is <the set value of F-17, and the system will alarm the output within one cycle. | 1. Check whether the three-phase input voltage value is below the set value of undervoltage protection of function code (F-17). If it is below the set value, disconnect the power supply and wait for the power supply voltage value to return to the normal value (above the set value of undervoltage protection of function code (F-17)). 2. Check the voltage level consistent with the nameplate on the machine. 3. This protection is closed when F-17 is set to 0. | ✓ | ✓ | ✓ | ✓ |
| Er07 Overload protection | When the operating current reaches the overload level set by F-12, the system makes a fault alarm (see the relevant overload protection curve). | 1. Check whether the motor power exceeds the rated power of the soft starter. If so, please replace the match and try again. 2. Check whether the load of the fruit motor is too heavy, or the load has a fluctuation during operation. 3. The value of the function code F-12 to change the system operation overload protection curve to operate the device in the normal area. 4. Modify the F-12 setting value to 0, and turn off the system overload protection function. | ✓ | ✓ | ✓ | ✓ |
| Er08 Voltage imbalance | When the difference between the maximum and the minimum operating current reaches the product of the F-21 set value and the rated current, the system alarms within a period. | 1. Check the motor for aging. 2. Check whether the three-phase input voltage is unbalanced. 3. Check whether the power supply input and output wiring is secure. | ✓ | ✓ | ✓ | ✓ |

Chapter 6 Maintenance and Maintenance

Due to the influence of environmental temperature, humidity, dust and vibration, aging and wear inside the soft starter, will lead to the potential failure of the soft starter, it is necessary to carry out daily and regular maintenance and maintenance of the soft starter.

Note :
Before inspection and maintenance, please first confirm that the soft starter has cut off the power supply and the power indicator light is off, otherwise the risk of electric shock will occur.

7.1 Product routine maintenance and inspection

The soft starter must operate according to the operating environment specified in this book. In addition, there may be some accidents in the operation, users should follow the following below, daily maintenance work, to maintain a good operating environment. It is a good way to extend the service life of the soft starter and early detection of abnormal causes for recording the daily operation data. See Table 7-1:

Table 7-1 Daily inspection tips

| Check object | Check the essentials | | judging critena |
|-----------------------|-----------------------|---------------------|---|
| | Check content | Inspection means | |
| Operating environment | temperature | thermometer | -10℃ ~ + 40℃ exceeds 40 C should derating be used No water leaks Less than 5.9 m / s (0.6g) odorless |
| | humidity | humidometer | |
| | Dust, water and drips | Visually | |
| | vibration | DeVibration Meter | |
| Soft starter | gas | Sniff | Smooth, normal air No abnormal sound In the rated value range In the rated value range |
| | heat | Touch case | |
| | sound | listen | |
| | Output current | Current clamp meter | |
| Motor | The output voltage | Voltmeter | No abnormal fever No abnormal sound |
| | heat | houch | |
| | sound | listen | |

7.2 Regular maintenance

Depending on the use environment, the user can conduct regular inspection of products for 3 or 6 months.

Note :
1)) Personnel responsible for maintenance work must have professional training.
2) Do not leave metal parts in the machine, otherwise there is a danger of damaging the equipment.


General inspection content:

- Whether the control terminal screws are loose, tighten with a screwdriver;
- Whether the main circuit terminals are badly connected; whether there are overheating marks on the screw position.
- Whether the power cables and control cables are damaged, especially whether there are cuts on the skin that is in contact with the metal surface;
- Whether the insulation bandage of the power cable nose has come off;
- Clean the dust on the circuit board and air duct thoroughly. it is best to use a vacuum cleaner.

6) The soft starter stored for a long time must be powered on once within half a year. When the power is powered on, the voltage regulator is slowly raised to the rated value, for nearly 5 hours, and can be carried out without load.

7) In the insulation test of the soft starter, all the input and output terminals must be short connected with wires to test the protective area. It is strictly prohibited to test the single terminal, otherwise there is a risk of damage to the soft starter.

8) If the motor is tested for insulation, the connection between the motor and the soft starter must be disconnected, and the motor must be tested separately, otherwise the soft starter will be damaged.

 **Note :**
The withstand voltage test has been passed before leaving the factory. The user does not need to perform withstand voltage test, otherwise the device will be damaged.


7.3 Soft starter storage

After the user purchases the soft starter, the temporary storage and long-term storage must pay attention to the following points:

- 1) Avoid storage in places with high temperature, humidity, and dust or metal dust. Keep the storage environment well ventilated.
- 2) Long-term storage will cause the deterioration of electrolytic capacitors. It must be ensured that it is energized once within 2 years, and the energization time is at least 5 hours. The input voltage must be slowly increased to the rated value with a voltage regulator.

7.4 Product warranty

The quality guarantee of this product shall be subject to the following provisions




- (1) Whenever and where the company motor soft starter, all enjoy lifetime paid service.
- (2) If the fault is caused by the following reasons, the company shall provide the paid repair service during the warranty period:
 - ① Problems caused by incorrect operation (subject to this use manual) or self-repair and modification without permission
 - ② Problems caused by the use of a motor soft starter beyond the standard specification requirements
 - ③ Damage resulting from improper handling or storage
 - ④ Device aging or failure caused by the environment
 - ⑤ Damage caused by earthquake, fire, flood, lightning strike, abnormal voltage or other natural disasters
 - ⑥ Intentionally damage the nameplate, mark and production serial number of the motor soft starter, which can not be identified separately
- (3) In case of quality problems or product accidents, the company will only bear the responsibilities mentioned in the specific content of the quality assurance in this chapter. If users need more liability guarantee, please insure the insurance company by yourself.
- (4) The relevant service fee shall be calculated according to the actual cost. If there is a contract, it shall be dealt with on the principle of contract priority. Safety assembly line specification parameters safety information operation instructions detailed fault countermeasures maintenance and maintenance application.






- a) The electrolytic capacitor of the main circuit and the electrolytic capacitor on the printed board may explode when incinerated.
- b) Toxic gas will be generated when plastic parts such as the front panel and the plastic case are incinerated.
- c) Please dispose as industrial waste.

Appendix 1: Application example diagram



Appendix 2: Dimensional drawing





NOTE :

